


AC Servo Drives

Σ -V-SD Series

USER'S MANUAL

Speed Reference with Analog Voltage
Expanded Functions

CACR-JU□□□□□E□ SERVOPACK
CACP-JU□□□□3□ Power Regeneration Converter
UAK□J-□□CZ□ Spindle Motor



Outline	1
Compatible Devices	2
Specifications and External Dimensions	3
Installation	4
Wiring	5
Control Signals	6
Winding Selection Control	7
Orientation Control with a Motor Encoder	8
Orientation Control with an External Encoder	9
Orientation Control with a Magnetic Sensor	10
Operation	11
Adjustments	12
Digital Operator	13
Standards Compliance	14
Inspection, Maintenance, and Troubleshooting	15
Appendix	16

Copyright © 2014 YASKAWA ELECTRIC CORPORATION

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of Yaskawa. No patent liability is assumed with respect to the use of the information contained herein. Moreover, because Yaskawa is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, Yaskawa assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

About this Manual

This manual describes information required for designing, testing, adjusting, and maintaining Σ -V-SD Series servo drives.

Keep this manual in a location where it can be accessed for reference whenever required. Manuals outlined on the following page must also be used as required by the application.


■ Description of Technical Terms

The following table shows the meanings of terms used in this manual.

Term	Meaning
Spindle Motor or Motor	Σ -V-SD Series UAKAJ and UAKBJ motor
Power Regeneration Converter	Σ -V-SD Series CACP-JU converter
SERVOPACK	Σ -V-SD Series CACR-JU servo amplifier
Σ -V-SD Driver	A power regeneration converter and a SERVOPACK
Servo Drive	A set including a spindle motor and a Σ -V-SD driver
Servo System	A complete system that consists of a servo drive, a host controller, and peripheral devices
Servo ON	The power to the motor ON
Servo OFF	The power to the motor OFF
Base Block (BB)	The power supply to motor is turned OFF by shutting off the base current to the power transistor in the current amplifier.
DC-bus Voltage	The main circuit DC voltage (between P and N terminals) in a power regeneration converter and a SERVOPACK

■ IMPORTANT Explanations

The following icon is displayed for explanations requiring special attention.

 IMPORTANT	<ul style="list-style-type: none">• Indicates important information that should be memorized, as well as precautions, such as alarm displays, that do not involve potential damage to equipment.
--	--

■ Notation Used in this Manual

• Notation for Reverse Signals

The names of reverse signals (i.e., ones that are valid when low) are written with a forward slash (/) before the signal name.

Notation Example

$\overline{\text{RDY}} = \text{/RDY}$

• Notation for Parameters

The notation depends on whether the parameter requires a value setting (parameter for numeric settings) or requires the selection of a function (parameter for selecting functions).

• Parameters for Numeric Settings

Control methods for which the parameter applies.					
	<input type="checkbox"/> Speed	<input type="checkbox"/> Position	<input type="checkbox"/> Torque		
Pn430	Torque Limit (Powering) <input type="checkbox"/> Speed <input type="checkbox"/> Position <input type="checkbox"/> Torque				
	Setting Range	Units	Factory Setting	When Enabled	Classification
	0 to 800	1%	150	Immediately	Setup

Parameter number

Indicates the setting range for the parameter.

Indicates the minimum setting unit for the parameter.

Indicates the parameter setting before shipment.

Indicates when a change to the parameter will be effective.

Indicates the parameter classification.

• Parameters for Selecting Functions

Parameter	Meaning	When Enabled	Classification
Pn460	n.□□□0	Immediately	Tuning
	n.□□□1 [Factory Setting]		
	n.□0□□		
	n.□1□□ [Factory Setting]		

Parameter number

The notation "n.□□□□" indicates a parameter for selecting functions. Each □ corresponds to the setting value of that digit. The notation shown here means that the third digit is 1.

This section explains the selections for the function.

■ Manuals Related to the Σ -V-SD Series

Refer to the following manuals as required.

Name	Selecting Models and Peripheral Devices	Ratings and Specifications	System Design	Panels and Wiring	Trial Operation	Trial Operation and Servo Adjustment	Maintenance and Inspection
Σ -V-SD Series Speed Reference with Analog Voltage Expanded Functions Catalog (KAEP S800001 41)	✓	✓					
Σ -V-SD Series Speed Reference with Analog Voltage Expanded Functions User's Manual (this manual)	✓	✓	✓	✓	✓	✓	✓
Σ -V-SD Series Speed Reference with Analog Voltage Expanded Functions Safety Precautions (TOMP C710829 13)	✓			✓			✓
AC Servo Drives Σ -V-SD Series SAFETY PRECAUTIONS Base Mounting Unit (TOMP C710829 08)	✓						✓
AC SPINDLE MOTOR/ AC SERVOMOTOR INSTRUCTIONS (TOE-C235-2)	✓						✓

■ Safety Information

The following conventions are used to indicate precautions in this manual. Failure to heed precautions provided in this manual can result in serious or possibly even fatal injury or damage to the products or to related equipment and systems.



Indicates precautions that, if not heeded, could possibly result in loss of life or serious injury.



Indicates precautions that, if not heeded, could result in relatively serious or minor injury, damage to the product, or faulty operation. In some situations, the precautions indicated could have serious consequences if not heeded.



Indicates prohibited actions that must not be performed. For example, this symbol would be used to indicate that fire is prohibited as follows:



Indicates compulsory actions that must be performed. For example, this symbol would be used to indicate that grounding is compulsory as follows:



Safety Precautions

This section describes important precautions that must be followed during storage, transportation, installation, wiring, operation, maintenance, inspection, and disposal. Be sure to always observe these precautions thoroughly.

WARNING

- Never touch any rotating motor parts while the spindle motor is running.
Failure to observe this warning may result in injury.
- Before starting operation with a machine connected, make sure that an emergency stop can be applied at any time.
Failure to observe this warning may result in injury or damage to the product.
- Never touch the inside of the power regeneration converters and SERVOPACKs.
Failure to observe this warning may result in electric shock.
- Do not remove the cover of power supply terminal while the power is ON.
Failure to observe this warning may result in electric shock.
- Do not touch power supply terminals before the main-circuit capacitor has had time to discharge after the power has been turned OFF. Refer to 5.2.1 *Main Circuit Power Supply* for the details of discharge time of main-circuit capacitor.
Residual voltage may cause electric shock.
- Do not touch terminals while the charge indicator is lit. First make sure the charge indicator is turned OFF and that the DC-bus (symbol: P and N) voltage value is correct by using a tester or other device before wiring or starting an inspection.
Residual voltage may cause electric shock.
- Do not touch terminals before the main-circuit capacitor has had time to discharge after voltage resistance test. Refer to 5.2.1 *Main Circuit Power Supply* for the details of discharge time of main-circuit capacitor.
Residual voltage may cause electric shock.
- Follow the procedures and instructions for the trial operation as noted in the applicable manual for that product.
Malfunctions that occur after the spindle motor is connected to the equipment not only damage the equipment, but may also cause an accident resulting in death or injury.
- Do not remove the front cover, cables, or connectors on the foreside while the power is ON.
Failure to observe this warning may result in electric shock.
- Do not damage, press, exert excessive force or place heavy objects on the cables.
Failure to observe this warning may result in electric shock, stopping operation of the product, or fire.
- Do not modify the product.
Failure to observe this warning may result in injury, damage to the product, or fire.
- Provide an appropriate braking device on the machine side to ensure safety.
Failure to observe this warning may result in injury.
- Do not come close to the machine immediately after resetting momentary power loss to avoid an unexpected restart. Take appropriate measures to ensure safety against an unexpected restart.
Failure to observe this warning may result in injury.
- Check the following items and settings before you use the anti-resonance control adjustment function.
 - Make sure that trial operation was completed successfully.
 - Set the moment of inertia ratio (Pn103) correctly.
 - Check the SigmaWin+ Operation Manual.There is a risk of injury or equipment damage if the above checks and settings are not performed.
- Connect the ground terminal to electrical codes (ground resistance: 100 Ω or less for a power regeneration converter and a SERVOPACK with a 200 V power supply. 10 Ω or less for a power regeneration converter and a SERVOPACK with a 400 V power supply).
Improper grounding may result in electric shock or fire.
- Installation, disassembly, or repair must be performed only by authorized personnel.
Failure to observe this warning may result in electric shock or injury.
- The person who designs a system using the Hard Wire Base Block function must have full knowledge of the related safety standards and full understanding of the instructions in this manual.
Failure to observe this warning may result in injury or damage to the product.



■ Storage and Transportation

CAUTION

- Do not store or install the product in the following places.
 - Locations subject to direct sunlight.
 - Locations subject to temperatures outside the range specified in the storage/installation temperature conditions.
 - Locations subject to humidity outside the range specified in the storage/installation humidity conditions.
 - Locations subject to condensation as the result of extreme changes in temperature.
 - Locations subject to corrosive or flammable gases.
 - Locations subject to dust, salts, or iron dust.
 - Locations subject to exposure to water, oil, or chemicals.
 - Locations subject to shock or vibration.

Failure to observe this caution may result in fire, electric shock, or damage to the product.

- Do not hold the motor by the cable and motor shaft while transporting it.
Failure to observe this caution may result in injury or malfunction.
- Do not hold the power regeneration converters and SERVOPACKs by the front cover or terminal cover while moving them.
Failure to observe this caution may result in damage to the covers or in a greater possibility of the products being dropped and damaged.
- Do not place any load exceeding the limit specified on the packing box.
Failure to observe this caution may result in injury or malfunction.
- If disinfectants or insecticides must be used to treat packing materials such as wooden frames, pallets, or plywood, the packing materials must be treated before the product is packaged, and methods other than fumigation must be used.
Example: Heat treatment, where materials are kiln-dried to a core temperature of 56°C for 30 minutes or more.

If the electronic products, which include stand-alone products and products installed in machines, are packed with fumigated wooden materials, the electrical components may be greatly damaged by the gases or fumes resulting from the fumigation process. In particular, disinfectants containing halogen, which includes chlorine, fluorine, bromine, or iodine can contribute to the erosion of the capacitors.

■ Installation

CAUTION

- Never use the products in an environment subject to water, corrosive gases, inflammable gases, or combustibles.
Failure to observe this caution may result in electric shock or fire.
- Do not step on or place a heavy object on the product.
Failure to observe this caution may result in injury or malfunction.
- Do not cover the inlet or outlet ports and prevent any foreign objects from entering the product.
Failure to observe this caution may cause internal elements to deteriorate resulting in malfunction or fire.
- Be sure to install the product in the correct direction.
Failure to observe this caution may result in malfunction.
- Provide the specified clearances between the power regeneration converter and the inside surface of the control panel and between the SERVOPACK and the inside surface of the control panel, and keep both the converter and the SERVOPACK sufficiently separated from all other devices.
Failure to observe this caution may result in fire or malfunction.
- Do not apply any strong impact.
Failure to observe this caution may result in malfunction.
- Provide sufficient space so that cooling air will be provided to the cooling fan. Keep a space of at least 100 mm between the machine and the ventilation outlet of the spindle motor.
If ventilation is not proper, the motor temperature fault protective function will work regardless of whether or not the load is at the rated value or not.
- Install the spindle motor in a clean location free from oil mist and water drops. If the spindle motor is likely to come in contact with water or oil, protect the spindle motor with a cover.
The intrusion of water or dirty oil into the interior of the spindle motor will decrease the insulation resistance, which may result in a ground fault.
- Check that the mounting bed, base, or stand of the spindle motor is of robust construction.
The weight of the spindle motor as well as the dynamic load of the motor in operation will be imposed on it, possibly causing vibration.

■ Wiring

CAUTION

- Be sure to wire correctly and securely.
Failure to observe this caution may result in spindle motor overrun, injury, or malfunction.
- Do not bundle the main circuit cable and the encoder cable together. Keep the main circuit cable and I/O signal cable separated at least 30 cm away from each other.
Placing these cables too close to each other may result in malfunction.
- The maximum wiring length is 3 m for I/O signal cables, 20 m for encoder cables or motor main circuit cables, and 10 m for control power supply cables (+24 V, 0 V).
- Take appropriate and sufficient countermeasures for each when installing systems in the following locations.
 - Locations subject to static electricity or other forms of noise.
 - Locations subject to strong electromagnetic fields and magnetic fields.
 - Locations subject to possible exposure to radioactivity.
 - Locations close to power supplies.Failure to observe this caution may result in damage to the product.
- Wiring or inspection must be performed by a technical expert.
- Do not connect a commercial power supply to the U, V, or W motor connection terminals.
Failure to observe this caution may result in injury or fire.
- Do not connect the spindle motor directly to an industrial power supply.
Failure to observe this caution may damage the spindle motor. Connect the spindle motor to the dedicated SERVOPACK.
- Securely connect the power supply terminal screws and motor connection terminal screws.
Failure to observe this caution may result in fire.
- Do not touch power terminals before the main-circuit capacitor has had time to discharge after the power has been turned OFF. Refer to 5.2.1 *Main Circuit Power Supply* for the details of discharge time of main-circuit capacitor.
Residual voltage may cause electric shock.
- Do not touch terminals while the charge indicator is lit. First make sure the charge indicator is turned OFF and that the DC-bus (symbol: P and N) voltage value is correct by using a tester or other device before wiring or starting an inspection.
Residual voltage may cause electric shock.
- Observe the following precautions when wiring main circuit terminal blocks.
 - Do not turn the servo drive power ON until all wiring, including the main circuit terminal blocks has been completed.
 - If the main circuit terminal is the connector, remove the connector from the SERVOPACK before wiring.
 - Insert only one wire per insertion slot on the terminal block and the connector.
 - Make sure that the core wire is not electrically shorted to adjacent core wires.
- Always use the specified power supply voltage.
An incorrect voltage may result in fire.
- Make sure that the polarity (P (+), N (-)) is correct.
Incorrect polarity may cause ruptures or damage.
- Take appropriate measures to ensure that the input power supply is supplied within the specified voltage fluctuation range. Be particularly careful in places where the power supply is unstable.
An incorrect power supply may result in damage to the product.
- Install external breakers or other safety devices against short-circuiting in external wiring.
Failure to observe this caution may result in fire.
- For the control power supply, use a 24-VDC power supply with double insulation or reinforced insulation against primary. Make sure that the output holding time is 100 ms or more.
- Use twisted-pair shielded wires or multi-core twisted pair shielded wires for I/O signal cables and the encoder cables.
- Always connect the power regeneration converter to the left side of the SERVOPACK. You cannot connect it to the right side of the SERVOPACK due to the product structure.
Connections made through product modifications may cause equipment damage, fire, or injury.

■ Operation

CAUTION

- Always use the spindle motor and SERVOPACK in one of the specified combinations.
Failure to observe this caution may result in fire or malfunction.
- Conduct trial operation on the spindle motor alone with the motor shaft disconnected from machine to avoid any unexpected accidents.
Failure to observe this caution may result in injury.
- Secure system safety against problems such as signal line disconnection.
Failure to observe this caution may result in damage to the product or injury.
- Before starting operation with a machine connected, change the settings to match the parameters of the machine.
Starting operation without matching the proper settings may cause the machine to run out of control or malfunction.
- Avoid frequently turning the power ON and OFF.
Since the Σ -V-SD driver have a capacitor in the power supply, a high charging current flows when power is turned ON. Frequently turning the power ON and OFF causes main power devices like capacitors and fuses in the power regeneration converter and the SERVOPACK to deteriorate more quickly, resulting in unexpected problems.
- Before you supply power to the motor, use the SigmaWin+ to confirm that the motor model set in the SERVOPACK matches the spindle motor that you are using.
Failure to observe this caution may result in injury, fire, and damage to the product.
- Do not touch the power regeneration converter and SERVOPACK heat sinks or spindle motor while the power is ON or soon after the power is turned OFF.
Failure to observe this caution may result in burns due to high temperatures.
- Do not make any extreme adjustments or setting changes of parameters.
Failure to observe this caution may result in injury or damage to the product.
- When an alarm occurs, remove the cause, clear the alarm after confirming safety, and then resume operation.
Failure to observe this caution may result in damage to the product, fire, or injury.

■ Maintenance and Inspection

CAUTION

- Do not disassemble the power regeneration converter and SERVOPACK.
Failure to observe this caution may result in electric shock or injury.
- Do not attempt to change wiring while the power is ON.
Failure to observe this caution may result in electric shock or injury.
- When replacing the SERVOPACK, resume operation only after transferring the previous SERVOPACK parameters to the new SERVOPACK.
Failure to observe this caution may result in damage to the product.

■ Disposal

CAUTION

- When disposing of the products, treat them as ordinary industrial waste.

■ General Precautions

**Observe the following general precautions
to ensure safe application.**

- The products shown in illustrations in this manual are sometimes shown without covers or protective guards. Always replace the cover or protective guard as specified first, and then operate the products in accordance with the manual.
- The drawings presented in this manual are typical examples and may not match the product you received.
- Any and all quality guarantees provided by Yaskawa are null and void if the customer modifies the product in any way. Yaskawa disavows any responsibility for damages or losses that are caused by modified products.
- If the manual must be ordered due to loss or damage, inform your nearest Yaskawa representative or one of the offices listed on the back of this manual.

Warranty

(1) Details of Warranty

■ Warranty Period

The warranty period for a product that was purchased (hereinafter called “delivered product”) is one year from the time of delivery to the location specified by the customer or 18 months from the time of shipment from the Yaskawa factory, whichever is sooner.

■ Warranty Scope

Yaskawa shall replace or repair a defective product free of charge if a defect attributable to Yaskawa occurs during the warranty period above. This warranty does not cover defects caused by the delivered product reaching the end of its service life and replacement of parts that require replacement or that have a limited service life.

This warranty does not cover failures that result from any of the following causes.

1. Improper handling, abuse, or use in unsuitable conditions or in environments not described in product catalogs or manuals, or in any separately agreed-upon specifications
2. Causes not attributable to the delivered product itself
3. Modifications or repairs not performed by Yaskawa
4. Abuse of the delivered product in a manner in which it was not originally intended
5. Causes that were not foreseeable with the scientific and technological understanding at the time of shipment from Yaskawa
6. Events for which Yaskawa is not responsible, such as natural or human-made disasters

(2) Limitations of Liability

1. Yaskawa shall in no event be responsible for any damage or loss of opportunity to the customer that arises due to failure of the delivered product.
2. Yaskawa shall not be responsible for any programs (including parameter settings) or the results of program execution of the programs provided by the user or by a third party for use with programmable Yaskawa products.
3. The information described in product catalogs or manuals is provided for the purpose of the customer purchasing the appropriate product for the intended application. The use thereof does not guarantee that there are no infringements of intellectual property rights or other proprietary rights of Yaskawa or third parties, nor does it construe a license.
4. Yaskawa shall not be responsible for any damage arising from infringements of intellectual property rights or other proprietary rights of third parties as a result of using the information described in catalogs or manuals.

(3) Suitability for Use

1. It is the customer's responsibility to confirm conformity with any standards, codes, or regulations that apply if the Yaskawa product is used in combination with any other products.
2. The customer must confirm that the Yaskawa product is suitable for the systems, machines, and equipment used by the customer.
3. Consult with Yaskawa to determine whether use in the following applications is acceptable. If use in the application is acceptable, use the product with extra allowance in ratings and specifications, and provide safety measures to minimize hazards in the event of failure.
 - Outdoor use, use involving potential chemical contamination or electrical interference, or use in conditions or environments not described in product catalogs or manuals
 - Nuclear energy control systems, combustion systems, railroad systems, aviation systems, vehicle systems, medical equipment, amusement machines, and installations subject to separate industry or government regulations
 - Systems, machines, and equipment that may present a risk to life or property
 - Systems that require a high degree of reliability, such as systems that supply gas, water, or electricity, or systems that operate continuously 24 hours a day
 - Other systems that require a similar high degree of safety
4. Never use the product for an application involving serious risk to life or property without first ensuring that the system is designed to secure the required level of safety with risk warnings and redundancy, and that the Yaskawa product is properly rated and installed.
5. The circuit examples and other application examples described in product catalogs and manuals are for reference. Check the functionality and safety of the actual devices and equipment to be used before using the product.
6. Read and understand all use prohibitions and precautions, and operate the Yaskawa product correctly to prevent accidental harm to third parties.

(4) Specifications Change

The names, specifications, appearance, and accessories of products in product catalogs and manuals may be changed at any time based on improvements and other reasons. The next editions of the revised catalogs or manuals will be published with updated code numbers. Consult with your Yaskawa representative to confirm the actual specifications before purchasing a product.

Contents

About this Manual	iii
Safety Precautions	vi
Warranty	xii
1 Outline	1-1
1.1 System Configurations	1-2
1.1.1 Standard (Orientation Control with a Motor Encoder)	1-2
1.1.2 Orientation Control with an External Encoder	1-3
1.1.3 Orientation Control with a Magnetic Sensor	1-4
1.2 Model Designation	1-5
1.2.1 Spindle Motor	1-5
1.2.2 Σ -V-SD Series Driver	1-6
2 Compatible Devices	2-1
2.1 Combinations	2-2
2.1.1 SERVOPACK and Spindle Motor	2-2
2.1.2 Power Regeneration Converter and SERVOPACK	2-2
2.2 Selecting Cables	2-3
2.2.1 Spindle Motor	2-3
2.2.2 Σ -V-SD Driver	2-5
2.3 Peripheral Devices	2-10
2.3.1 Molded-case Circuit Breakers, Ground Fault Detectors, and Magnetic Contactors	2-10
2.3.2 Surge Absorbers	2-11
2.3.3 AC Reactor	2-11
2.3.4 Magnetic Contactor for Winding Selection	2-12
2.3.5 Noise Filter	2-12
2.3.6 Base Mounting Units	2-13
3 Specifications and External Dimensions	3-1
3.1 Spindle Motor	3-2
3.2 Σ -V-SD Driver	3-17
3.2.1 Power Regeneration Converter	3-17
3.2.2 SERVOPACK	3-22
3.3 Peripheral Devices	3-31
3.3.1 AC Reactor	3-31
3.3.2 Magnetic Contactor for Winding Selection	3-37
3.3.3 Noise Filter	3-40
3.3.4 Base Mounting Units	3-43
4 Installation	4-1
4.1 Spindle Motors	4-2
4.1.1 Installation Environment	4-2
4.1.2 Enclosure	4-2
4.1.3 Installation Orientation	4-3
4.1.4 Coupling Motor and Machinery	4-3

4.2 Σ -V-SD Driver	4-5
4.2.1 Installation Requirements	4-5
4.2.2 Thermal Design of Control Panel	4-6
4.2.3 Control Panel Dust-proof Design	4-9
4.2.4 Installation Precautions	4-10
4.2.5 Installation Orientation and Space	4-11

5 Wiring 5-1

5.1 Spindle Motors	5-2
5.1.1 Precautions on Wiring	5-2
5.1.2 Wirings for Spindle Motors	5-3
5.2 Σ -V-SD Driver	5-7
5.2.1 Main Circuit Power Supply	5-7
5.2.2 Control Circuit Power Supply	5-13
5.2.3 DC-bus	5-15
5.2.4 Local Bus	5-16
5.2.5 I/O Signals	5-17

6 Control Signals 6-1

6.1 Sequence Input Signals	6-2
6.1.1 Sequence Input Signals	6-2
6.1.2 Status Display of Sequence Input Signals	6-3
6.1.3 Details on Sequence Input Signals	6-5
6.2 Analog Speed Reference	6-19
6.3 12-bit Digital Speed Reference	6-22
6.4 Sequence Output Signals	6-26
6.4.1 Sequence Output Signals	6-26
6.4.2 Status Display of Sequence Output Signals	6-27
6.4.3 Details on Sequence Output Signals	6-28
6.5 Speed Meter Signal Output (SM)	6-40
6.6 Load Ratio Meter Signal Output	6-41
6.7 Encoder Pulse Input Circuit	6-42
6.8 Encoder Pulse Output Circuit	6-43

7 Winding Selection Control 7-1

7.1 Features of the Winding Selection Wide Constant Power Drive	7-2
7.2 Connection Diagram	7-3
7.3 Spindle Motor Characteristics	7-4
7.4 Winding Selection Operation	7-5
7.5 Winding Selection Methods	7-6
7.5.1 M Code Winding Selection Method	7-6
7.5.2 Automatic Winding Selection Methods	7-8
7.6 Winding Selection Control Precautions	7-11

8 Orientation Control with a Motor Encoder 8-1

8.1 Overview	8-2
8.2 Connection Diagram	8-3
8.3 Stop Position Reference Signals	8-4
8.3.1 Connecting the Stop Position Reference Signals	8-4
8.3.2 Status Indications of the Stop Position Reference Signals	8-4
8.3.3 Stop Position Reference Signal Details	8-4

8.4 Orientation Control Details	8-6
8.4.1 Orientation Signal (/ORT)	8-6
8.4.2 Orientation Completed Signal (/ORE)	8-6
8.4.3 Operation of Orientation Control with a Motor Encoder for Absolute Positioning	8-7
8.4.4 Operation of Orientation Control with a Motor Encoder for Incremental Positioning	8-11
8.4.5 Precautions for Orientation Control	8-12
8.5 Related Parameters	8-13
9 Orientation Control with an External Encoder	9-1
9.1 Overview	9-2
9.2 Connection Diagram	9-3
9.3 Orientation Specifications	9-4
9.3.1 Standard Specifications	9-4
9.3.2 External Encoder Specifications	9-4
9.4 External Dimensions	9-5
9.5 External Encoder Connector Pin Arrangement	9-5
9.6 Encoder Attachment and Wiring Precautions	9-6
9.7 Stop Position Reference Signals	9-7
9.7.1 Connecting the Stop Position Reference Signals	9-7
9.7.2 Status Indications of the Stop Position Reference Signals	9-7
9.7.3 Stop Position Reference Signal Details	9-7
9.8 Orientation Control Details	9-9
9.8.1 Orientation Signal (/ORT)	9-9
9.8.2 Orientation Completed Signal (/ORE)	9-9
9.8.3 Operation of Orientation Control with an External Encoder for Absolute Positioning	9-10
9.8.4 Operation of Orientation Control with an External Encoder for Incremental Positioning	9-14
9.8.5 Precautions for Orientation Control	9-15
9.9 Related Parameters	9-16
9.10 Adjustment Procedure for Orientation Control Mode with an External Encoder	9-19
10 Orientation Control with a Magnetic Sensor	10-1
10.1 Overview	10-2
10.2 Connection Diagram	10-3
10.3 Orientation Specifications	10-4
10.3.1 Standard Specifications	10-4
10.3.2 Magnet Specifications	10-4
10.3.3 Magnetic Sensor Specifications	10-5
10.4 External Dimensions	10-6
10.4.1 Magnet	10-6
10.4.2 Magnetic Sensor	10-7
10.5 Connections between Devices	10-8
10.5.1 Magnetic Sensor Signal	10-8
10.5.2 Stop Position Reference	10-8
10.6 Control Signal Connector Pin Arrangements	10-9
10.7 Mounting the Magnet and Magnetic Sensor	10-10
10.8 Mounting Precautions	10-11
10.9 Stop Position Reference Signals	10-13
10.9.1 Status Indications of the Stop Position Reference Signals	10-13
10.9.2 Stop Position Reference Signal Details	10-13

10.10	Orientation Control Details	10-15
10.10.1	Orientation Signal (/ORT)	10-15
10.10.2	Orientation Completed Signal (/ORE)	10-16
10.10.3	Feedback Speed Selection	10-16
10.10.4	Operation of Orientation Control with a Magnetic Sensor for Preset Position Stopping Control	10-16
10.10.5	Operation of Orientation Control with a Magnetic Sensor for Incremental Positioning	10-19
10.10.6	Precautions for Orientation Control	10-20
10.11	Related Parameters	10-21
10.12	Adjustment Procedure for Orientation Control Mode with a Magnetic Sensor	10-24

11 Operation 11-1

11.1	Panel Display	11-2
11.1.1	Status Display	11-2
11.1.2	Alarm and Warning Display	11-2
11.1.3	Hard Wire Base Block Display	11-2
11.1.4	RDY and ALM LEDs	11-2
11.2	Basic Functions Settings	11-3
11.2.1	Spindle Motor Settings	11-3
11.2.2	Spindle Motor Rotation Direction	11-7
11.2.3	Stopping Spindle Motor after SV_OFF Command or Alarm Occurrence	11-7
11.2.4	Instantaneous Power Interruption Settings	11-9
11.2.5	Setting Motor Overload Detection Level	11-10
11.2.6	Limiting Torque	11-12
11.3	Trial Operation	11-13
11.3.1	Preparations for Trial Operation	11-13
11.3.2	Trial Operation Example	11-15
11.4	Hard Wire Base Block (HWBB) Function	11-16
11.4.1	Precautions for the Hard Wire Base Block (HWBB) State	11-16
11.4.2	Hard Wire Base Block (HWBB) State	11-17
11.4.3	Resetting the HWBB State	11-18
11.4.4	Error Detection in HWBB Signal	11-18
11.4.5	Connection Example and Specifications of Input Signals (HWBB Signals)	11-19
11.4.6	Operation with SigmaWin+	11-20
11.4.7	External Device Monitor (EDM)	11-20
11.4.8	Application Example of HWBB Function	11-21
11.4.9	Confirming HWBB Function	11-22
11.4.10	Attaching the HWBB Jumper Connector	11-22

12 Adjustments 12-1

12.1	Adjustments	12-2
12.2	Monitoring Analog Signals	12-3
12.2.1	CN6 Connector for Analog Monitor	12-3
12.2.2	Monitor Signal	12-3
12.2.3	Setting Monitor Factor	12-4
12.2.4	Related Parameters	12-5
12.3	Anti-Resonance Control Adjustment Function	12-6
12.3.1	Anti-Resonance Control Adjustment Function	12-6
12.3.2	Related Parameters	12-16

13 Digital Operator	13-1
13.1 Overview	13-2
13.1.1 Part Names and Functions	13-3
13.1.2 Switching Mode	13-5
13.2 Parameter Mode	13-6
13.2.1 Parameter Setting	13-6
13.3 Monitor Mode (Un□□□)	13-9
13.3.1 Monitor Items	13-9
13.3.2 Monitor Mode Display	13-13
13.4 Utility Functions (Fn□□□)	13-14
13.4.1 Utility Functions List	13-14
13.4.2 Operations	13-16
13.4.3 Alarm History Display (Fn000)	13-17
13.4.4 JOG Operation (Fn002)	13-18
13.4.5 Origin Search (Fn003)	13-20
13.4.6 Program JOG Operation (Fn004)	13-22
13.4.7 Initializing Parameter Settings (Fn005)	13-26
13.4.8 Clearing Alarm History (Fn006)	13-27
13.4.9 Automatic Tuning of Analog Speed Reference Offset (Fn009)	13-28
13.4.10 Manual Servo-tuning of Speed Reference Offset (Fn00A)	13-29
13.4.11 Offset Adjustment of Analog Monitor Output (Fn00C)	13-30
13.4.12 Gain Adjustment of Analog Monitor Output (Fn00D)	13-31
13.4.13 Automatic Offset-Signal Adjustment of the Motor Current Detection Signal (Fn00E)	13-32
13.4.14 Manual Offset-Signal Adjustment of the Motor Current Detection Signal (Fn00F)	13-33
13.4.15 Write Prohibited Setting (Fn010)	13-35
13.4.16 Software Version Display (Fn012)	13-37
13.4.17 Display of SERVOPACK and Motor ID (Fn01E)	13-38
13.4.18 Turnup Function (Fn024)	13-39
13.4.19 Load Ratio Meter Output Gain Adjustment (Fn025)	13-40
13.4.20 Anti-Resonance Control Adjustment Function (Fn204)	13-42
14 Standards Compliance	14-1
14.1 Harmonized Standards	14-2
14.2 Models That Are Compliant with International Standards	14-3
14.3 Precautions for Complying with European Standards	14-4
14.3.1 EMC Installation Conditions	14-4
14.3.2 Precautions	14-6
14.3.3 Compliance with Low Voltage Directive	14-7
14.4 Precautions for Complying with UL Standards	14-8
15 Inspection, Maintenance, and Troubleshooting	15-1
15.1 Inspection and Maintenance	15-2
15.1.1 Spindle Motor	15-2
15.1.2 Σ -V-SD Driver	15-3
15.2 Troubleshooting	15-4
15.2.1 List of Alarms	15-4
15.2.2 Troubleshooting of Alarms	15-10
15.3 Warning Displays	15-29
15.3.1 List of Warnings	15-29
15.3.2 Troubleshooting of Warnings	15-30
15.4 Troubleshooting Malfunction Based on Operation and Conditions of the Spindle Motor	15-33

16 Appendix	16-1
16.1 Operation Modes and Applicable Parameters	16-2
16.2 List of Parameters	16-3
16.3 Parameter Recording Table	16-18
16.4 Determining Drive Capacity	16-23
16.4.1 Load Drive Capacity	16-23
16.4.2 Acceleration/deceleration Capacity	16-27
16.4.3 Calculating Start and Stop Times	16-29
16.4.4 Intermittent Load Operating Capacity	16-30


Revision History

Outline

1.1 System Configurations	1-2
1.1.1 Standard (Orientation Control with a Motor Encoder)	1-2
1.1.2 Orientation Control with an External Encoder	1-3
1.1.3 Orientation Control with a Magnetic Sensor	1-4
1.2 Model Designation	1-5
1.2.1 Spindle Motor	1-5
1.2.2 Σ -V-SD Series Driver	1-6


1.1 System Configurations

1.1.1 Standard (Orientation Control with a Motor Encoder)



1.1.2 Orientation Control with an External Encoder


Power supply
Three-phase 200/400 VAC



Outline

1

1.1.3 Orientation Control with a Magnetic Sensor



1.2 Model Designation

1.2.1 Spindle Motor

Number of Digits: 1 2 3 4 5 6 7 8 9 10 11 12 13 14

U A K A J - 2 2 C Z 1 O O E

1st + 2nd digits:
Motor Type

Code	Specifications
UA	AC Spindle Motor

3th digit: Cooling Method

Code	Specifications
K	External fan cooled

4th digit: Winding System

Code	Specifications
A	Single winding
B	Winding selection

5th digit: Series

Code	Specifications
J	Σ -V-SD Series

7th + 8th digits:
50% ED Rating (S3)

Code	Specifications (kW)
04*1	3.7
06	5.5
08	7.5
11	11
15	15
19	18.5
22	22
30*2	30
37*1, *2	37
45*1, *2	45

*1. Available only for single winding models.

*2. Available only for three-phase 200 VAC models.

9th digit:
Design Revision Order

Code	Specifications
C	Standard

10th digit: Encoder Specifications

Code	Specifications
Z	Pulse encoder

11th digit: Mounting

Code	Specifications
1	Flange type
3	Foot-mounted type

12th digit: Shaft End

Code	Specifications
O	Straight with key and tap
Blank	
N	Straight without key and tap

13th digit: Lead Wire Orientation

Code	Specifications
O	Left when viewed from the load side
Blank	

14th digit: Input Voltage

Code	Specifications
Blank	Three-phase 200 VAC
E	Three-phase 400 VAC

1.2.2 Σ-V-SD Series Driver

(1) Power Regeneration Converter

Number of Digits: 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19
C A C P - J U 2 2 A 3 □ □ □ □ □ □ □ □

1st + 2nd + 3rd + 4th + 5th + 6th + 7th digits: Series

Code	Specifications
CACP-JU	Σ-V-SD Series Power Regeneration Converter

8th + 9th digits: 50% ED Rating

Code	Specifications (kW)
15	15
19	18.5
22	22
37*1	37
45*1	45

10th digit: Input Voltage

Code	Specifications
A	Three-phase 200 VAC
D	Three-phase 400 VAC

11th digit: Regeneration Method

Code	Specifications
3	120-degree conduction

12th digit: Design Revision Order*2
 A, B, C . . .

13th digit: Mounting

Code	Specifications
Blank	Duct-ventilated
B*3	Base-mounted

14th to 19th digits:
 Custom Specification*4

Code	Specifications
Blank	Standard

- *1. Available only for three-phase 200 VAC models.
- *2. Compliance with UL standards starts with design revision order B. For details, refer to 14.2 *Models That Are Compliant with International Standards*.
- *3. Available only for CACP-JU□□A3BB model.
- *4. For details about custom-made converters, contact your Yaskawa representative.

(2) SERVOPACK

Number
of Digits:

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20

C A C R - J U 1 0 2 A E A □ □ □ □ □ □ □ □

1st + 2nd + 3rd + 4th + 5th +
6th + 7th digits: Series

Code	Specifications
CACR-JU	Σ-V-SD Series SERVOPACK

8th + 9th + 10th digits:
Rated Output Current

Code	Specifications (Arms)	Input Voltage
028	28	270 VDC
036	36	
065	65	
084	84	
102	102	
125	125	
196	196	540 VDC
014	14	
018	18	
033	32.5	
042	42	
051	51	

11th digit: Input Voltage

Code	Specifications
A	270 VDC
D	540 VDC

12th digit: Interface Specifications

Code	Specifications
E	Analog speed reference expanded functions

13th digit: Design Revision Order
A, B, C . . .

14th digit: Mounting

Code	Specifications
Blank	Duct-ventilated
B*1	Base-mounted

15th to 20th digits:
Custom Specification*2

Code	Specifications
Blank	Standard
01*3	Orientation control with an external encoder
02*3	Orientation control with a magnetic sensor

- *1. Available only for CACR-JU□□□AEAB model.
 *2. For details about custom-made converters, contact your Yaskawa representative.
 *3. There is no code for 17th digit to 20th digit.

Compatible Devices

2.1	Combinations	2-2
2.1.1	SERVOPACK and Spindle Motor	2-2
2.1.2	Power Regeneration Converter and SERVOPACK	2-2
2.2	Selecting Cables	2-3
2.2.1	Spindle Motor	2-3
2.2.2	Σ -V-SD Driver	2-5
2.3	Peripheral Devices	2-10
2.3.1	Molded-case Circuit Breakers, Ground Fault Detectors, and Magnetic Contactors	2-10
2.3.2	Surge Absorbers	2-11
2.3.3	AC Reactor	2-11
2.3.4	Magnetic Contactor for Winding Selection	2-12
2.3.5	Noise Filter	2-12
2.3.6	Base Mounting Units	2-13

2.1 Combinations

2.1.1 SERVOPACK and Spindle Motor

Model	Input Voltage	Spindle Motor	
		UAKAJ-	UAKBJ-
		Single Winding	Winding Selection
CACR-JU028AEA	270 VDC	04, 06	06
CACR-JU036AEA		08	08
CACR-JU065AEA		11, 15	11, 15
CACR-JU084AEA		19	19
CACR-JU102AEA		22	22
CACR-JU125AEA		30	30
CACR-JU196AEA		37, 45	–
CACR-JU014DEA	540 VDC	04, 06	06
CACR-JU018DEA		08	08
CACR-JU033DEA		11, 15	11, 15
CACR-JU042DEA		19	19
CACR-JU051DEA		22	22


2.1.2 Power Regeneration Converter and SERVOPACK

Select a power regeneration converter that has a continuous output capacity that is the same or higher than the continuous rated capacity of the SERVOPACK.

Power Regeneration Converter Model	Continuous Output Capacity (kW)	SERVOPACK Model	Continuous Rated Capacity (kW)
CACP-JU15A3□	11	CACR-JU028AEA	3.7
		CACR-JU036AEA	5.5
		CACR-JU065AEA	11
CACP-JU19A3□	15	CACR-JU084AEA	15
CACP-JU22A3□	18.5	CACR-JU102AEA	18.5
CACP-JU30A3□	22	CACR-JU125AEA	22
CACP-JU45A3B	37	CACR-JU196AEA	37
CACP-JU15D3□	11	CACR-JU014DEA	3.7
		CACR-JU018DEA	5.5
		CACR-JU033DEA	11
CACP-JU19D3□	15	CACR-JU042DEA	15
CACP-JU22D3□	18.5	CACR-JU051DEA	18.5

2.2 Selecting Cables

2.2.1 Spindle Motor



(1) Main Circuit Cable

The main circuit cable for the spindle motor must be assembled by customers. The main circuit cable for the spindle motor consists of the following two parts.

- Cable-end connectors to SERVOPACKs
- Cable

Note: All models of spindle motors have screw terminals for the connection of main-circuit cables. For details, refer to 5.1.2 (1) *Main Circuit Cable Wiring*.

Use the following information on specifications to select appropriate parts.

■ Specifications for Cable-end Connectors to SERVOPACKs


SERVOPACK Model	Connector Housing Model	Electrical Contact Model	Wire Size	Manufacturer
CACR-JU028AEA	1-917807-2	1318697-6	AWG8	Tyco Electronics Japan G.K.
CACR-JU036AEA	DK-5200S-04R	DK-5RECLLP1 (D3)	AWG8	DDK Ltd.
CACR-JU014DEA	1-917807-2	316041-6	AWG12	Tyco Electronics Japan G.K.
CACR-JU018DEA	DK-5200S-04R	DK-5RECMLP1-100	AWG10	DDK Ltd.

Note: For other SERVOPACKs, they have screw terminals. For details, refer to 5.2.1 (1) *Wire Sizes and Tightening Torques*.

■ Cables

A 600 V heat-resistant vinyl cable is recommended. Select an appropriate size of cable for the spindle motor and the SERVOPACK used. For details, refer to 5.1.2 (1) *Main Circuit Cable Wiring* and 5.2.1 (1) *Wire Sizes and Tightening Torques*.

(2) Pulse Encoder Cable

Name	Length	Order No.	External Appearance
Pulse Encoder Cable for Spindle Motor	2 m	JZSP-CJP00-02-E	
	3 m	JZSP-CJP00-03-E	
	5 m	JZSP-CJP00-05-E	
	10 m	JZSP-CJP00-10-E	
	15 m	JZSP-CJP00-15-E	
	20 m	JZSP-CJP00-20-E	

Use the following information to select appropriate parts when assembling a pulse encoder cable.

■ Specifications for Cable-end Connectors to SERVOPACKS

Name	Model	Manufacturer
Shell	54331-0201	Molex Japan Co., Ltd.
Plug	54306-2019	

Note: This cable-end connector is equivalent to the shell (10320-52A0-008) and the plug (10120-3000PE) made by Sumitomo 3M Ltd.


■ Specifications for Cable-end Connectors to Spindle Motors

The cable-end connector to the spindle motor is stored in the motor's terminal box upon delivery.

Name	Model	Manufacturer	
Connector	ELP-12V	J.T.S Mfg. Co., Ltd.	
Electrical Contact	Other pins		LLF-01T-P1.3E*
	No.10 pin		LLF-41T-P1.3E*










* The YC-202 crimping tool is required. Contact J.T.S. Mfg. Co., Ltd. for more information.

■ Cable Specifications





Items	Standard Type
Order No.	B9400064-1-E (3 m)
	B9400064-2-E (5 m)
	B9400064-3-E (10 m)
	B9400064-4-E (15 m)
	B9400064-5-E (20 m)
General Specifications	KQVV-SW: AWG22 × 3 (three colors) AWG26 × 4 (four twisted-pair)
Finished Dimensions	7.5 mm dia.
Internal Configuration and Lead Color	 <p>A1: Red A2: Black A3: Yellow green F1: Blue and white - twisted-pair wire F2: Yellow and white - twisted pair wire F3: Green and white - twisted pair wire F4: Orange and white - twisted pair wire</p>
Available Cable Lengths (Yaskawa Standards)	3 m, 5 m, 10 m, 15 m, 20 m

2.2.2 Σ -V-SD Driver

(1) Cables for Σ -V-SD Drivers

Name	Length	Order No.	External Appearance	Reference
Cable for 24-volt control power supply <ul style="list-style-type: none"> • With loose leads on one end • Connects one Σ-V-SD driver to 24-volt control power supply 	1 m	JZSP-CNG00-01-E		2.2.2 (2)
	2 m	JZSP-CNG00-02-E		
	3 m	JZSP-CNG00-03-E		
Cable for 24-volt control power supply <ul style="list-style-type: none"> • With connectors on both ends • Connects two Σ-V-SD drivers 	0.2 m	JZSP-CNG01-A2-E		2.2.2 (3)
	0.3 m	JZSP-CNG01-A3-E		
Cables for local bus communications	0.5 m	JUPIT-W6004-A5		2.2.2 (4)
Cable for converter I/O	1 m	JZSP-CJI01-1-E		2.2.2 (5)
	2 m	JZSP-CJI01-2-E		
	3 m	JZSP-CJI01-3-E		
Cable for SERVOPACK CN1 I/O	1 m	JZSP-CJI103-1-E		2.2.2 (6)
	2 m	JZSP-CJI103-2-E		
	3 m	JZSP-CJI103-3-E		
Cable for SERVOPACK CN2 I/O	1 m	JZSP-CJI203-1-E		2.2.2 (6)
	2 m	JZSP-CJI203-2-E		
	3 m	JZSP-CJI203-3-E		
Cable for external encoder (with connectors on both ends)	3 m	JZSP-CJPS00-03-E		2.2.2 (6)
	5 m	JZSP-CJPS00-05-E		
	10 m	JZSP-CJPS00-10-E		
	15 m	JZSP-CJPS00-15-E		
Cable for external encoder (with loose leads on one end)	3 m	JZSP-CJPS03-03-E		2.2.2 (6)
	5 m	JZSP-CJPS03-05-E		
	10 m	JZSP-CJPS03-10-E		
	15 m	JZSP-CJPS03-15-E		
Cable for external pulse encoder output	1 m	JZSP-CJPE03-1-E		2.2.2 (6)
	2 m	JZSP-CJPE03-2-E		
	3 m	JZSP-CJPE03-3-E		

(cont'd)

Name	Length	Order No.	External Appearance	Reference
Cable for magnetic sensor *1	3 m	JZSP-CJMS03-03-E		2.2.2 (6)
	5 m	JZSP-CJMS03-05-E		
	10 m	JZSP-CJMS03-10-E		
	15 m	JZSP-CJMS03-15-E		
	20 m	JZSP-CJMS03-20-E		
HWBB cable	1 m	JZSP-CVH03-01-E		2.2.2 (7)
	3 m	JZSP-CVH03-03-E		
Cable for analog monitor *2	1 m	JZSP-CA01-E		2.2.2 (8)
Cable for personal computer connection	2.5 m	JZSP-CVS06-02-E		2.2.2 (9)

*1. The cable connector for the FS-1378C magnetic sensor end of the cable is provided with the FS-1378C magnetic sensor.

*2. Required for maintenance work.

(2) Cable Specifications for 24-V Control Power Supply (With loose leads at one end and connects a Σ -V-SD driver to a 24-V control power supply)

Items	Specifications
Order No. *	JZSP-CNG00-□□-E
Cable Length	1 m, 2 m, 3 m
Cable and Connector	Cable : UL1015 AWG14 Cable-end connector to driver : 175362-1 (PIN : 353717-2) Connector manufacturer : Tyco Electronics Japan G.K.

* Specify the cable length in □□ of the order number.

Example: JZSP-CNG00-01-E (1 m)

(3) Cable Specifications for 24-volt Control Power Supply (With connectors on both ends and connects two Σ -V-SD drivers)

Items	Specifications	
Order No.	JZSP-CNG01-A2-E	JZSP-CNG01-A3-E
Cable Length*	0.2 m	0.3 m
Cable and Connector	Cable : UL1015 AWG14 Connector : 175362-1 (PIN : 353717-2) Connector manufacturer : Tyco Electronics Japan G.K.	

* When using CACP-JU45A3B converter, use 0.3 m-cable.

(4) Cable Specifications for Local Bus Communications

Items	Specifications
Order No.	JUPIT-W6004-A5
Cable Length	0.5 m
Cable	HRZFFVV-ESB (20276)
Remarks	Used for communication between the Converter and the SERVOPACK.

(5) Cable Specifications for Converter I/O Signals

Items	Specifications
Order No. *	JZSP-CJI01-□-E
Cable Length	1 m, 2 m, 3 m
Cable and Connector	Cable : HP-SB/20276SR AWG28 × 7P Cable-end connector : 10114-6000EL (Crimping type)
Remarks	Used for emergency stop.

* Specify the cable length in □ of the order number.
Example: JZSP-CJI01-1-E (1 m)

(6) I/O Cable Specifications for SERVOPACKS

If you make your own I/O cables, refer to the following specifications to select suitable materials.

■ CN1

Items	Specifications
Cable and Connector	Cable : AWG24 to ANG26 × 25P (shielded) Shell : 10350-52A0-008 (Sumitomo 3M Ltd.) Plug : 10150-3000PE (soldered type, Sumitomo 3M Ltd.)*1 Connector kit : JZSP-CSI9-1-E*2
Remarks	Used for I/O signals

*1. The crimping type is 10150-6000EL (Sumitomo 3M Ltd.).

*2. This product consists of a plug and a shell (unshielded, Yaskawa Controls Co. Ltd.).

■ CN2

Items	Specifications
Cable and Connector	Cable : AWG24 to AWG30 × 18P (shielded) Shell : 10336-52A0-008 (Sumitomo 3M Ltd.) Plug : 10136-3000PE (soldered type, Sumitomo 3M Ltd.)*1 Connector kit : JZSP-VAI09-E*2
Remarks	Used for I/O signals

*1. The crimping type is 10150-6000EL (Sumitomo 3M Ltd.).

*2. This product consists of a plug and a shell (plated, Yaskawa Controls Co. Ltd.).

■ CN9

Items	Specifications
Cable and Connector	Cable : AWG24 to AWG30 × 10P (shielded) Shell : 10320-52A0-008 (Sumitomo 3M Ltd.) Plug : 10120-3000PE (soldered type, Sumitomo 3M Ltd.)* ¹ Connector kit : JZSP-VEP02-E* ²
Remarks	Used for I/O signals

*1. The crimping type is 10120-6000EL (Sumitomo 3M Ltd.).

*2. This product consists of a plug and a shell (plated, Yaskawa Controls Co. Ltd.).

■ CN10

Items	Specifications
Cable and Connector	Cable : AWG24 to AWG30 × 7P (shielded) Shell : 10314-52A0-008 (Sumitomo 3M Ltd.) Plug : 10114-3000PE (soldered type, Sumitomo 3M Ltd.)* ¹ Connector kit : JZSP-CHI9-1* ²
Remarks	Used for output signals of load shaft encoder

*1. The crimping type is 10114-6000EL (Sumitomo 3M Ltd.).

*2. This product consists of a plug and a shell (unshielded, Yaskawa Controls Co. Ltd.).

(7) Cable Specifications for HWBB

Items	Specifications
Order No.*	JZSP-CVH03-0□-E
Cable Length	1 m, 3 m
Cable and Connector	Cable : 2A-SB LF AWG26 × 3P Connector kit : 2013595-1 (Tyco Electronics Japan G.K.)
Remarks	Used for HWBB

* Specify the cable length in □ of the order number.

Example: JZSP-CVH03-01-E (1 m)

(8) Cable Specifications for Use with an Analog Monitor

Items	Specifications
Order No.	JZSP-CA01-E
Cable length	1 m
Connectors	Cable : STYLE 1007 AWM E74037 AWG24 VW-1 Connector : DF11-4DS-2C
Remarks	Used for analog output signals, such as speed reference and torque reference.

(9) Cable Specifications for Use with a Computer

Items	Specifications
Order No.	JZSP-CVS06-02-E
Cable length	2.5 m
Connectors	Cable-end connector to SERVOPACK : USB Type miniB Cable-end connector to computer : USB Type A
Remarks	Used to connect a SERVOPACK with a personal computer in which SigmaWin+ is installed.

2.3 Peripheral Devices

2.3.1 Molded-case Circuit Breakers, Ground Fault Detectors, and Magnetic Contactors

Always install a circuit breaker to protect the main circuits. The type of circuit breaker that is required depends on what you need to detect.

Detecting only overcurrent: Use a molded-case circuit breaker.

Detecting overcurrent and leakage current: Use a ground fault detector that detects overloads and leakage current. Or, use a molded-case circuit breaker together with a ground fault detector that detects only leakage current.



WARNING

- Always install a molded-case circuit breaker or ground fault detector in the main circuit. Failure to observe this warning may result in electric shock, equipment damage, or fire.

(1) Molded-case Circuit Breaker

A molded-case circuit breaker shuts OFF the power supply when it detects an overcurrent. Install a molded-case circuit breaker between the power supply and the main circuit power supply input terminals (R/L1, S/L2, and T/L3).

Select the molded-case circuit breaker based on the information of power supply capacity per power regeneration converter, input current (50%ED, continuous ratings), and inrush current in (4) *Converter Input Current and Inrush Current*.

(2) Ground Fault Detector

A ground fault detector detects leakage current. Some models will also detect overcurrent in addition to leakage current. Use the type that is suitable for your application. Install a ground fault detector between the power supply and the main circuit power supply input terminals (R/L1, S/L2, and T/L3).

Recommended ground fault detector: A ground fault detector with harmonic countermeasures and a rated sensed current of 30 mA or higher for each power regeneration converter. A ground fault detector with harmonic countermeasures removes leakage current for harmonics and detects only leakage current in the frequency range that presents a hazard to humans. If you use a ground fault breaker that does not have harmonic countermeasures, the leakage current from the harmonics will increase the chance of malfunctions.

Select the ground fault detector based on the information of power supply capacity per power regeneration converter, input current (50%ED, continuous ratings), and inrush current in (4) *Converter Input Current and Inrush Current*.

(3) Magnetic Contactors

The magnetic contactor for the control circuit power supply turns the control circuit power supply ON and OFF. The magnetic contactor for the main circuit power supply turns the main circuit power supply ON and OFF. Use a magnetic contactor (MC) to turn OFF the control power supply or main circuit power supply sequence.

Note: If the magnetic contactor on the main circuit power supply input is turned ON and OFF frequently, the Σ -V-SD servo driver may be damaged. Do not turn the power supply ON and OFF with the magnetic contactor more than one time every 30 minutes.

Select the magnetic contactor based on the information of power supply capacity per power regeneration converter, input current (50%ED, continuous ratings), and inrush current in (4) *Converter Input Current and Inrush Current*.

(4) Converter Input Current and Inrush Current

Voltage	Capacity (50%ED) kW	Capacity (Continuous Ratings) kW	Power Regeneration Converter Model	Power Supply Capacity per Power Regeneration Converter (kVA)	Input Current (50%ED) Arms	Input Current (Continuous Ratings) Arms	Inrush Current (Main Circuit) A _{0-P}
200 V	15	11	CACP-JU15A3□	22.5	73	54	83
	18.5	15	CACP-JU19A3□	30.5	90	73	83
	22	18.5	CACP-JU22A3□	37.5	107	90	83
	30	22	CACP-JU30A3□	45.0	145	107	178
	37	30	CACP-JU37A3B	61.5	179	145	178
	45	37	CACP-JU45A3B	75.0	218	179	178
400 V	15	11	CACP-JU15D3□	22.5	36	27	173
	18.5	15	CACP-JU19D3□	30.5	45	36	173
	22	18.5	CACP-JU22D3□	37.5	53	45	173

2.3.2 Surge Absorbers

A surge absorber absorbs the energy that is stored in the coil of an inductive load to suppress noise. Always use surge absorbers or diodes on all inductive loads that are connected near the Σ -V-SD servo driver. (Inductive loads include magnetic contactors, magnetic relays, magnetic valves, solenoids, and magnetic brakes.)



IMPORTANT

- Select a surge absorber with a capacity that is sufficient for the coil in the inductive load.
- Always install surge absorbers. If you do not install surge absorbers, the surge voltage from the coil that occurs when the inductive load is turned ON and OFF will affect the SERVOPACK control signal lines and could cause incorrect signals.

2.3.3 AC Reactor

Make sure to install an AC reactor, which corresponds to the capacity of the individual power regeneration converter, to each power regeneration converter.

Do not connect any equipment other than the power regeneration converter to the secondary side of the AC reactor. If this caution is not observed, an overcurrent may occur in the power regeneration converter. An AC reactor is effective in improving the power factor of the power supply side.

Select an AC reactor based on the following table.

Power Regeneration Converter		AC Reactor
Input Voltage	Model	Model
Three-phase 200 VAC	CACP-JU15A3□	X008017
	CACP-JU19A3□	X008018
	CACP-JU22A3□	X008019
	CACP-JU30A3□	X008020
	CACP-JU37A3B	X008029
	CACP-JU45A3B	X008022
Three-phase 400 VAC	CACP-JU15D3□	X008010*
	CACP-JU19D3□	X008011
	CACP-JU22D3□	X008012

* UL standards are not supported. Ask your Yaskawa representative if you require an AC Reactor that supports UL standards.

2.3.4 Magnetic Contactor for Winding Selection

A magnetic contactor for winding selection is needed only if a winding selection motor is used as the spindle motor.

Select a magnetic contactor for winding selection based on the following table.

SERVOPACK		Magnetic Contactor* for Winding Selection	
Input Voltage	Model	Model	
		Standard	For UL Compliance
270 VDC	CACR-JU028AEA	HV-75AP4	HV-75AP4/UL
	CACR-JU036AEA		
	CACR-JU065AEA		
	CACR-JU084AEA	HV-150AP4	HV-150AP4/UL
	CACR-JU102AEA		
	CACR-JU125AEA		
	CACR-JU196AEA	HV-200AP4	HV-200AP4/UL
540 VDC	CACR-JU014DEA	HV-75AP4	HV-75AP4/UL
	CACR-JU018DEA		
	CACR-JU033DEA		
	CACR-JU042DEA	HV-150AP4	HV-150AP4/UL
	CACR-JU051DEA		

* Model numbers for contactors with safety covers are HV-□□AP4S and HV-□□AP4S/UL.

2.3.5 Noise Filter

A noise filter installed on the power supply side eliminates noise leaking from the main circuit power line to the Σ -V-SD driver. The filter also reduces the noise leaking from the Σ -V-SD driver to the main circuit power line.

Use a noise filter designed to suppress harmonic noise. Do not use general-purpose noise filters, because their effectiveness is minimal when used with the Σ -V-SD driver.

Install a noise filter at the input side of the power regeneration converter.

Yaskawa recommends the following noise filters.

Power Regeneration Converter		Noise Filter
Input Voltage	Model	Model
Three-phase 200 VAC	CACP-JU15A3□	HF3060C-SZC-47EDD
	CACP-JU19A3□	HF3080C-SZC-47EDD
	CACP-JU22A3□	HF3100C-SZC-47EDD
	CACP-JU30A3□	HF3150C-SZC-47EDD
	CACP-JU37A3B	
	CACP-JU45A3B	HF3200C-SZC-49EDE*
Three-phase 400 VAC	CACP-JU15D3□	HF3030C-SZC-47EDD
	CACP-JU19D3□	HF3040C-SZC-47EDD
	CACP-JU22D3□	HF3050C-SZC-47EDD

* Also use the following compact AC power supply block-type capacitor (X capacitor).
Compact AC power supply block-type capacitor (X capacitor) model: LDA106M-AA (Soshin Electric Co., Ltd.)

**IMPORTANT**

Some noise filters have large leakage currents. Leakage current is also greatly affected by ground conditions. If you use a ground fault detector, consider the ground conditions and the leakage current of the noise filter when you select one.

Ask the manufacturer of the noise filter for details.

2.3.6 Base Mounting Units

When mounting Servo Drives to bases, mount them together with the following Base Mounting Units.

(1) Power Regeneration Converters

Power Regeneration Converter		Base Mounting Unit
Input Voltage	Model*	Model
Three-phase 200 VAC	CACP-JU15A3□	JUSP-JUBM100AA
	CACP-JU19A3□	
	CACP-JU22A3□	
	CACP-JU30A3□	JUSP-JUBM150AA
	CACP-JU37A3B	
	CACP-JU45A3B	
Three-phase 400 VAC	CACP-JU15D3□	JUSP-JUBM100AA
	CACP-JU19D3□	
	CACP-JU22D3□	

* The box at the end of the model numbers indicates the design order (A, B, C, etc.). Compliance with UL standards starts with design order B.

(2) SERVOPACK

SERVOPACK		Base Mounting Unit
Input Voltage	Model	Model
270 VDC	CACR-JU028AEA	JUSP-JUBM050AA
	CACR-JU036AEA	
	CACR-JU065AEA	JUSP-JUBM075AA
	CACR-JU084AEA	JUSP-JUBM150AA
	CACR-JU102AEA	
	CACR-JU125AEA	
	CACR-JU196AEA	JUSP-JUBM250AA
540 VDC	CACR-JU014DEA	JUSP-JUBM050AA
	CACR-JU018DEA	
	CACR-JU033DEA	JUSP-JUBM075AA
	CACR-JU042DEA	JUSP-JUBM150AA
	CACR-JU051DEA	


Specifications and External Dimensions

3.1 Spindle Motor	3-2
3.2 Σ -V-SD Driver	3-17
3.2.1 Power Regeneration Converter	3-17
3.2.2 SERVOPACK	3-22
3.3 Peripheral Devices	3-31
3.3.1 AC Reactor	3-31
3.3.2 Magnetic Contactor for Winding Selection	3-37
3.3.3 Noise Filter	3-40
3.3.4 Base Mounting Units	3-43

3.1 Spindle Motor


(1) Configuration

The motor configuration is shown in the following diagram.



Motor Configuration


Number	Name	Number	Name
①	Output shaft (Motor shaft)	⑥	Stator winding
②	Bearings	⑦	Terminal box
③	Rotor	⑧	Cable socket
④	Rotor short-circuit ring	⑨	Cooling fan
⑤	Stator	⑩	Encoder



Terminal and Connector Arrangement

Encoder Connector

Number	Terminal	Number	Terminal
1	5 VDC	7	PC
2	0 V	8	/PC
3	PA	9	FG (Frame Ground)
4	/PA	10	SS (Shield)
5	PB	11	TS
6	/PB	12	



Model: ELR-12V
 Manufacturer: J.S.T.Mfg.Co.,Ltd.
 Note: A crimp tool is required.

Motor Connector

(2) Ratings and Specifications

■ Single-winding Motor

Items		Model: UAKAJ-□□C (200 V), -□□C□□□□E (400 V)									
		04	06	08	11	15	19	22	30* ²	37* ²	45* ²
50% ED Rating (S3)* ¹	kW	3.7	5.5	7.5	11	15	18.5	22	30	37	45
Continuous Rating (S1)	kW	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37
Continuous Rated Torque	N·m	14	24	35	48	70	96	118	183	249	307
Base Speed	min ⁻¹	1500							1150		
Maximum Speed	min ⁻¹	10000				7000			6000		5000
Moment of Inertia	× 10 ⁻³ kg·m ²	7.1	14.0	21.0	25.0	69.0	69.0	89.0	231	266	398
Vibration		V5									V10
Noise	dB (A)	75 or less							80 or less		
Cooling Method		Totally enclosed, external fan cooled									
Protection Class		IP44 (IEC34-5)									
Cooling Fan Motor		Equipped with thermostat (automatic reset) 200 V class: Three-phase 200 V 50/60 Hz, 220 V 50/60 Hz, 230 V 60 Hz 400 V class: Three-phase 400 V 50/60 Hz, 440 V 50/60 Hz, 460 V 60 Hz									
Encoder (Magnetic)		Pulse encoder (1024 p/r)									
Overheating Protection		NTC thermistor									
Installation		Flange type: IM B5, IM V1 (motor shaft from horizontal to vertically down) Foot-mounted type: IM B3 (installed on floor)									
Overload Capacity		200% of continuous rated (S1) output for 10 s (UAKAJ-08, -37: 180% of continuous rated (S1) output for 10 s)									
Thermal Class		F									
Withstand Voltage		200 V class: 1500 VAC for one minute 400 V class: 1800 VAC for one minute									
Insulation Resistance		500 V DC 10 MΩ minimum									
Surrounding Air Temperature and Surrounding Air Humidity		0 to 40°C, 20 to 80% RH (no condensation)									
Altitude		1000 m or less									
Bearing Lubrication		Grease									
Paint Color		Munsell N1.5									
Compliant Standards		JIS, JEC									
Applicable SERVOPACK CACR-JU□□□	Three-phase 200 V AC	028A	028A	036A	065A	065A	084A	102A	125A	196A	196A
	Three-phase 400 V AC	014D	014D	018D	033D	033D	042D	051D	-	-	-

*1. The 50% ED rating (S3) is for a 10 minute cycle consisting of 5 minutes of operation and 5 minutes stopped.

*2. Available only for three-phase, 200 VAC models.

■ Winding Selection Motor

Items		Model: UAKBJ-□□C (200 V), -□□C□□□□E (400 V)						
		06	08	11	15	19	22	30 ^{*2}
50% ED Rating (S3) ^{*1}	kW	5.5	7.5	11	15	18.5	22	30
Continuous Rating (S1)	kW	3.7	5.5	7.5	11	15	18.5	20
Continuous Rated Torque	N·m	71	105	143	263	249	307	332
Base Speed	min ⁻¹	500			400	575		
Maximum Speed	min ⁻¹	7000			6000			5000
Moment of Inertia	× 10 ⁻³ kg·m ²	69.0	69.0	89.0	231.0	231.0	266.0	398.0
Vibration		V5						V10
Noise	dB (A)	75 or less			80 or less			
Cooling Method		Totally enclosed, external fan cooled						
Protection Class		IP44 (IEC34-5)						
Cooling Fan Motor		Equipped with thermostat (automatic reset) 200 V class: Three-phase 200 V 50/60 Hz, 220 V 50/60 Hz, 230 V 60 Hz 400 V class: Three-phase 400 V 50/60 Hz, 440 V 50/60 Hz, 460 V 60 Hz						
Encoder (Magnetic)		Pulse encoder (1024 p/r)						
Overheating Protection		NTC thermistor						
Installation		Flange type: IM B5, IM V1 (motor shaft from horizontal to vertically down) Foot-mounted type: IM B3 (installed on floor)						
Overload Capacity		200% of continuous rated (S1) output for 10 s						
Thermal Class		F						
Withstand Voltage		200 V class: 1500 VAC for one minute 400 V class: 1800 VAC for one minute						
Insulation Resistance		500 V DC 10 MΩ minimum						
Surrounding Air Temperature and Surrounding Air Humidity		0 to 40°C, 95% RH or less (no condensation)						
Altitude		1000 m or less						
Bearing Lubrication		Grease						
Paint Color		Munsell N1.5						
Compliant Standards		JIS, JEC						
Applicable SERVOPACK CACR-JU□□□□	Three-phase 200 V AC	028A	036A	065A	065A	084A	102A	125A
	Three-phase 400 V AC	014D	018D	033D	033D	042D	051D	–

*1. The 50% ED rating (S3) is for a 10 minute cycle consisting of 5 minutes of operation and 5 minutes stopped.

*2. Available only for three-phase, 200 VAC models.

(3) Output and Torque Characteristics

The output and torque characteristics for spindle motors are shown below.









■ Single-winding Motors

Model UAKAJ-	Output Characteristics	Torque Characteristics
04C		
06C		
08C		
11C		
15C		

(cont'd)

Model UAKAJ-	Output Characteristics	Torque Characteristics
19C	<p>Output (kW) vs Motor speed (min⁻¹) for Model 19C. The graph shows three performance curves: 10 second rating (pink), 50%ED rating (black), and Continuous rating (blue). At 1500 min⁻¹, the 10 second rating is 30 kW, 50%ED rating is 18.5 kW, and Continuous rating is 15 kW. At 7000 min⁻¹, the 10 second rating is 17.0 kW, 50%ED rating is 15.8 kW, and Continuous rating is 12.8 kW.</p>	<p>Torque (N·m) vs Motor speed (min⁻¹) for Model 19C. The graph shows three performance curves: 10 second rating (pink), 50%ED rating (black), and Continuous rating (blue). At 1500 min⁻¹, the 10 second rating is 191 N·m, 50%ED rating is 118 N·m, and Continuous rating is 95.5 N·m.</p>
22C	<p>Output (kW) vs Motor speed (min⁻¹) for Model 22C. The graph shows three performance curves: 10 second rating (pink), 50%ED rating (black), and Continuous rating (blue). At 1500 min⁻¹, the 10 second rating is 37 kW, 50%ED rating is 22 kW, and Continuous rating is 18.5 kW. At 7000 min⁻¹, the 10 second rating is 21.1 kW, 50%ED rating is 18.8 kW, and Continuous rating is 15.8 kW.</p>	<p>Torque (N·m) vs Motor speed (min⁻¹) for Model 22C. The graph shows three performance curves: 10 second rating (pink), 50%ED rating (black), and Continuous rating (blue). At 1500 min⁻¹, the 10 second rating is 236 N·m, 50%ED rating is 140 N·m, and Continuous rating is 118 N·m.</p>
30C	<p>Output (kW) vs Motor speed (min⁻¹) for Model 30C. The graph shows three performance curves: 10 second rating (pink), 50%ED rating (black), and Continuous rating (blue). At 1150 min⁻¹, the 10 second rating is 44 kW, 50%ED rating is 30 kW, and Continuous rating is 22 kW. At 6000 min⁻¹, the 10 second rating is 27.1 kW, 50%ED rating is 22.5 kW, and Continuous rating is 16.5 kW.</p>	<p>Torque (N·m) vs Motor speed (min⁻¹) for Model 30C. The graph shows three performance curves: 10 second rating (pink), 50%ED rating (black), and Continuous rating (blue). At 1150 min⁻¹, the 10 second rating is 365 N·m, 50%ED rating is 249 N·m, and Continuous rating is 183 N·m.</p>
37C	<p>Output (kW) vs Motor speed (min⁻¹) for Model 37C. The graph shows three performance curves: 10 second rating (pink), 50%ED rating (black), and Continuous rating (blue). At 1150 min⁻¹, the 10 second rating is 54 kW, 50%ED rating is 37 kW, and Continuous rating is 30 kW. At 6000 min⁻¹, the 10 second rating is 33.3 kW, 50%ED rating is 27.7 kW, and Continuous rating is 22.5 kW.</p>	<p>Torque (N·m) vs Motor speed (min⁻¹) for Model 37C. The graph shows three performance curves: 10 second rating (pink), 50%ED rating (black), and Continuous rating (blue). At 1150 min⁻¹, the 10 second rating is 449 N·m, 50%ED rating is 307 N·m, and Continuous rating is 249 N·m.</p>
45C	<p>Output (kW) vs Motor speed (min⁻¹) for Model 45C. The graph shows three performance curves: 10 second rating (pink), 50%ED rating (black), and Continuous rating (blue). At 1150 min⁻¹, the 10 second rating is 74 kW, 50%ED rating is 45 kW, and Continuous rating is 37 kW. At 5000 min⁻¹, the 10 second rating is 41.4 kW, 50%ED rating is 29.7 kW, and Continuous rating is 24.4 kW.</p>	<p>Torque (N·m) vs Motor speed (min⁻¹) for Model 45C. The graph shows three performance curves: 10 second rating (pink), 50%ED rating (black), and Continuous rating (blue). At 1150 min⁻¹, the 10 second rating is 615 N·m, 50%ED rating is 374 N·m, and Continuous rating is 307 N·m.</p>

■ Winding Selection Motors

Model UAKBJ-	Output Characteristics	Torque Characteristics
06C	<p>High-speed winding</p> 	<p>High-speed winding</p> 
	<p>Low-speed winding</p> 	<p>Low-speed winding</p> 
08C	<p>High-speed winding</p> 	<p>High-speed winding</p> 
	<p>Low-speed winding</p> 	<p>Low-speed winding</p> 





(cont'd)

Model UAKBJ-	Output Characteristics	Torque Characteristics
11C	<p>High-speed winding</p>	<p>High-speed winding</p>
	<p>Low-speed winding</p>	<p>Low-speed winding</p>
15C	<p>High-speed winding</p>	<p>High-speed winding</p>
	<p>Low-speed winding</p>	<p>Low-speed winding</p>

(cont'd)

Model UAKBJ-	Output Characteristics	Torque Characteristics
19C	<p>High-speed winding</p>	<p>High-speed winding</p>
	<p>Low-speed winding</p>	<p>Low-speed winding</p>
22C	<p>High-speed winding</p>	<p>High-speed winding</p>
	<p>Low-speed winding</p>	<p>Low-speed winding</p>

(cont'd)

Model UAKBJ-	Output Characteristics	Torque Characteristics
30C	<p>High-speed winding</p>  <p>Output (kW)</p> <p>Motor speed (min⁻¹)</p> <p>40 10 second rating 30 50%ED rating 20 Continuous rating</p> <p>32.0 28.8 19.2</p> <p>1500 4000 4800 5000</p>	<p>High-speed winding</p>  <p>Torque (N·m)</p> <p>Motor speed (min⁻¹)</p> <p>255 10 second rating 191 Continuous rating 127 50%ED rating</p> <p>1500 4000 4800 5000</p>
	<p>Low-speed winding</p>  <p>Output (kW)</p> <p>Motor speed (min⁻¹)</p> <p>36 10 second rating 30 50%ED rating 20 Continuous rating</p> <p>575 1500</p>	<p>Low-speed winding</p>  <p>Torque (N·m)</p> <p>Motor speed (min⁻¹)</p> <p>598 10 second rating 498 Continuous rating 332 50%ED rating</p> <p>575 1500</p>

(4) Tolerance Radial Loads

The tolerance radial loads for spindle motors are shown in the following table.

Model: UAKAJ-, UAKBJ-	Rated Output (kW) 50%ED Rating/ Continuous Rating	Tolerance Radial Load (N)	
		Single-winding Motor Model: UAKAJ-□□C	Winding Selection Motor Model: UAKBJ-□□C
04	3.7/2.2	1180	–
06	5.5/3.7	1180	2940
08	7.5/5.5	1470	2940
11	11/7.5	1470	3530
15	15/11	2940	4410
19	18.5/15	2940	4410
22	22/18.5	3530	4900
30 ^{*1}	30/22 ^{*2}	4410	5200
37 ^{*1}	37/30	4900	–
45 ^{*1}	45/37	5200	–

*1. Available only for three-phase, 200 VAC models.

*2. The rated output for the winding selection motor is 30/20 kW.

(5) Motor Total Indicator Readings

The motor TIR (Total Indicator Reading) are shown in the following tables.

■ Flange Type

Item	Model		Accuracy
	Single-winding Motor: UAKAJ-□□	Winding Selection Motor: UAKBJ-□□	
Perpendicularity of the Flange Face to the Motor Shaft	04 to 22	06 to 11	0.04 mm
	30, 37	15	0.06 mm
	45	19 to 30	0.072 mm
Concentricity of the Flange Mating Part to the Motor Shaft	04 to 11	–	0.04 mm
	15 to 22	06 to 11	0.046 mm
	30, 37	15	0.048 mm
Axial Runout of the Motor Shaft	45	19 to 30	0.070 mm
	04 to 08	–	0.02 mm
	11 to 22	06 to 11	0.022 mm
	30 to 45	15 to 30	0.028 mm

■ Foot-mounted Type


Item	Model		Accuracy
	Single-winding Motor: UAKAJ-□□	Winding Selection Motor: UAKBJ-□□	
Shaft Parallelism	04 to 08	–	0.03 mm
	11 to 22	06 to 11	0.033 mm
	30 to 45	15 to 30	0.042 mm
Shaft Vibration	04 to 08	–	0.02 mm
	11 to 22	06 to 11	0.022 mm
	30 to 45	15 to 30	0.028 mm

(6) Rotation Direction



Forward rotation of the spindle motor is counterclockwise when viewed from the load. For more information on how to change the direction of rotation, refer to 11.2.2 *Spindle Motor Rotation Direction*.

(7) Vibration Resistance



The spindle motor will withstand the following vibration acceleration in three directions: Vertical, side to side, and front to back.

Spindle Motor		Vibration Acceleration at Flange	Vibration Frequency	
Winding System	Model		Constant Amplitude	Constant Acceleration
Single winding	UAKAJ-04 to -22	24.5 m/s ²	10 to 60 Hz	6 to 2500 Hz
	UAKAJ-30, -37	19.6 m/s ²		
	UAKAJ-45	4.9 m/s ²		
Winding Selection	UAKBJ-06, 08, -11	24.5 m/s ²		
	UAKBJ-15 to -22	19.6 m/s ²		
	UAKBJ-30	4.9 m/s ²		




IMPORTANT

The amount of vibration the spindle motor endures will vary depending on the application. Check the vibration acceleration being applied to your motor for each application.

(8) External Dimensions

■ Single-winding Motors

• Flange type



Unit: mm


Model UAKAJ-	L	LA	LB	LC	LG	LH	LL	LR	Z	D	I	KD	KL	KI
04	375	185	150 ⁰ _{-0.04}	174	12	220	315	60	11	174	–	34	142	174
06	467	185	150 ⁰ _{-0.04}	174	12	220	407	60	11	174	–	34	142	174
08	496	215	180 ⁰ _{-0.04}	204	16	250	416	80	15	204	270	42.5	158	207
11	556	215	180 ⁰ _{-0.04}	204	16	250	446	110	15	204	270	42.5	158	207
15	568	265	230 ⁰ _{-0.046}	250	20	300	458	110	15	260	343	42.5	181	250
19	568	265	230 ⁰ _{-0.046}	250	20	300	458	110	15	260	343	42.5	181	250
22	632	265	230 ⁰ _{-0.046}	250	20	300	522	110	15	260	343	42.5	181	250
30	769	350	300 ⁰ _{-0.052}	320	20	385	629	140	19	320	440	61	227	320
37	809	350	300 ⁰ _{-0.052}	320	20	385	669	140	19	320	440	61	227	320
45	797	400	350 ⁰ _{-0.057}	370	22	450	657	140	24	380	504	61	315	388

Model UAKAJ-	Shaft End Dimensions										Approx. Mass kg
	Q	QK	QR	S	T	U	W	d	m		
04	60	45	1	28 ^{0.009} _{-0.004}	7	4	8	16	M6	29	
06	60	45	1	28 ⁰ _{-0.013}	7	4	8	22	M4	47	
08	80	70	2	32 ⁰ _{-0.016}	8	5	10	22	M5	52	
11	110	90	0.5	48 ⁰ _{-0.016}	9	5.5	14	40	M5	59	
15	110	90	1	48 ⁰ _{-0.016}	9	5.5	14	40	M5	94	
19	110	90	1	48 ⁰ _{-0.016}	9	5.5	14	40	M5	94	
22	110	90	1	55 ^{0.030} _{0.011}	10	6	16	45	M5	120	
30	140	110	2	60 ^{0.030} _{0.011}	11	7	18	50	M6	220	
37	140	110	2	60 ^{0.030} _{0.011}	11	7	18	50	M6	250	
45	140	110	1	70 ^{0.030} _{0.011}	12	7.5	20	60	M6	310	

Note 1. The shaft key and the keyway are standard JIS B 1301-1996 models.

2. The figures are provided only to explain the dimensions. The actual appearance of the spindle motor may vary.

• Foot-mounted type`



Unit: mm


Model UAKAJ-	A	B	C	D	E	F	G	H	J	KD	L	M	N	R
04	230	83	100 ⁰ _{-0.5}	174	80	40	9	242	34	34	375	188	106	145
06	292	113	100 ⁰ _{-0.5}	174	80	70	9	242	34	34	467	188	168	175
08	286	117	112 ⁰ _{-0.5}	204	95	50	10	269	75	42.5	486	220	129	200
11	296	137	112 ⁰ _{-0.5}	204	95	70	10	269	75	42.5	546	220	177	250
15	261	196	160 ⁰ _{-0.5}	260	127	89	16	341	55	42.5	568	290	223	307
19	261	196	160 ⁰ _{-0.5}	260	127	89	16	341	55	42.5	568	290	223	307
22	307	212	160 ⁰ _{-0.5}	260	127	105	16	341	55	42.5	630	290	255	323
30	381	246	180 ⁰ _{-0.5}	320	139.5	127	16	407	55	61	769	320	298	388
37	421	246	180 ⁰ _{-0.5}	320	139.5	127	16	407	55	61	809	320	298	388
45	377	273	225 ⁰ _{-0.5}	380	178	127	21	540	75	61	793	420	370	416

Model UAKAJ-	XB	Z	KI	Shaft End Dimensions									Approx. Mass kg
				Q	QK	QR	S	T	U	W	d	m	
04	45	12	174	60	45	1	28 ^{0.009} _{-0.004}	7	4	8	16	M6	30
06	45	12	174	60	45	1	28 ⁰ _{-0.013}	7	4	8	22	M4	49
08	70	12	207	80	70	2	32 ⁰ _{-0.016}	8	5	10	22	M5	56
11	70	12	207	110	90	0.5	48 ⁰ _{-0.016}	9	5.5	14	40	M5	64
15	108	15	250	110	90	1	48 ⁰ _{-0.016}	9	5.5	14	40	M5	110
19	108	15	250	110	90	1	48 ⁰ _{-0.016}	9	5.5	14	40	M5	110
22	108	15	250	110	90	1	55 ^{0.030} _{0.011}	10	6	16	45	M5	130
30	121	19	320	140	110	2	60 ^{0.030} _{0.011}	11	7	18	50	M6	230
37	121	19	320	140	110	2	60 ^{0.030} _{0.011}	11	7	18	50	M6	260
45	149	24	388	140	110	1	70 ^{0.030} _{0.011}	12	7.5	20	60	M6	320

- Note 1. The shaft key and the keyway are standard JIS B 1301-1996 models.
 2. The figures are provided only to explain the dimensions. The actual appearance of the spindle motor may vary.

■ Winding Selection Motors

- Flange type




Unit: mm

Model UAKBJ-	L	LA	LB	LC	LG	LH	LL	LR	Z	D	I	KD	KL	KI
06	568	265	230 ⁰ _{-0.046}	250	20	300	458	110	15	260	343	42.5	181	250
08	568	265	230 ⁰ _{-0.046}	250	20	300	458	110	15	260	343	42.5	181	250
11	632	265	230 ⁰ _{-0.046}	250	20	300	522	110	15	260	343	42.5	181	250
15	769	350	300 ⁰ _{-0.052}	320	20	385	629	140	19	320	440	61	227	320
19	769	350	300 ⁰ _{-0.052}	320	20	385	629	140	19	320	440	61	227	320
22	809	350	300 ⁰ _{-0.052}	320	20	385	669	140	19	320	440	61	227	320
30	797	400	350 ⁰ _{-0.057}	370	22	450	657	140	24	380	504	61	315	388

Model UAKBJ-	Shaft End Dimensions										Approx. Mass kg
	Q	QK	QR	S	T	U	W	d	m		
06	110	90	1	48 ⁰ _{-0.016}	9	5.5	14	40	M5	94	
08	110	90	1	48 ⁰ _{-0.016}	9	5.5	14	40	M5	94	
11	110	90	1	55 ^{0.030} _{0.011}	10	6	16	45	M5	120	
15	140	110	2	60 ^{0.030} _{0.011}	11	7	18	50	M6	220	
19	140	110	2	60 ^{0.030} _{0.011}	11	7	18	50	M6	220	
22	140	110	2	60 ^{0.030} _{0.011}	11	7	18	50	M6	250	
30	140	110	1	70 ^{0.030} _{0.011}	12	7.5	20	60	M6	310	

- Note 1. The shaft key and the keyway are standard JIS B 1301-1996 models.
 Note 2. The figures are provided only to explain the dimensions. The actual appearance of the spindle motor may vary.

• Foot-mounted type



Unit: mm

Model UAKBJ-	A	B	C	D	E	F	G	H	J	KD	L	M	N	R
06	261	196	160 ⁰ _{-0.5}	260	127	89	16	341	55	42.5	568	290	223	307
08	261	196	160 ⁰ _{-0.5}	260	127	89	16	341	55	42.5	568	290	223	307
11	307	212	160 ⁰ _{-0.5}	260	127	105	16	341	55	42.5	630	290	255	323
15	381	246	180 ⁰ _{-0.5}	320	139.5	127	16	407	55	61	769	320	298	388
19	381	246	180 ⁰ _{-0.5}	320	139.5	127	16	407	55	61	769	320	298	388
22	421	246	180 ⁰ _{-0.5}	320	139.5	127	16	407	55	61	809	320	298	388
30	376.5	273	225 ⁰ _{-0.5}	380	178	127	21	540	75	61	792.5	420	370	416

Model UAKBJ-	XB	Z	KI	Shaft End Dimensions									Approx. Mass kg
				Q	QK	QR	S	T	U	W	d	m	
06	108	15	250	110	90	1	48 ⁰ _{-0.016}	9	5.5	14	40	M5	110
08	108	15	250	110	90	1	48 ⁰ _{-0.016}	9	5.5	14	40	M5	110
11	108	15	250	110	90	1	55 ^{0.030} _{0.011}	10	6	16	45	M5	130
15	121	19	320	140	110	2	60 ^{0.030} _{0.011}	11	7	18	50	M6	230
19	121	19	320	140	110	2	60 ^{0.030} _{0.011}	11	7	18	50	M6	230
22	121	19	320	140	110	2	60 ^{0.030} _{0.011}	11	7	18	50	M6	260
30	149	24	388	140	110	1	70 ^{0.030} _{0.011}	12	7.5	20	60	M6	320

- Note 1. The shaft key and the keyway are standard JIS B 1301-1996 models.
 2. The figures are provided only to explain the dimensions. The actual appearance of the spindle motor may vary.

3.2 Σ -V-SD Driver

3.2.1 Power Regeneration Converter

(1) Basic Specifications

Item		Specifications					
Model: CACP-JU□□A3□, CACP-JU□□D3□		15	19	22	30* ¹	37* ¹	45* ¹
50% ED Rating	kW	15	18.5	22	30	37	45
Continuous Rating	kW	11	15	18.5	22	30	37
Basic Specifications	Input Power	Main Circuits L1, L2, and L3	CACP-JU□□A3□: Three-phase 200 to 230 V (50/60 Hz) CACP-JU□□D3□: Three-phase 380 to 480 V (50/60 Hz) Allowable voltage fluctuation: +10% to -15% Allowable frequency fluctuation: $\pm 5\%$ Voltage unbalance: 5% maximum				
		Control Power	24 VDC Allowable voltage fluctuation: $\pm 15\%$ Output holding time: 100 ms minimum				
		Power Supply for Fan* ²	24 VDC				
	Output Power	Main Circuit Power Output +/-	CACP-JU□□A3□: 270 to 310 VDC CACP-JU□□D3□: 520 to 650 VDC				
		Control Power Output	24 VDC $\pm 15\%$ (connector pass current: 10 A)				
	Input Signals	Sequence Input Signals	Emergency stop input signal Input power voltage: 24 VDC $\pm 5\%$ Required current per channel: 3 mA				
Functions	Regeneration Control Method		Power regeneration control (120-degree conduction)				
	Protective Functions		Main circuit fuse, overload, overvoltage, insufficient voltage, overcurrent, frequency error, heat sink overheating, etc.				
	Allowable Power Loss Time		5 ms (at 70% load)				
	Connections between SERVOPACKs		Local bus				
	Indications		CHARGE (orange), ALARM (red), and READY (green)				


*1. Available only for three-phase 200 VAC models.

*2. Needed when using a base mounting unit. For details, refer to 3.3.4 *Base Mounting Units*.

■ Panel Display

The status of power regeneration converter can be checked on the panel display.

Name	LED Color	Meaning
CHARGE	Orange	Lit when main circuit power is on. Not lit when main circuit power is off.
ALARM	Red	Lit when alarm occurs. Not lit when no alarm occurs.
READY	Green	Lit when CPU of power regeneration converter works normally. Not lit when CPU of power regeneration converter not working.



Power Regeneration Converter


(2) I/O Current and Inrush Current

Voltage	Capacity (50%ED) kW	Capacity (Continuous Ratings) kW	Model	Input Current (50%ED) Arms	Input Current (Continuous Ratings) Arms	Output Current (50%ED) Arms	Output Current (Continuous Ratings) Arms	Inrush Current (Main Circuit) A _{0-P}
200 V	15	11	CACP-JU15A3□	73	54	69	51	83
	18.5	15	CACP-JU19A3□	90	73	85	69	83
	22	18.5	CACP-JU22A3□	107	90	102	85	83
	30	22	CACP-JU30A3□	145	107	138	102	178
	37	30	CACP-JU37A3B	179	145	170	138	178
	45	37	CACP-JU45A3B	218	179	207	170	178
400 V	15	11	CACP-JU15D3□	36	27	36	27	173
	18.5	15	CACP-JU19D3□	45	36	45	36	173
	22	18.5	CACP-JU22D3□	53	45	53	45	173

(3) External Dimensions

■ Duct-ventilated Type


- Model: CACP-JU15□□, -JU19□□, -JU22□□



Unit: mm
Approx. Mass: 8.3 kg

* The cooling air speed of heat sink must be at least 2.5 m/s at the point closest to the heat sink.
Note: Ten digit of □: A = Three-phase 200 VAC, D = Three-phase 400 VAC

- Models: CACP-JU30A3□ and -JU37A3B




Unit: mm
Approx. mass: 11.1 kg for the -JU30A3□,
12.0 kg for the -JU37A3B

* The cooling air speed of heat sink must be at least 2.5 m/s at the point closest to the heat sink.
Note: Available only for three-phase 200 VAC models.

3.2.1 Power Regeneration Converter


- Model: CACP-JU45A3B



* The cooling air speed of heat sink must be at least 2.5 m/s at the point closest to the heat sink.
 Note: Available only for three-phase 200 VAC models.


■ Base-mounted Type

- Model: CACP-JU15A3BB, -JU19A3BB, -JU22A3BB




* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.
 Note: Available only for three-phase 200 VAC models.

- Models: CACP-JU30A3BB and -JU37A3BB



* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.
 Note: Available only for three-phase 200 VAC models.

- Model: CACP-JU45A3BB



* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.
 Note: Available only for three-phase 200 VAC models.

3.2.2 SERVOPACK**(1) Basic Specifications**

Item		Specifications	
Input Power	Main Circuits + / -	CACR-JU□□□AE□: 270 V to 310 VDC CACR-JU□□□DE□: 520 V to 650 VDC	
	Control Power Supply	24 VDC Allowable voltage fluctuation: ± 15% Output holding time: 100 ms minimum	
	Power Supply for Fan *1	24 VDC	
Feedback*2		Pulse encoder (phases A, B, and Z)	
Fuses		Main circuit power: Not available (built into power regeneration converter) Control power: Built in	
Analog Monitor (Built-in)*3	Number of Channels	2 for each axis	
	Output Power Range	±10 V (linear range: ±8 V)	
	Response Frequency	1 kHz	
USB Communications	Connected Device	Personal computer (application: SigmaWin+ version 5.70 or later Σ-V-SD component version 1.00 or later)	
	Communication Standard	USB 1.1 compliant, 12 Mbps (full speed support)	
	Functions	Status displays, parameter setting, and adjustment function	
Sequence Signal	External Input Power	Input Power Voltage	24 VDC ±5%
		Current Required per Channel	4 mA
	Input Signals	Number of Channels	14 for each axis (isolated)
		Output Signals	Number of Channels
	Maximum Output Current		50 mA
	Maximum Applicable Voltage		30 V
	Delay		Depends on relay circuit.
	Error Signals (Relays)	Number of Channels	1 channel (SPDT contacts)
		Maximum Load Current	1 A
		Maximum Applicable Voltage	30 V

*1. Needed when using a base mounting unit. For details, refer to 3.3.4 *Base Mounting Units*.

*2. Not available for serial encoder.

*3. Do not use an analog monitor signal for system control. Use an analog monitor signal only for adjusting the motor or obtaining data for maintenance purpose.

(cont'd)


Item		Specifications	
HWBB Signal	External Input Power	Input Power Voltage	24 VDC \pm 5%
		Current Required per Channel	4 mA
	Input Signals	Number of Channels	2 for each axis (isolated)
	Output Signal	Number of Channels	1 for each axis (isolated)
		Maximum Output Current	50 mA
		Maximum Applicable Voltage	30 V
		When an HWBB signal is input	Output ON when inputs of two channels are OFF.
Load Factor Meter Output, Speed Meter Output	Output Voltage Range	0 to 10 V	
	Maximum Output Current	2 mA	
Analog Speed Reference Input	Maximum Input Voltage	\pm 12 V	
	Input Impedance	60 k Ω	
	Internal Power Supply	+15 VDC \pm 5%	
12-bit Digital Reference Input	Input Power Voltage	24 VDC \pm 5%	
	Current Required per Channel	4 mA	
Motor Winding Temperature Detection	Number of Channels	1 for each axis	
	Temperature Sensor	NTC thermistor	
Motor Winding Selection	Number of Channels	1ch	
	Output Voltage	+24 V	
	Allowable Output Current	50 mA	
	Answerback Function	Supported	
Speed Control Range		40 min ⁻¹ to Maximum motor speed	

■ Panel Display

The SERVOPACK status can be checked on the panel display.

Name	LED Color	Meaning
CHARGE	Orange	Lit when main circuit power is on. Not lit when main circuit power is off.
RDY	Green	Lit when CPU of SERVOPACK works normally. Blink when the digital operator is connected. Not lit when CPU of SERVOPACK not working.
ALM	Red	Lit when alarm occurs. Not lit when no alarm occurs.
7-segment LED*	Red	Shows the status of the SERVOPACK such as alarms.

* For details on the panel indicator and its meanings, refer to 11.1 Panel Display.




(2) I/O Current

Voltage	Capacity (50%ED) kW	Capacity (Continuous Ratings) kW	Model	Input Current (50%ED) Arms	Input Current (Continuous Ratings) Arms	Output Current (50%ED) Arms	Output Current (Continuous Ratings) Arms
270 VDC	5.5	3.7	CACR-JU028AEA	26	17	34	28
	7.5	5.5	CACR-JU036AEA	35	26	46	36
	15	11	CACR-JU065AEA	69	51	82	65
	18.5	15	CACR-JU084AEA	85	69	100	84
	22	18.5	CACR-JU102AEA	102	85	116	102
	30	22	CACR-JU125AEA	138	102	160	125
540 VDC	45	37	CACR-JU196AEA	207	170	240	196
	5.5	3.7	CACR-JU014DEA	13	9	17	14
	7.5	5.5	CACR-JU018DEA	18	13	23	18
	15	11	CACR-JU033DEA	36	27	41	32.5
	18.5	15	CACR-JU042DEA	45	36	50	42
	22	18.5	CACR-JU051DEA	53	45	58	51


3.2.2 SERVOPACK

- Model: CACR-JU065AEA, -JU033DEA




* The cooling air speed of heat sink must be at least 2.5 m/s at the point closest to the heat sink.

- Model: CACR-JU084AEA, -JU102AEA, -JU042DEA, -JU051DEA




* The cooling air speed of heat sink must be at least 2.5 m/s at the point closest to the heat sink.

• Model: CACR-JU125AEA



* The cooling air speed of heat sink must be at least 2.5 m/s at the point closest to the heat sink.


• Model: CACR-JU196AEA



* The cooling air speed of heat sink must be at least 2.5 m/s at the point closest to the heat sink.

■ Base-mounted Type


- Model: CACR-JU028AEAB



Unit: mm
 Approx. Mass: 4.4 kg

* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.



- Model: CACR-JU036AEAB



Unit: mm
 Approx. Mass: 7.8 kg

* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.



• Model: CACR-JU065AEAB



Unit: mm
Approx. Mass: 9.2 kg

* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.

• Model: CACR-JU084AEAB, -JU102AEAB




Unit: mm
Approx. Mass: 15.4 kg

* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.

3.2.2 SERVOPACK


• Model: CACR-JU125AEAB



Unit: mm
Approx. Mass: 15.6 kg

* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.

• Model: CACR-JU196AEAB



Unit: mm
Approx. Mass: 25.0 kg

* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.

3.3 Peripheral Devices

3.3.1 AC Reactor



(1) Specifications

Power Regeneration Converter Model	AC Reactor Model	Rated Voltage (V)	Frequency (Hz)	Rated Current (A)	Inductance (mH)	Insulation Class (class)	Watt Data Loss (W)	Surrounding Air Temperature	Storage Temperature	Approx. Mass (kg)
CACP-JU15A3□	X008017	230	50/60	56	0.21	H	55	-10 to 55°C	-20 to 85°C	8
CACP-JU19A3□	X008018	230	50/60	73	0.17	H	70	-10 to 55°C	-20 to 85°C	8
CACP-JU22A3□	X008019	230	50/60	90	0.14	H	80	-10 to 55°C	-20 to 85°C	12
CACP-JU30A3□	X008020	230	50/60	107	0.1	H	85	-10 to 55°C	-20 to 85°C	12
CACP-JU37A3B	X008029	230	50/60	145	0.09	H	93	-10 to 55°C	No restrictions.	12
CACP-JU45A3B	X008022	230	50/60	179	0.07	H	130	-10 to 55°C	-20 to 85°C	25
CACP-JU15D3□	X008010*	480	50/60	27	0.82	H	70	-10 to 55°C	-20 to 85°C	7.3
CACP-JU19D3□	X008011	480	50/60	36	0.67	H	80	-10 to 55°C	-20 to 85°C	7.3
CACP-JU22D3□	X008012	480	50/60	45	0.56	H	120	-10 to 55°C	-20 to 85°C	11.2

* UL standards are not supported. Ask your Yaskawa representative if you require an AC Reactor that supports UL standards.



(2) External Dimensions

■ Model: X008017





Unit: mm

■ Model: X008018





Unit: mm

■ Model: X008019




Unit: mm

■ Model: X008020




Unit: mm

■ Model: X008029




Unit: mm

■ Model: X008022




Unit: mm


■ Model: X008010



■ Model: X008011



■ Model: X008012



3.3.2 Magnetic Contactor for Winding Selection

(1) Specifications

Model ^{*1}	Standard	HV-75AP4	HV-150AP4	HV-200AP4
	For UL Compliance	HV-75AP4/UL	HV-150AP4/UL	HV-200AP4/UL
Contact	Main contact: 3NO, 3NC, auxiliary contact: 1NC			
Rated Insulation Voltage	600 V			
Rated Applying Current	Continuous	75 A	150 A	200 A
	30 minutes ^{*2}	87 A	175 A	226 A
Breaking Current Capacity	220 V	200 A	400 A	
	440 V	150 A	300 A	
Open/Close Frequency	600 times/hour			
Mechanical Duration of Life	5 million times			
Control Magnetic Coil Rating	200 V 50/60 Hz, 220 V 50/60 Hz, 230 V 60 Hz			
Mass	2.5 kg	5.0 kg		
Surrounding Air Temperature	-10 to 55°C			
Storage Temperature	-20 to 85°C			
Humidity	10 to 95%RH (non-condensing)			
Spindle Motor Capacity (50%ED)	5.5 to 15 kW	18.5 to 30 kW	37 to 45 kW	


*1. Model numbers for contactors with safety covers are HV-□□AP4S and HV-□□AP4S/UL.

*2. A dwell time of 1 hour or more is required after applying power supply for 30 minutes.


(2) External Dimensions

The external dimensions are shown below.


■ Model: HV-75AP4



■ Model: HV-75AP4/UL




■ Model: HV-150AP4, HV-150AP4/UL, HV-200AP4, HV-200AP4/UL



(3) Terminal Descriptions

The terminal name and operation status are shown below. For mounting direction, refer to 3.3.2 (4) *Installation Orientation*.

Terminal	Name	Operation Status	
13-14	Selection signal	+24 V (Low-speed winding)	0 V (High-speed winding)
1-2 3-4 5-6	Main contact: 3NC	Open	Closed
7-8 9-10 11-12	Main contact: 3NO	Closed	Open
15-16	Auxiliary contact: 1NC	Open	Closed
17-18	Single-phase 200 V power supply	—	—



(4) Installation Orientation

Use the following method to install a magnetic contactor for winding selection.

Mounting	Model: HV-75AP4, HV-75AP4/UL	Model: HV-150AP4, HV-150AP4/UL, HV-200AP4, HV-200AP4/UL
Possible		
Not possible		

3.3.3 Noise Filter


(1) Specifications

Power Regeneration Converter		Noise Filter					
Input Voltage	Model	Model	Rated Current (A)	Classification	Rated Voltage	Leakage Current (mA)	Manufacturer
Three-phase 200 VAC	CACP-JU15A3□	HF3060C-SZC-47EDD	60	Three-phase three-wire	480 VAC	8 (for 200 VAC, 60 Hz)	SOSHIN ELECTRIC CO., LTD
	CACP-JU19A3□	HF3080C-SZC-47EDD	80				
	CACP-JU22A3□	HF3100C-SZC-47EDD	100				
	CACP-JU30A3□	HF3150C-SZC-47EDD	150				
	CACP-JU37A3B	HF3150C-SZC-47EDD	150				
	CACP-JU45A3B	HF3200C-SZC-49EDE*	200			25 (for 200 VAC, 60 Hz)	
Three-phase 400 VAC	CACP-JU15D3□	HF3030C-SZC-47DDD	30	Three-phase three-wire	480 VAC	13 (for 400 VAC, 50 Hz)	SOSHIN ELECTRIC CO., LTD
	CACP-JU19D3□	HF3040C-SZC-47EDD	40				
	CACP-JU22D3□	HF3050C-SZC-47EDD	50				

* Also use the following compact AC power supply block-type capacitor (X capacitor).
 Compact AC power supply block-type capacitor (X capacitor) model: LDA106M-AA (Soshin Electric Co., Ltd.)
 Connect the X capacitor near the noise filter input terminal.

(2) External Dimensions


■ Model: HF3030C-SZC-47DDD, HF3040C-SZC-47EDD, HF3050C-SZC-47EDD, HF3060C-SZC-47EDD



Unit: mm

Noise Filter Model	A	B	C	D	E	F	G	H	J	K	L
HF3030C-SZC-47DDD	220	210	66	55	78	R2.25 × 6	4.5 dia.	M4	M4	10.5	12.5
HF3040C-SZC-47EDD	270	260	80	70	84	R2.75 × 7	5.5 dia.	M5	M4	13	16
HF3050C-SZC-47EDD											
HF3060C-SZC-47EDD											

■ Model: HF3080C-SZC-47EDD, HF3100C-SZC-47EDD




- ① Input terminal: M6
- ② Case
- ③ Nameplate
- ④ Output terminal: M6
- ⑤ Earth terminal: M6


Unit: mm

3.3.3 Noise Filter

■ Model: HF3150C-SZC-47EDD



Example of Nameplate: HF3150C-SZC




- Model name
- Rated voltage and current
- Rated frequency
- Lot No.


- 1 Input terminal: M8
- 2 Case
- 3 Nameplate
- 4 Output terminal: M8
- 5 Earth terminal: M6

Unit: mm

■ Model: HF3200C-SZC-49EDE



Example of Nameplate: HF3200C-SZC




- Model name
- Rated voltage and current
- Rated frequency
- Lot No.

- 1 Input terminal: M10
- 2 Case
- 3 Nameplate
- 4 Output terminal: M10
- 5 Earth terminal: M8

Unit: mm

- Compact AC power supply block-type capacitor (X capacitor)
Model: LDA106M-AA



3.3.4 Base Mounting Units


(1) Specifications

Model	Unit Width (mm)	Cooling Fan		Terminal Block		
		Input Voltage (VDC)	Input Current (A)	Terminal Screw	Wire Sizes (AWG)	Tightening Torque (N·m)
JUSP-JUBM050AA	50	24	0.42	M3.5	24 to 12	0.8 to 1.2
JUSP-JUBM075AA	75		0.94			
JUSP-JUBM100AA	100		0.94			
JUSP-JUBM150AA	150		1.88			
JUSP-JUBM250AA	250		1.24			

Note: The input current that is given above is the current for one base mounting unit.


(2) External Dimensions

■ JUSP-JUBM050AA



<Mounting Hole Diagram>


<Unit Mounted Diagram>



Unit: mm


* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.

■ JUSP-JUBM075AA



<Mounting Hole Diagram>


<Unit Mounted Diagram>



Unit: mm


* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.

■ JUSP-JUBM100AA



<Mounting Hole Diagram>




<Unit Mounted Diagram>



Unit: mm


* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.

■ JUSP-JUBM150AA



Approx. Mass: 3.5 kg

<Mounting Hole Diagram>




<Unit Mounted Diagram>




Unit: mm

* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.

■ JUSP-JUBM250AA



Approx. Mass: 4.9 kg




Unit: mm

* The power supply for a cooling fan (24 VDC) is not provided by Yaskawa.

(3) Wiring

Connect the 24-VDC and 0-VDC lines to the terminals on the base mounting unit to power the cooling fan.

- Note 1. The power supply for the cooling fan on the base mounting unit is separate from the control power supply for the power regeneration converter and SERVOPACK and separate from the power supply for the sequence signals.
2. The output current that is required from the power supply when one power supply is connected to more than one base mounting unit is the total input current for all of the connected units. Use a suitable wire size for the required current and do not exceed the wire size range of the terminal block.




(4) Mounting Method

Mount the power regeneration converter and SERVOPACK to the base mounting units as described in this section.

As shown in the following figure, insert the heat sink on the power regeneration converter or SERVOPACK into the base mounting unit and secure it with the enclosed screws (four).

The side of the base mounting unit with the terminal block is the bottom of the unit.

For instructions on installation in a control panel, refer to 1.2.2 Σ -V-SD Series Driver.



Model	Size of Enclosed Screws	Tightening Torque
JUSP-JUBM050AA	M5	2.6 to 3.2 N·m (23.0 to 28.3 lbf·in)
JUSP-JUBM075AA		
JUSP-JUBM100AA		
JUSP-JUBM150AA		
JUSP-JUBM250AA	M6	4.3 to 4.9 N·m (38.1 to 43.4 lbf·in)

Installation

4.1 Spindle Motors	4-2
4.1.1 Installation Environment	4-2
4.1.2 Enclosure	4-2
4.1.3 Installation Orientation	4-3
4.1.4 Coupling Motor and Machinery	4-3
4.2 Σ -V-SD Driver	4-5
4.2.1 Installation Requirements	4-5
4.2.2 Thermal Design of Control Panel	4-6
4.2.3 Control Panel Dust-proof Design	4-9
4.2.4 Installation Precautions	4-10
4.2.5 Installation Orientation and Space	4-11

4.1 Spindle Motors

The service life of the spindle motor will be shortened or unexpected problems will occur if the spindle motor is installed incorrectly or in an inappropriate location. Always observe the following installation instructions.

4.1.1 Installation Environment


Item	Condition
Surrounding Air Temperature	0 to 40°C (no freezing)
Surrounding Air Humidity	20% to 80%RH (no condensation)
Installation Site	<ul style="list-style-type: none"> • Indoor, free of corrosive or explosive gases • Well-ventilated and free of dust and moisture • Facilitates inspection and cleaning. • Elevation: 1,000 m max. • Free of high magnetic field • Free of oil
Storage Environment	Store the motor in the following environment if it is stored with the power cable disconnected. Temperature during storage: -20 to +60°C (no freezing) Humidity during storage: 20% to 80%RH (no condensation)

⚠ CAUTION

- Provide sufficient space so that cooling air will be provided to the cooling fan. Keep a space of at least 100 mm between the machine and the ventilation outlet of the motor.
If ventilation is not proper, the motor temperature fault protective function will work regardless of whether or not the load is at the rated value or not.
- Install the motor in a clean location free from oil mist and water drops. If the motor is likely to come in contact with water or oil, protect the motor with a cover.
The intrusion of water or dirty oil into the interior of the motor will decrease the insulation resistance, which may result in a ground fault.
- Check that the mounting bed, base, or stand of the motor is of robust construction because the weight of the motor as well as the dynamic load of the motor in operation will be imposed on it, possibly causing vibration.
- Use seal connectors, conduits, or similar devices to seal the cable openings of the motor terminal box.
Failure to observe this caution may result in cuttings, cutting oil mist, or other foreign matter entering the motor through the cable opening, possibly causing malfunction.
- When vertically mounting the motor with the shaft on the bottom, the motor shaft must not touch the stand, the ground, or other surfaces.
If the shaft touches these surfaces, the shaft is pushed into the motor and the bearing may be damaged.

4.1.2 Enclosure

The protective structure of the spindle motor when the special cable is used provides IP44 protection. However, this does not apply to the shaft opening. (Refer to the following figure.)



If you need to use the motor in a location where oil will come into contact with the shaft opening, contact a Yaskawa sales representative.

4.1.3 Installation Orientation

(1) Flange type

- Mount the motor with the motor shaft on the load side at any angle between horizontal and the downward vertical direction. If the motor shaft is facing up, excessive force will be imposed on the motor shaft. As a result, the service life of the motor will be adversely affected.
- Use the spindle motor UAKAJ-45 or UAKBJ-30 (outer diameter $\square 380$) with the terminal box facing upward and the motor shaft facing horizontal. If the terminal box is in the horizontal or downward direction, dust may intrude from the ventilation mouth on the bottom of the load-side bracket. As a result, the motor may fail to operate or unexpected accidents may occur.

(2) Foot-mounted type


- Mount the legs on the floor. If the legs are installed upward, excessive force will be imposed on the legs. As a result, the service life of the spindle motor will be adversely affected.

4.1.4 Coupling Motor and Machinery

Consider the following conditions when coupling the spindle motor with the machinery.


(1) Direct Coupling

Couple the motor with the machinery so that the center of the motor shaft and that of the machinery shaft are on a straight line. Insert a liner for adjustment, if necessary.



IMPORTANT


- Install the motor so that alignment accuracy falls within the following range. Vibration that will damage the bearings and encoders if the shafts are not properly aligned.




Measurement Method	Allowable Value
Tolerance A	0.03 mm max.
Surface irregularity B	0.03 mm max.

Note: Turn together with coupling.

- Do not allow any direct impact to the shafts when installing the couplings. Do not hit the area near encoders with a hammer etc., as impacts may damage the encoders.




- Before installation, thoroughly remove the anticorrosive paint from the flange surface and the end of the motor shaft. Only after removing the paint can motors be installed on the machines.



(2) Belt Coupling

- Check that the motor shaft is parallel to the machinery shaft and that the line connecting the centers of the pulleys and the shafts are at right angles to each other. If the angularity of the belt is improper, the belt will vibrate or slip.
- The radial load imposed on the motor shaft edge must not exceed the permissible value. If an excessive radial load is imposed on the motor shaft, the motor bearings will be adversely affected and the service life of the bearings will be decreased.
For details, refer to 3.1(4) *Tolerance Radial Loads*.
- Be sure that no axial load is imposed on the motor shaft.
- Make sure that the contact angle of the belt with the pulley is 140° or more. If not, the belt may slip.



- If C is 1,000 mm or less, $d < 1$ mm.
- If C is more than 1,000 mm, $d/C < 1/1000$.
- $\beta < 1/3^\circ$
- Contact angle $\phi > 140^\circ$

Belt Installation

(3) Gear Coupling

Check that the motor shaft is parallel to the machinery shaft and that the centers of the gears are engaged properly. Refer to 3.1(5) *Motor Total Indicator Readings* for the precision of the peripheral parts connecting to the motor shaft. The gears may grate if they do not engage properly.

Be sure that no axial load is imposed on the motor shaft.

(4) Mounting a Pulley or Gear to the Motor Shaft

When mounting a pulley or gear to the motor shaft, consider the mounting balance of the motor. The dynamic balance of the motor is kept with a half key (for motors with a keyway), which is a half as thick as the key (T) specified in the motor shaft dimensional drawing. The motor rotates at high speed and a little imbalance in the mechanism may cause the motor to vibrate.

4.2 Σ -V-SD Driver

4.2.1 Installation Requirements

Item	Specifications	
Surrounding Air Temperature	0°C to 40°C: at 100% load 0°C to 55°C: at 70% load	
Storage Temperature	-20°C to 85°C	
Surrounding Air Humidity and Storage Humidity	90%RH or less (with no freezing or condensation)	
Vibration Resistance	4.9 m/s ²	
Shock Resistance	19.6 m/s ²	
Protection Class	IP10	An environment that satisfies the following conditions. <ul style="list-style-type: none"> • Free of corrosive or flammable gases • Free of exposure to water, oil, or chemicals • Free of dust, salts, or iron dust
Pollution Degree	2	
Altitude	1000 m or less	
Others	Free of static electricity, strong electromagnetic fields, magnetic fields or exposure to radioactivity	

4.2.2 Thermal Design of Control Panel

Install the Σ -V-SD drivers, host controllers, and other units in a control panel.

Use a control panel with an enclosed structure that provides protection against corrosive gases, water, and oil.

Also, design the system so that the temperature rise in the control panel does not cause the temperature to exceed the surrounding air temperature.

(1) Calorific Value

■ Power Regeneration Converter

Model	Calorific Value at Continuous Rated Operation				
	Total (W)	Loss of Control Block (W)	Loss of Power Block (W)		
			Total	Inside	Duct
CACP-JU15A3□	116.4	13.1	103.3	10.3	93.0
CACP-JU19A3□	154.3	13.1	141.2	14.1	127.1
CACP-JU22A3□	183.8	13.1	170.7	17.1	153.6
CACP-JU30A3□	247.2	14.7	232.5	23.2	209.3
CACP-JU37A3B	276.2	14.7	261.5	26.2	235.3
CACP-JU45A3B	394.7	14.7	380	38.0	342.0
CACP-JU15D3□	66.8	13.1	53.7	5.4	48.4
CACP-JU19D3□	90.5	13.1	77.4	7.7	69.7
CACP-JU22D3□	104.8	13.1	91.7	9.1	82.6

■ SERVOPACK

Model	Calorific Value at Continuous Rated Operation				
	Total (W)	Loss of Control Block (W)	Loss of Power Block (W)		
			Total	Inside	Duct
CACR-JU028AEA	154.1	19.0	135.1	27.0	108.1
CACR-JU036AEA	181.0	19.0	162.0	32.4	129.6
CACR-JU065AEA	324.2	18.9	305.3	30.5	274.8
CACR-JU084AEA	424.6	21.6	403.0	40.3	362.7
CACR-JU102AEA	478.8	21.6	457.2	45.7	411.5
CACR-JU125AEA	614.5	28.6	585.9	58.6	527.3
CACR-JU196AEA	1322.4	29.8	1292.6	129.3	1163.3
CACR-JU014DEA	142.1	19.6	122.5	24.5	98.0
CACR-JU018DEA	168.6	19.6	149.0	29.8	119.2
CACR-JU033DEA	308.4	19.0	289.4	28.9	260.5
CACR-JU042DEA	368.5	21.6	346.9	34.7	312.2
CACR-JU051DEA	424.9	21.6	403.3	40.3	363.0

(2) Air Temperature Rise inside Control Panel (Average Temperature Rise)

Design the control panel so that the internal air temperature will be no more than 10°C higher than the reference value. If the rise in air temperature in the control panel exceeds 10°C, a cooling system must be installed. For details, refer to 4.2.2 (3) *Cooling System Installation*.


The calculation formula for internal temperature rise for a control panel made of metal sheets is as follows:

$$\Delta T = \frac{P}{qe} = \frac{P}{k \cdot A}$$

- ΔT : Temperature rise in the control panel (°C)
- P : Calorific value in the control panel (W)
- qe : Heat flow through ratio of the control panel (W/°C)
- k : Heat pass through ratio of a metal plate (W/m²°C)
 With a stirring fan: 6 W/m²°C
 Without a stirring fan: 4 W/m²°C
- A : Effective radiation area of the control panel (m²)*
 * Radiation available area of the control panel surface area (Exclude the surface which contacts other object)

<Example>

Allowable Watt Data Loss for a Control Panel with a Stirring Fan



- Effective radiation area of the control panel: $A=1.0155$ (m²)
 (Exclude the base area because control panel is type of putting on the floor.)
- Calorific value in the control panel: $P=60$ (W)
- Temperature rise value in the control panel: $\Delta T = \frac{P}{qe} = \frac{P}{k \cdot A} = \frac{60}{6 \times 1.0155} = 9.8$ (°C)

In the above example, the rise in the air temperature inside the control panel, ΔT , is 9.8°C. The criteria of 10°C has therefore been met.

(3) Cooling System Installation


Use the following calculation formula to select a cooling system and install it in the control panel so that the air temperature in the control panel will be no more than 10°C higher than the reference value.

$$\Delta T = \frac{P}{qe} = \frac{P}{k \cdot (A-B) + qh}$$

- ΔT : Temperature rise in the control panel (°C)
 - P: Calorific value in the control panel (W)
 - qe : Heat flow through ratio of the control panel (W/°C)
 - qh : Heat flow through ratio of the cooling system (W/°C)
 - k: Heat pass through ratio of a metal plate (W/m²°C)
With a stirring fan: 6 W/m²°C
Without a stirring fan: 4 W/m²°C
 - A: Effective radiation area of the control panel (m²)*
 - B: Installation area of the cooling system (m²)
- * Radiation available area of the control panel surface area (Exclude the surface which contacts other object)

An installation example is given below.

Install the cooling system so that internal air is taken into the control panel at the top and returned at the bottom, and so that the external air is taken in at the bottom and exhausted at the top.




Cooling System Installation

4.2.3 Control Panel Dust-proof Design

The host controller and other printed circuit boards mounted in the control panel may malfunction due to the effects of airborne particles (dust, cuttings, oil mist, etc.). Observe the following precautions to prevent airborne particles from entering the control panel.

- Always use a sealed structure for the control panel.
- Block cable openings with packing. (Refer to the figure labeled Cable Openings given below.)
- Install packing on the door and external cover to seal them. (Refer to the figure labeled Door Packing given below.)
- Block all gaps.
- Oil may collect on the top surface and may enter the control panel through screw holes. Take special countermeasures, such as using oil-proof packing.



4.2.4 Installation Precautions

Observe the following precautions when designing the control panel.

(1) General Precautions


General precautions are given below.

- Always use a sealed structure for the control panel.
- Install the units so that maintenance inspections, removal, and installation can be performed easily.
- Provide about 100 mm of space between components and the control panel surfaces so that the flow of air is not blocked inside the control panel.
- Design the control panel so that the average internal air temperature will be no more than 10°C higher than the external air.
- We recommend the use of a fan to stir the air to increase cooling efficiency and prevent localized temperature increases in the sealed control panel.
- Separate the units from cables or components of 90 VDC or higher and cables or components for AC power supply by at least 10 mm to help prevent malfunction due to noise.
- Separate the primary and secondary sides of transformer and noise filters.

(2) Installation Precautions

Precautions for installing the Σ -V-SD driver are given below.

- Always secure the Σ -V-SD driver on a vertical surface using screws or bolts.
- Provide the specified space on the left, right, top, and bottom of the driver to enable maintenance and ventilation. For details, refer to 4.2.5 *Installation Orientation and Space*.
- Place the heat sink of the Σ -V-SD driver outside of the ventilation ducts to allow external air flow through the heat sink. The loss from the control panel will be reduced, and the majority of the loss from the unit will be cooled directly by the external air.
- Cooling the heat sink requires an air flow of 2.5 m/s in the ventilation duct.
- Make sure that cooling air flows through the heat sink for each Σ -V-SD driver.
- We recommend a metal cooling fan. Plastic fans will deteriorate when exposed to cutting oil, which may cause Σ -V-SD driver failure or other problems.




Σ -V-SD Driver Installation

4.2.5 Installation Orientation and Space


Precautions for the mounting the Σ -V-SD driver, including the mounting orientation and mounting space, are given below.

Note: The figure is an example of a duct-ventilated type driver. Dimensions for base-mounted type drivers are the same (ventilation duct is not required).



Installation Orientation and Space for Σ -V-SD Driver

- Always install the power regeneration converter on the left side of the SERVOPACK.
- Refer to the external dimension diagrams for external dimensions and mounting dimensions of the products (3.2.1 (3) *External Dimensions* and 3.2.2 (3) *External Dimensions*).
- Make sure that the surrounding air temperature of the Σ -V-SD driver is 0 to 55°C near the heat sink and inside the control panel at a 70% load, and 0 to 40°C near the heat sink and inside the control panel at a 100% load.
- To prevent oil penetration, seal the mounting screw sections of the power regeneration converter and the SERVOPACK.
- Always install the Σ -V-SD driver with the fan at the top to ensure efficient cooling.
- When mounting the Σ -V-SD driver, allow space above and below it to prevent heat buildup.
- When stirring the air inside the control panel, do not allow the airflow to fall directly on the Σ -V-SD driver to prevent dirt from collecting on the Σ -V-SD driver.
- Provide the following spaces between the units.



5


Wiring

5.1 Spindle Motors	5-2
5.1.1 Precautions on Wiring	5-2
5.1.2 Wirings for Spindle Motors	5-3
5.2 Σ -V-SD Driver	5-7
5.2.1 Main Circuit Power Supply	5-7
5.2.2 Control Circuit Power Supply	5-13
5.2.3 DC-bus	5-15
5.2.4 Local Bus	5-16
5.2.5 I/O Signals	5-17

5.1 Spindle Motors

⚠ CAUTION

- Do not bundle the main circuit cable and the encoder cable together.
Failure to observe this caution may result in malfunction.
- The maximum wiring length is 20 m for encoder cables or motor main circuit cables.
If the encoder cable is too long, voltage drop along the cable will reduce the power supply voltage to the encoder and may prevent normal operation.
- Do not connect the spindle motor directly to an industrial power supply.
Failure to observe this caution may damage the spindle motor. Connect the spindle motor to the correct SERVO-PACK.



5.1.1 Precautions on Wiring

(1) Cables

Standard motor main circuit cables, encoder cables, and relay cables cannot be used in cases where high flexibility is needed, as when the cables themselves move or are twisted or turned. Use flexible cables for flexible applications.

(2) Cable Stress

Make sure there is no bending or tension on the cables themselves, the connections, or the cable lead inlets. Be especially careful to wire encoder cables so that they are not subject to stress because the core wires of encoder cables are very thin at only 0.2 to 0.3 mm².

(3) Connectors

Observe the following precautions:

- Connect the main circuit cable, and then connect the encoder cable. If you connect the encoder cable first, the encoder may be damaged due to the difference in electrical potential from the FG.
- Make sure there is no foreign matters such as dust and metal chips in the connector before connecting.
- Do not apply shock to resin connectors. Otherwise, they may be damaged.
- Make sure of the pin arrangement.
- When handling a motor with its cables connected, hold the motor or the connectors and cables will be damaged.

5.1.2 Wirings for Spindle Motors

(1) Main Circuit Cable Wiring

■ Terminal Screws and Tightening Torques (200 V)

Model		Terminal Symbols	Terminal Screw	Tightening Torque [N·m]	Wire Sizes
UAKAJ-□□CZ (Single winding)	04	U, V, W, FG	M5	2.0 to 2.4	AWG8
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	06	U, V, W, FG	M5	2.0 to 2.4	AWG8
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	08	U, V, W, FG	M5	2.0 to 2.4	AWG8
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	11	U, V, W, FG	M5	2.0 to 2.4	AWG6
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	15	U, V, W, FG	M8	6.0 to 9.0	AWG4
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	19	U, V, W, FG	M8	6.0 to 9.0	AWG2
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	22	U, V, W, FG	M8	6.0 to 9.0	AWG1
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
30	U, V, W, FG	M10	10.0 to 15.0	AWG2/0	
	Z1, Z2, Z3	M4	1.2 to 1.8	AWG14	
37	U, V, W, FG	M10	10.0 to 15.0	AWG4/0	
	Z1, Z2, Z3	M4	1.2 to 1.8	AWG14	
45	U, V, W, FG	M10	10.0 to 15.0	AWG4/0	
	Z1, Z2, Z3	M4	1.2 to 1.8	AWG14	
UAKBJ-□□CZ (Winding selection)	06	U1, V1, W1, U2, V2, W2, FG	M6	2.5 to 3.75	AWG8
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	08	U1, V1, W1, U2, V2, W2, FG	M6	2.5 to 3.75	AWG8
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	11	U1, V1, W1, U2, V2, W2, FG	M6	2.5 to 3.75	AWG6
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	15	U1, V1, W1, U2, V2, W2, FG	M8	6.0 to 9.0	AWG4
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	19	U1, V1, W1, U2, V2, W2, FG	M8	6.0 to 9.0	AWG2
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	22	U1, V1, W1, U2, V2, W2, FG	M8	6.0 to 9.0	AWG1
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	30	U1, V1, W1, U2, V2, W2, FG	M10	10.0 to 15.0	AWG2/0
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14

■ Terminal Screws and Tightening Torques (400 V)

Model		Terminal Symbols	Terminal Screw	Tightening Torque [N·m]	Wire Sizes
UAKAJ-□□CZ (Single winding)	06	U, V, W, FG	M5	2.0 to 2.4	AWG8
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	08	U, V, W, FG	M5	2.0 to 2.4	AWG10
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	11	U, V, W, FG	M5	2.0 to 2.4	AWG10
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	15	U, V, W, FG	M8	6.0 to 9.0	AWG8
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	19	U, V, W, FG	M8	6.0 to 9.0	AWG6
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	22	U, V, W, FG	M8	6.0 to 9.0	AWG6
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
UAKBJ-□□CZ (Winding selection)	06	U1, V1, W1, U2, V2, W2, FG	M6	2.5 to 3.75	AWG8
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	08	U1, V1, W1, U2, V2, W2, FG	M6	2.5 to 3.75	AWG10
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	11	U1, V1, W1, U2, V2, W2, FG	M6	2.5 to 3.75	AWG10
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	15	U1, V1, W1, U2, V2, W2, FG	M8	6.0 to 9.0	AWG8
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	19	U1, V1, W1, U2, V2, W2, FG	M8	6.0 to 9.0	AWG6
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14
	22	U1, V1, W1, U2, V2, W2, FG	M8	6.0 to 9.0	AWG6
		Z1, Z2, Z3	M4	1.2 to 1.8	AWG14

■ Wiring

- CACR-JU028AEA, -JU014DEA

SERVOPACK End (CN8)			Motor End	
Pin No.	Signal Name		Terminal Name	
A1	U	—	U	
B1	V	—	V	
B2	W	—	W	
A2	⊕	—	⊕	

- CACR-JU036AEA, -JU018DEA

SERVOPACK End (CN8)			Motor End	
Pin No.	Signal Name		Terminal Name	
1	U	—	U	
2	V	—	V	
3	W	—	W	
4	⊕	—	⊕	

- CACR-JU065AEA, -JU084AEA, -JU102AEA, -JU125AEA, -JU196AEA, -JU033DEA, -JU042DEA, -JU051DEA

SERVOPACK End			Motor End	
Terminal Name			Terminal Name	
U		—	U	
V		—	V	
W		—	W	
⊕		—	⊕	

(2) Encoder Wiring


■ Pulse Encoder (SERVOPACK-end connector: CN3)

- Connections

Pin No.	Signal Name	I/O	Function	Pin No.	Signal Name	I/O	Function
1	PG0V	—	Power supply for encoder 0 V	11	CC	O	0 V for magnetic contactor for winding selection
2	PG0V	—	Power supply for encoder 0 V	12	CA1	I	Winding selection status signal
3	PG0V	—	Power supply for encoder 0 V	13	CA2	I	
4	PG5V	—	Power supply for encoder 5 V	14	PC	I	Motor encoder phase C signal input
5	PG5V	—	Power supply for encoder 5 V	15	/PC	I	
6	PG5V	—	Power supply for encoder 5 V	16	PA	I	Motor encoder phase A signal input
7	(NC)	—	—	17	/PA	I	
8	THSA	I	Motor winding temperature detection	18	PB	I	Motor encoder phase B signal input
9	THSB	I		19	/PB	I	
10	C24V	O	+24 VDC power supply for magnetic contactor for winding selection	20	(NC)	—	—

Note 1. Do not use NC signal.

2. Connect the shielded wires to the CN3 connector shell.



Connecting Diagram of Pulse Encoder for Spindle Motor

5.2 Σ -V-SD Driver

5.2.1 Main Circuit Power Supply



IMPORTANT

- Do not touch the power terminals before the main-circuit capacitor has had time to discharge because high voltage may still remain in the converter and SERVOPACK after the power supply is turned OFF. Refer to the following table for the discharge time of main-circuit capacitor.
- When two or more SERVOPACKs are used in combination, use the longest discharge time of those SERVOPACKs for the main-circuit capacitor.

Input Voltage	SERVOPACK Model	Discharge Time Needed for Main-Circuit Capacitor (min)
Three-phase 200 VAC	CACR-JU028AEA	15
	CACR-JU036AEA	20
	CACR-JU065AEA	20
	CACR-JU084AEA	20
	CACR-JU102AEA	25
	CACR-JU125AEA	25
	CACR-JU196AEA	25
Three-phase 400 VAC	CACR-JU014DEA	10
	CACR-JU018DEA	15
	CACR-JU033DEA	15
	CACR-JU042DEA	15
	CACR-JU051DEA	15

- First make sure the charge indicator is turned OFF and that the DC-bus (symbol: P and N) voltage value is correct by using a tester or other device before wiring or starting an inspection.

(1) Wire Sizes and Tightening Torques

■ Power Regeneration Converter

Input Voltage	Model: CACP-JU	Terminal Symbols	Terminal Screw	Tightening Torque [N·m]	Wire Sizes
Three-phase, 200 VAC	15A3□	L1, L2, L3	M6	2.5 to 3.0	AWG6
		B1, B2	M5	2.0 to 2.4	AWG14
		⊕	M5	2.0 to 2.4	AWG6
	19A3□	L1, L2, L3	M6	2.5 to 3.0	AWG4
		B1, B2	M5	2.0 to 2.4	AWG14
		⊕	M5	2.0 to 2.4	AWG4
	22A3□	L1, L2, L3	M6	2.5 to 3.0	AWG3
		B1, B2	M5	2.0 to 2.4	AWG14
		⊕	M5	2.0 to 2.4	AWG4
	30A3□	L1, L2, L3	M6	2.5 to 3.0	AWG2
		B1, B2	M5	2.0 to 2.4	AWG14
		⊕	M6	2.5 to 3.0	AWG4
	37A3B	L1, L2, L3	M8	2.5 to 3.0	AWG1/0
		B1, B2	M5	2.0 to 2.4	AWG14
		⊕	M6	2.5 to 3.0	AWG2
	45A3B	L1, L2, L3	M10	30	AWG3/0
		B1, B2	M5	2.0 to 2.4	AWG14
		⊕	M6	2.5 to 3.0	AWG1/0
Three-phase, 400 VAC	15D3□	L1, L2, L3	M6	2.5 to 3.0	AWG8
		B1, B2	M5	2.0 to 2.4	AWG14
		⊕	M5	2.0 to 2.4	AWG7
	19D3□	L1, L2, L3	M6	2.5 to 3.0	AWG8
		B1, B2	M5	2.0 to 2.4	AWG14
		⊕	M5	2.0 to 2.4	AWG7
	22D3□	L1, L2, L3	M6	2.5 to 3.0	AWG7
		B1, B2	M5	2.0 to 2.4	AWG14
		⊕	M5	2.0 to 2.4	AWG7

■ SERVOPACK

Input Voltage	Model: CACR-JU	Terminal Symbols	Terminal Screw	Tightening Torque [N·m]	Wire Sizes
Three-phase, 200 VAC	028AEA	U, V, W	(connector)	–	AWG8
		motor ⊕	(connector)	–	AWG8
		⊕	M4	1.2 to 1.4	AWG8
	036AEA	U, V, W	(connector)	–	AWG8
		motor ⊕	(connector)	–	AWG8
		⊕	M4	1.2 to 1.4	AWG8
	065AEA	U, V, W	M6	2.5 to 3.0	AWG4 (AWG6)* ¹
		motor ⊕	M6	2.5 to 3.0	AWG4 (AWG6)* ¹
		⊕	M4	1.2 to 1.4	AWG4 (AWG6)* ¹
	084AEA	U, V, W	M6	2.5 to 3.0	AWG2
		motor ⊕	M6	2.5 to 3.0	AWG2
		⊕	M5	2.0 to 2.4	AWG4
	102AEA	U, V, W	M6	2.5 to 3.0	AWG1
		motor ⊕	M6	2.5 to 3.0	AWG1
		⊕	M5	2.0 to 2.4	AWG4
	125AEA	U, V, W	M8	2.5 to 3.0	AWG2/0
		motor ⊕	M8	2.5 to 3.0	AWG2/0
		⊕	M6	2.5 to 3.0	AWG2
196AEA	U, V, W	M10	30	AWG4/0	
	motor ⊕	M10	30	AWG4/0	
	⊕	M6	2.5 to 3.0	AWG1/0	
Three-phase, 400 VAC	014DEA	U, V, W	(connector)	–	AWG12
		motor ⊕	(connector)	–	AWG12
		⊕	M4	1.2 to 1.4	AWG12
	018DEA	U, V, W	(connector)	–	AWG10
		motor ⊕	(connector)	–	AWG10
		⊕	M4	1.2 to 1.4	AWG10
	033DEA	U, V, W	M6	2.5 to 3.0	AWG8 (AWG10)* ²
		motor ⊕	M6	2.5 to 3.0	AWG8 (AWG10)* ²
		⊕	M4	1.2 to 1.4	AWG8 (AWG10)* ²
	042DEA	U, V, W	M6	2.5 to 3.0	AWG6
		motor ⊕	M6	2.5 to 3.0	AWG6
		⊕	M5	2.0 to 2.4	AWG6
	051DEA	U, V, W	M6	2.5 to 3.0	AWG6
		motor ⊕	M6	2.5 to 3.0	AWG6
		⊕	M5	2.0 to 2.4	AWG6

*1. For motor model: UAK□J-11CZ (Input voltage: Three-phase 200 VAC)

*2. For motor model: UAK□J-11CZ (Input voltage: Three-phase 400 VAC)

(2) Installation of Molded-case Circuit Breaker (MCCB)

Make sure to connect MCCB between the power supply and the main circuit power supply input terminals R/L1, S/L2 and T/L3 to protect wiring.

(3) Installation of Ground Fault Interrupter

The output of the Σ -V-SD driver is switched at high speed, which results in high-frequency leakage current. When connecting a ground fault interrupter to the input terminals of the power regeneration converter, select an one designed for Σ -V-SD driver that eliminates the high-frequency leakage current and detects only the leakage current in frequency bands that are harmful to the human body.

- Use a ground fault interrupter designed for Σ -V-SD driver for each power regeneration converter, with a minimum sensing current of 30 mA.
- A standard ground fault interrupter can be used for each power regeneration converter provided that it has a minimum sensing current of 200 mA with a minimum response time of 0.1 s.

(4) Installation of Magnetic Contactor

When the main circuit power supply is shut OFF in the sequence, a magnetic contactor (MC) can be used instead of a molded-case circuit breaker (MCCB). However, when a magnetic contactor is switched OFF at the main circuit power supply input side, regenerative braking does not function and the motor coasts to a stop. (At this time, protective function activates to display a fault.)


Frequent turning ON and OFF the magnetic contactor for the main circuit power supply input may cause the Σ -V-SD driver to malfunction. Turn the magnetic contactor ON and OFF once every 30 minutes at most.

(5) Terminal Block Connection Sequence

Main circuit power supply input phases can be connected to any terminal regardless of the order of R/L1, S/L2 and T/L3 on the terminal block.

(6) Installation of Surge Absorber

For inductive loads (magnetic contactors, magnetic relays, magnetic valves, solenoids, magnetic brakes, etc.) connected near the Σ -V-SD driver, install a surge absorber.

 IMPORTANT	<p>A surge absorber is used to absorb energy accumulated in the coil of an inductive load. Use a surge absorber with a capacity suitable for the coil. Do not, however, connect surge absorbers to output terminals U, V, W of the SERVOPACK. If a surge absorber is not used, the generated surge voltage of the coil will affect the control signal line of the SERVOPACK when the inductive load is turn ON and OFF. As a result, the control signal may malfunction.</p>
---	--

(7) Prohibition of Installation of Phase Advancing Capacitor

Do not connect a phase advancing capacitor or surge absorber to main circuit power supply input (R/L1, S/L2, or T/L3) of a power regeneration converter. The phase advancing capacitor or surge absorber may become overheated and damaged by the harmonic components of the Σ -V-SD driver. Also, the Σ -V-SD driver may malfunction because of overcurrent.

(8) Designing the Power ON Sequence

Take the following points into consideration when designing the power ON sequence.

- The main circuit power supply must turn ON only after it has been confirmed that no servo alarm has occurred.
- The main circuit power supply must turn OFF when a servo alarm occurs during operation. The state of the motor must be considered when the main circuit power supply is turned OFF during operation. For details, refer to 5.2.1 (9) *Typical Main Circuit Wiring Example*.

(9) Typical Main Circuit Wiring Example

The typical main circuit wiring examples is shown below.


⚠ WARNING

- Do not touch the power terminals before the main-circuit capacitor has had time to discharge because high voltage may still remain in the converter and SERVOPACK. Refer to this section for the details of discharge time of main-circuit capacitor.
- Do not touch any terminals while the CHARGE lamp is lit.

There is a risk of electrical shock due to residual voltage.

First make sure the charge indicator is turned OFF and that the DC-bus (symbol: P and N) voltage value is correct by using a tester or other device before wiring or starting an inspection.

■ Three-phase 200 V, 400 V



1QF: Molded-case circuit breaker

1FIL: Noise filter

1KM: Magnetic contactor
(for control power supply)

2KM: Magnetic contactor
(for main circuit power supply)

3KM: Magnetic contactor
(for emergency stop)

1Ry: Relay

1PL: Indicator lamp
1SA: Surge absorber

2SA: Surge absorber

3SA: Surge absorber

4SA: Surge absorber

1D: Flywheel diode

*1. A host controller is not provided by Yaskawa.



*2. These are the signals of a host controller.

For emergency stop signal (ESP) of Σ -V-SD driver, refer to 6.1.3 (15) *Converter Emergency Stop Signal (ESP)*.

(10) Grounding

Use the following information to ensure that the ground is sufficient.

- Make sure to ground the ground terminal (⊕).
200 V class: Ground to 100 Ω or less
400 V class: Ground to 10 Ω or less
- Never ground the Σ -V-SD driver in common with welding machines, motors, or other large current electrical equipment. Wiring for grounding cable must be separated from the large-current electrical equipment.
- Always use a ground wire that complies with technical standards on electrical equipment. Minimize the length of the ground wire. Leakage current flows through the Σ -V-SD driver. Therefore, if the distance between the ground terminal and the ground terminal is too long, the potential on the ground terminal of the Σ -V-SD driver will become unstable.
- Always ground Σ -V-SD driver and motors using a ground terminal even when equipment is grounded through sill channel or steel plate.
- Ground each Σ -V-SD driver directly to the ground as shown in the following figure (a) of “Grounding.” Do not make a loop as shown in (b). Ground the Σ -V-SD driver and motor as shown in the following figure (a) of “Grounding of Motor and Σ -V-SD Driver.” Do not ground both the Σ -V-SD driver and motor as shown in (b).



5.2.2 Control Circuit Power Supply

(1) Specifications

■ Voltage

24 VDC \pm 15%

■ Current


• Power Regeneration Converter

Input Voltage	Model	Specification
Three-phase, 200 VAC	CACP-JU15A3□	1 A
	CACP-JU19A3□	
	CACP-JU22A3□	
	CACP-JU30A3□	
	CACP-JU37A3B	1.5 A
CACP-JU45A3B		
Three-phase, 400 VAC	CACP-JU15D3□	1 A
	CACP-JU19D3□	
	CACP-JU22D3□	

• SERVOPACK

Input Voltage	Model	Specification
270 VDC	CACR-JU028AEA	1.2 A
	CACR-JU036AEA	
	CACR-JU065AEA	
	CACR-JU084AEA	1.5 A
	CACR-JU102AEA	
	CACR-JU125AEA	
540 VDC	CACR-JU196AEA	2 A
	CACR-JU014DEA	1.2 A
	CACR-JU018DEA	
	CACR-JU033DEA	
	CACR-JU042DEA	1.5 A
CACR-JU051DEA		

(2) Connections



Pin No.	Signal Name	I/O	Function	Pin No.	Signal Name	I/O	Function
A	24 VDC	I/O	+24 VDC	B	0 V	I/O	0 V


CN7A/B		CN7A/B	
Pin No.	Signal Name	Pin No.	Signal Name
A	24 VDC	A	24 VDC
B	0 V	B	0 V

5.2.3 DC-bus


A bus bar built into the Σ -V-SD driver connects the power regeneration converter and a SERVOPACK or two SERVOPACKs.

The bus bar connection procedure is given below.

1. Remove the barriers between the devices to connect.



2. Rotate the bus bar of the device on the right 180° clockwise, and then hook it on the terminals of the device on the left.




5.2.4 Local Bus

A local bus communication cable connects the power regeneration converter (CN5) and SERVOPACK (CN5A and CN5B).


Connect the local bus connection cable to CN5A or CN5B on the SERVOPACK.

Only one spindle SERVOPACK can be connected to one converter.



5.2.5 I/O Signals

The connector numbers and connector pin arrangement are shown below.



(1) Connections

■ Connector Pin Arrangement (CN1) for I/O Signals of the Power Regeneration Converter

Pin No.	Signal Name	I/O	Function	Pin No.	Signal Name	I/O	Function
1	(NC)	–	–	8	(NC)	–	–
2	(NC)	–	–	9	(NC)	–	–
3	(NC)	–	–	10	(NC)	–	–
4	(NC)	–	–	11	ESP+	I	Emergency stop input
5	(NC)	–	–	12	ESP-	I	Emergency stop input
6	(NC)	–	–	13	(NC)	–	–
7	(NC)	–	–	14	(NC)	–	–

- Note 1. Do not use NC signal.
 2. Connect the shielded wires to the CN1 connector shell.

■ Connector Pin Arrangement (CN1) for I/O Signals of the SERVOPACK

Pin No.	Signal Name	I/O	Function	Pin No.	Signal Name	I/O	Function
1	+15V	–	+15 V output	26	FC0	O	Error code signal 0
2	(NC)	–	–	27	FC1	O	Error code signal 1
3	SCOM	I	Analog speed reference input	28	FC2	O	Error code signal 2
4	0V	–	Analog speed reference 0 V	29	FC3	O	Error code signal 3
5	/DAS	I	Speed reference digital/analog selection	30	COM2	–	Common for error code signal
6	/RDY	I	Operation ready signal	31	(NC)	–	–
	EMG2		Emergency stop signal 2				
7	EMG	I	Emergency stop signal	32	(NC)	–	–
8	/FWD	I	Forward signal	33	/ZSPD	O	Zero speed signal
9	/REV	I	Reverse signal	34	/AGR	O	Speed coincidence signal
10	/TLH	I	Torque limit signal H	35	/SDET	O	Speed detection signal
11	/TLL	I	Torque limit signal L	36	/TDET	O	Torque detection signal
	/INC		Incremental signal				
12	/SSC	I	Soft start cancel signal	37	/TLE	O	Torque limit signal
	/SV		Servo mode signal				
13	/RST	I	Error reset signal	38	/ORG	O	Load shaft origin signal
14	/CHW	I	Winding selection signal	39	/ORE	O	Orientation completed signal
15	/PPI	I	P control / PI signal selection signal	40	/CHWE	O	Winding selection completed signal
	/LM10		Load ratio meter 10 times change signal				
16	/ORT	I	Orientation signal	41	FLTL	O	Error signal (OFF for error)
17	/LGR	I	L gear selection signal	42	COM1	–	Sequence output signal common
18	/MGR	I	M gear selection signal	43	FLTNO	O	Error contact output (ON for error)
19	EXTCOM0	–	Common for power supply for sequence input signal	44	FLTNC	O	Error contact output (OFF for error)
20	EXTCOM0	–	Common for power supply for sequence input signal	45	FLTCOM	–	Error contact output common
21	EXTCOM0	–	Common for power supply for sequence input signal	46	/TALM	O	Minor failure signal
22	24VCOM	–	Power supply for sequence input signal 24 V	47	SM	O	Speed meter signal output
23	24VCOM	–	Power supply for sequence input signal 24 V	48	0V	–	Speed meter signal 0 V

Note 1. Do not use NC signal.

2. Connect the shielded wires to the CN1 connector shell.

(cont'd)

Pin No.	Signal Name	I/O	Function	Pin No.	Signal Name	I/O	Function
24	0 VCOM	–	Power supply for sequence input signal 0 V	49	0 V	–	Load ratio meter signal 0 V
25	0 VCOM	–	Power supply for sequence input signal 0 V	50	LM	O	Load ratio meter signal output

- Note 1. Do not use NC signal.
2. Connect the shielded wires to the CN1 connector shell.

Connector Pin Arrangement (CN2) for I/O Signals of the SERVOPACK

Pin No.	Signal Name	I/O	Function	Pin No.	Signal Name	I/O	Function
1	(NC)	–	–	19	D1	I	12-bit digital reference 1
2	(NC)	–	–	20	D2	I	12-bit digital reference 2
3	(NC)	–	–	21	D3	I	12-bit digital reference 3
4	(NC)	–	–	22	D4	I	12-bit digital reference 4
5	(NC)	–	–	23	D5	I	12-bit digital reference 5
6	(NC)	–	–	24	D6	I	12-bit digital reference 6
7	(NC)	–	–	25	D7	I	12-bit digital reference 7
8	(NC)	–	–	26	D8	I	12-bit digital reference 8
9	(NC)	–	–	27	D9	I	12-bit digital reference 9
10	(NC)	–	–	28	D10	I	12-bit digital reference 10
11	PCO	O	Motor encoder phase C signal output	29	D11	I	12-bit digital reference 11
12	/PCO	O		30	D12	I	12-bit digital reference 12
13	PAO	O	Motor encoder phase A signal output	31	EXTCOM	–	12-bit digital reference common
14	/PAO	O		32	24 VCOM	–	Power supply for 12- bit digital reference +24 V
15	PBO	O	Motor encoder phase B signal output	33	0 VCOM	–	Power supply for 12- bit digital reference 0 V
16	/PBO	O		34	(NC)	–	–
17	(NC)	–	–	35	(NC)	–	–
18	GND	–	Control ground	36	(NC)	–	–

- Note 1. Do not use NC signal.
2. Connect the shielded wires to the CN2 connector shell.

Connector Pin Arrangement (CN9) for I/O Signals of the SERVOPACK

Pin No.	Signal Name	I/O	Function	Pin No.	Signal Name	I/O	Function
1	PG0V	–	Power supply for encoder 0 V	11	(NC)	–	–
2	PG0V	–	Power supply for encoder 0 V	12	(NC)	–	–
3	PG0V	–	Power supply for encoder 0 V	13	(NC)	–	–
4	PG5V	O	Power supply for encoder +5 V	14	SPC	I	External encoder phase C input
5	PG5V	O	Power supply for encoder +5 V	15	/SPC	I	
6	PG5V	O	Power supply for encoder +5 V	16	SPA	I	External encoder phase A input
7	(NC)	–	–	17	/SPA	I	
8	(NC)	–	–	18	SPB	I	External encoder phase B input
9	(NC)	–	–	19	/SPB	I	
10	(NC)	–	–	20	(NC)	–	–

Note 1. Do not use NC signal.

2. Connect the shielded wires to the CN9 connector shell.

Connector Pin Arrangement (CN10) for I/O Signals of the SERVOPACK
(Orientation control with an external encoder)

Pin No.	Signal Name	I/O	Function	Pin No.	Signal Name	I/O	Function
1	(NC)	–	–	8	(NC)	–	–
2	SPCO	O	External encoder phase C signal output	9	(NC)	–	–
3	/SPCO	O	External encoder phase C signal output	10	(NC)	–	–
4	SPAO	O	External encoder phase A signal output	11	(NC)	–	–
5	/SPAO	O	External encoder phase A signal output	12	(NC)	–	–
6	SPBO	O	External encoder phase B signal output	13	(NC)	–	–
7	/SPBO	O	External encoder phase B signal output	14	(NC)	–	–

Note 1. Do not use NC signal.

2. Connect the shielded wires to the CN10 connector shell.

Connector Pin Arrangement (CN10) for I/O Signals of the SERVOPACK
(Orientation control with a magnetic sensor)

Pin No.	Signal Name	I/O	Function	Pin No.	Signal Name	I/O	Function
1	(NC)	–	–	8	(NC)	–	–
2	(NC)	–	–	9	(NC)	–	–
3	0V	–	Power supply for magnetic sensor 0 V	10	+12V	–	Power supply for magnetic sensor +12 V
4	(NC)	–	–	11	(NC)	–	–
5	0V	–	Power supply for magnetic sensor 0 V	12	+15V	–	Power supply for magnetic sensor +15 V
6	(NC)	–	–	13	SIG+	I	Magnetic sensor signal +
7	(NC)	–	–	14	SIG-	I	Magnetic sensor signal -


- Note 1. Do not use NC signal.
2. Connect the shielded wires to the CN10 connector shell.

Connector Pin Arrangement (CN12) for I/O Signals of the SERVOPACK


Pin No.	Signal Name	I/O	Function	Pin No.	Signal Name	I/O	Function
1	(NC)	–	–	2	(NC)	–	–
3	/HWBB1-	I	HWBB signal input 1	4	/HWBB1+	I	HWBB signal input 1
5	/HWBB2-	I	HWBB signal input 2	6	/HWBB2+	I	HWBB signal input 2
7	EDM1-	O	HWBB circuit status output	8	EDM1+	O	HWBB circuit status output

- Note 1. Do not use NC signal.
2. Connect the shielded wires to the CN12 connector shell.
3. If you do not use the HWBB function, attach the enclosed safety jumper connector to CN12.


(2) Connection Diagrams



SERVOPACK I/O Connection 1



SERVOPACK I/O Connection 2



Converter I/O Connection


(3) Sequence Input Signal Circuits

Consider the following conditions when you design the input signal circuits.


- You can use a 0-V common, +24-V common, or external common for the sequence input signals on CN1 and the 12-bit digital reference on CN2 of the SERVOPACK.
- If you select an external common, prepare a +24-V power supply for the input signals.
- The EXTCOM pins are isolated between CN1 and CN2.
- If you use relay contacts, a contact capacity of 30 V minimum and 5 mA minimum is required.

Signal Name	Pin No.	
	CN1	CN2
EXTCOM	19, 20, 21	31
24 VCOM	22, 23	32
0 VCOM	24, 25	33


■ 0-V Common



■ +24 V Common




■ External Common



(4) Sequence Output Signal Circuits

Consider the following conditions when you design the output signal circuits.

- You can use either a +24-V common or a 0-V common.
- The signal outputs are isolated with photocouplers. Prepare a +24-V power supply for the output signals.
- Do not exceed an output current of 50 mA.
- If you turn external relays or other inductive loads ON and OFF, always connect a spark killer in parallel with the load. The maximum input voltage to the output circuits is 30 V. If you apply a voltage that exceeds the maximum input voltage, the photocoupler in the output circuit may be destroyed.
- For a capacitive load, the current is restricted. Connect a protective resistor in series with the load. If there is no protective resistor, an overcurrent will flow when the photocoupler is driven, and the element may be destroyed.
- An output circuit connection example for a +24-V common is given below.




(5) Analog Input Circuit

This section describes pins 1, 3, and 4 (speed reference input) on the CN1 connector.

The analog signals are used as the speed reference or torque reference signals. The input impedance is given below.

The maximum input voltage of the input circuit is ± 12 V.




* This wiring example is for a positive voltage input. However, the motor speed may not increase for input voltages that exceed +12 V.
If the internal power supply is used, select a resistor so that the output current is 10 mA or less.



IMPORTANT

- Connect the shielded wires on the I/O signal cables to the connector shells on the SERVOPACK and converter, and also ground the shielded wires at the host controller. Do not use I/O signal cables that exceed 3 m. If the cables are too long, external noise may prevent normal operation.
- Keep the main circuit cable and I/O signal cables at least 30 cm away from each other. Malfunction may result due to noise if these cables are too close to each other.

Prepare the shield at the ends of the I/O signal cables as shown in the following figure.



Control Signals

6.1	Sequence Input Signals	6-2
6.1.1	Sequence Input Signals	6-2
6.1.2	Status Display of Sequence Input Signals	6-3
6.1.3	Details on Sequence Input Signals	6-5
6.2	Analog Speed Reference	6-19
6.3	12-bit Digital Speed Reference	6-22
6.4	Sequence Output Signals	6-26
6.4.1	Sequence Output Signals	6-26
6.4.2	Status Display of Sequence Output Signals	6-27
6.4.3	Details on Sequence Output Signals	6-28
6.5	Speed Meter Signal Output (SM)	6-40
6.6	Load Ratio Meter Signal Output	6-41
6.7	Encoder Pulse Input Circuit	6-42
6.8	Encoder Pulse Output Circuit	6-43

6.1 Sequence Input Signals

This section lists the sequence input signals and provides details on the status indications and signals.

6.1.1 Sequence Input Signals

Input signals are input on the CN1 and CN3 connectors on the SERVOPACK and on the CN1 connector on the Power Regeneration Converter. The sequence input signals are listed below.

(1) Input Signals on SERVOPACK CN1 Connector

CN1 Connector Pin No.	Signal Name	Function	Related Parameters
5	/DAS	Speed reference digital/analog change signal	Pn850.0 (12-bit Digital Reference Signal Selection) Pn850.1 (Digital Speed Reference Selection)
6	/RDY	Operation ready signal	Pn82B.0 (RDY/EMG2 Selection)
	EMG2	Emergency stop signal 2	Pn406 (Emergency Stop Torque) Pn630 (Emergency Stop Execution Delay Time) Pn632 (Emergency Stop Fault Detection Time) Pn82B.0 (RDY/EMG2 Selection)
7	EMG	Emergency stop signal	Pn406 (Emergency Stop Torque) Pn630 (Emergency Stop Execution Delay Time) Pn632 (Emergency Stop Fault Detection Time)
8	/FWD	Forward signal	Pn031.0 (Analog Speed Reference Input Selection)
9	/REV	Reverse signal	Pn031.1 (Speed Limit Selection) Pn300 (Speed Reference Input Gain 1) Pn30A (Speed Reference Input Gain 2) Pn541 (Rated Speed Setting) Pn800 (For/Rev Signal Acceleration Constant) Pn802 (For/Rev Signal Deceleration Constant) Pn900 (Acceleration Basic Unit Selection)
10	/TLH	Torque limit signal H	Pn82A.1 (TLH Selection) Pn82A.0 (TLL/INC Selection)
11	/TLL	Torque limit signal L	Pn805 (External Low-torque Limit Level) Pn806 (External High-torque Limit Level) Pn807.0 (Torque Limit Auto Judgement)
	/INC	Incremental signal	Pn82A.0 (TLL/INC Selection)
12	/SSC	Soft start cancel signal	Pn82A.2 (SSC/SV Selection)
	/SV	Servo mode signal	Pn031.0 (Analog Speed Reference Input Selection) Pn031.2 (Speed Reference Gain Selection at Servo Mode) Pn300 (Speed Reference Input Gain 1) Pn30A (Speed Reference Input Gain 2) Pn432 (Motor Flux Lower Limit Level) Pn433 (Servo Mode Flux Level (High Speed Winding)) Pn434 (Servo Mode Base Speed Ratio (High Speed Winding)) Pn435 (Servo Mode Flux Level (Low Speed Winding)) Pn436 (Servo Mode Base Speed Ratio (Low Speed Winding)) Pn43D (Servo Mode Speed Reference Gain 1) Pn541 (Rated Speed Setting) Pn82A.2 (SSC/SV Selection)
13	/RST	Error reset signal	–
14	/CHW	Winding selection signal	Pn01E.1 (Select Winding Selection Method)
15	/PPI	P control / PI control selection signal	Pn82A.3 (PPI/LM10 Selection)
	/LM10	Load ratio meter 10 times change signal	Pn82A.3 (PPI/LM10 Selection)

(cont'd)

CN1 Connector Pin No.	Signal Name	Function	Related Parameters
16	/ORT	Orientation signal	Pn812 (Orientation Target Speed) Pn813 (Orientation Acceleration Constant) Pn815 (Orientation Deceleration Constant) Pn817 (The Amount of Reference Unit per Revolution of Machine) Pn900 (Acceleration Basic Unit Selection)
17	/LGR	L gear selection signal	–
18	/MGR	M gear selection signal	–

(2) Input Signals on SERVOPACK CN3 Connector

CN3 Connector Pin No.	Signal Name	Function	Related Parameter
12, 13	CA1, CA2	Answer from winding selection device	Pn01E.1 (Winding Selection)

(3) Input Signals on Power Regeneration Converter CN1 Connector


CN1 Connector Pin No.	Signal Name	Function	Related Parameters
11, 12	ESP+, ESP-	Converter emergency stop signal	Pn01B.0 (Emergency Stop Signal Selection) Pn406 (Emergency Stop Torque) Pn630 (Emergency Stop Execution Delay Time) Pn632 (Emergency Stop Fault Detection Time)

6.1.2 Status Display of Sequence Input Signals

The status of the input signals can be checked with the input signal monitor (Un005), the input signal monitor 2 (Un033) or the input signal monitor 3 (Un035) from the Digital Operator. The status of the input signal monitor (Un005), the input signal monitor 2 (Un033) and the input signal monitor 3 (Un035) are displayed as shown in the following figure. The top row indicates signals that are OFF (high level) and the bottom row indicates signals that are ON (low level). For details, refer to 13.3 *Monitor Mode (Un□□□□)*.

(1) Input Signal Monitor (Un005)

Un005 shows the status of the SERVOPACK input signals.


Un005 = 
 Digit 8 7 6 5 4 3 2 1

Digit Number	Signal Name (Function)
1	/FWD (forward signal)
2	/REV (reverse signal)
3	/SSC (soft start cancel signal) or /SV (servo mode signal)
4	/RST (error reset signal)
5	/CHW (winding selection signal)
6	/ORT (orientation signal)
7	/RDY (operation ready signal) or EMG2 (emergency stop signal 2)
8	EMG (emergency stop signal)

Refer to *Chapter 13 Digital Operator* for the procedure on the Digital Operator.

(2) Input Signal Monitor 2 (Un033)

Un033 shows the status of the SERVOPACK input signals.




Digit Number	Signal Name (Function)
1	/TLH (torque limit signal H)
2	/TLL (torque limit signal L) or /INC (incremental signal)
3	/PPI (P control/ PI control selection signal) or /LM10 (load ratio meter 10 times change signal)
4	/LGR (L gear selection signal)
5	/MGR (M gear selection signal)
6	/DAS (speed reference digital analog selection)
7	–
8	–

Refer to *Chapter 13 Digital Operator* for the procedure on the Digital Operator.

(3) Input Signal Monitor 3 (Un035)

Un035 shows the status of the SERVOPACK and the Power Regeneration Converter input signals.



Digit Number	Signal Name (Function)
1*	/HWBB□ (hard wire base block signal)
2	CA1, CA2 (answer from winding selectors)
3	ESP+, ESP- (converter emergency stop signal)
4	–
5	–
6	–
7	–
8	–

* The HWBB has two channels. If either channel is OFF, the display will show OFF. Refer to *Chapter 13 Digital Operator* for the procedure on the Digital Operator.

6.1.3 Details on Sequence Input Signals

This section provides information on each signal of sequence input.

(1) Speed Reference Digital/Analog Select Signal (/DAS)

The /DAS signal is used to select either an analog input (10 V/100%) or a digital input for the speed reference.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	/DAS	CN1-5	ON (closed)	Digital input is selected.
			OFF (open)	Analog input is selected.

■ Related Parameter

Parameter No.	Description	When Enabled	Classification	
Pn850	n.□□□0 [Factory Setting]	Digital speed reference	After restart	Setup
	n.□□□1	Orientation control stop position reference		

* When Pn850.0 is set to 0, the setting of Pn850.1 is used.

When Pn850.0 is set to 1, the setting of Pn850.2 is used.

For details on the Pn850.0 = 1, refer to *Chapter 8 Orientation Control with a Motor Encoder*, *Chapter 9 Orientation Control with an External Encoder*, and *Chapter 10 Orientation Control with a Magnetic Sensor*.

Parameter No.	Description	When Enabled	Classification	
Pn850	n.□□0□ [Factory Setting]	12-bit binary	After restart	Setup
	n.□□1□	3-digit BCD		
	n.□□2□	2-digit BCD		
	n.□□3□	Internal speed setting		

■ Precautions on Signals

- If pin 5 on CN1 is OFF, an analog input is selected.
- If pin 5 on CN1 is ON, a digital input is selected.
- If the /DAS signal is OFF, an analog speed reference is selected. If it is ON, a digital speed reference is selected.
- Changing the type of signal with the /DAS signal is effective only when the motor is stopped (when the /RDY signal is OFF or when operation, e.g., with the /FWD or other signals, is not possible due to an emergency stop or other reason).
- You can select one of the following methods for a digital speed reference.
 - 12-bit binary (factory setting)
 - 3-digit BCD
 - 2-digit BCD
 - Internal speed settings
- You can select the method with Pn850.1 (Digital Speed Reference Selection). For details on a digital speed reference, refer to *6.3 12-bit Digital Speed Reference*.

(2) Ready Signal (/RDY)

The ready signal (/RDY) is necessary for the /FWD, /REV, and /ORT signals.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	/RDY	CN1-6	ON (closed)	Operation ready
			OFF (open)	Forced gate block

■ Related Parameters

Parameter No.	Description	When Enabled	Classification
Pn82B	n.□□□0 [Factory Setting]	/RDY allocation	After restart Setup
	n.□□□1	EMG2 allocation	

■ Precautions on Signal

- If Pn82B.0 is set to 0, pin 6 on CN1 is the /RDY signal.
- If the /RDY signal turns OFF during operation, the gate is blocked immediately and the motor decelerates to a stop.
- If you turn OFF the /RDY signal, you must also turn OFF the /FWD, /REV, and /ORT signals before you can restart operation.
- If you will not use the /RDY signal, keep it ON all the time. (If you selected a 0-V common input or +24-V common input, connect pin 6 to pin 24. If you selected an external common input, externally keep the /RDY signal ON all the time.)

(3) Emergency Stop Signal (EMG) and Emergency Stop Signal 2 (EMG2)

The EMG and EMG2 signals are used to perform an emergency stop of the spindle motor. After the emergency stop waiting time elapses, the spindle motor decelerates to a stop. After the motor stops, the servo is turned OFF.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	EMG	CN1-7	ON (closed)	Emergency stop is released (when EMG2 is set to ON).
			OFF (open)	Emergency stop
Input	EMG2	CN1-6	ON (closed)	Emergency stop is released (when EMG is set to ON).
			OFF (open)	Emergency stop

■ Related Parameters

Parameter No.	Description	When Enabled	Classification
Pn82B	n.□□□0 [Factory Setting]	/RDY allocation	After restart Setup
	n.□□□1	EMG2 allocation	

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn406	Emergency Stop Torque	0 to 800	1%	800	Immediately	Setup
Pn630	Emergency Stop Execution Delay Time	0 to 10000	1 ms	0	Immediately	Setup
Pn632	Emergency Stop Fault Detection Time	0 to 65535	1 ms	10000	Immediately	Setup

■ Precautions on Signals

• EMG Signal

- If the EMG signal turns OFF during operation, the motor is stopped quickly with regenerative braking and the current is turned OFF. If the spindle motor does not stop within the time set in Pn632 after the EMG signal turns OFF, an A.680 alarm (Emergency Stop Failure) will occur and the motor will coast to a stop.
- During an emergency stop, the settings of Pn800 (Forward/Reverse Signal Acceleration Constant) and Pn802 (Forward/Reverse Signal Deceleration Constant) are disabled. A deceleration stop is performed with the torque set in Pn406 (Emergency Stop Torque).
- After the EMG signal turns OFF, you cannot start operation again even if you turn ON the EMG signal unless the /FWD, /REV, and /ORT signals that are ON are turned OFF.
- If the main power supply is turned OFF with the magnetic contactor on the converter's input during deceleration for an emergency stop, the motor will coast to a stop. At this time, the low main circuit voltage protective function or another protective function will be activated and an error will be displayed.
- To prevent coasting to a stop when an emergency stop turns OFF the main circuit power supply, use an OFF-delay circuit or other means to delay turning OFF the main circuit power supply.
- If you will not use the EMG signal, keep it ON all the time. (If you selected a 0-V common input or +24-V common input, connect pin 7 to pin 19. If you selected an external common input, externally keep the EMG signal ON all the time.)

• EMG2 Signal

- If Pn82B.0 is set to 1, pin 6 on CN1 is the EMG2 signal.
- The function of the EMG2 signal is the same as the function of the EMG signal (emergency stop signal). Refer to information on the EMG signal for details.
- If you use the EMG2 signal, you will have two emergency stop signals including the EMG signal.
- An emergency stop is performed if either the EMG or EMG2 signal turns OFF.
- To cancel the emergency stop operation and enable normal operation, turn ON both the EMG and EMG2 signals.

• ESP Signal

- If you set Pn01B.0 to 1 to enable the emergency stop signal, the ESP signal (converter emergency stop signal) is also enabled, giving you a total of three emergency stop signals (EMG, EMG2, and ESP). Refer to 6.1.3 (15) *Converter Emergency Stop Signal (ESP)* for details. To cancel the emergency stop operation and enable operation, turn ON the EMG, EMG2, and ESP signals.

(4) Forward Signal and Reverse Signal (/FWD, /REV)

The /FWD and the /REV signals determine the rotation direction of the spindle motor.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	/FWD	CN1-8	ON (closed)	The spindle motor can perform forward operation.
			OFF (open)	The spindle motor is stopped.
	/REV	CN1-9	ON (closed)	The spindle motor can perform reverse operation.
			OFF (open)	The spindle motor is stopped.

■ Related Parameters

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn031	Application Function Select Switch 31	0000 to 0111	–	0001	After restart	Setup
Pn300	Speed Reference Input Gain 1	50 to 3000	0.01 V/ Base speed	600	Immediately	Setup
Pn30A	Speed Reference Input Gain 2	500 to 30000	0.001 V	10000	Immediately	Setup
Pn541	Rated Speed Setting	100 to 65535	1 min ⁻¹	65535	After restart	Setup
Pn800	Forward/Reverse Signal Acceleration Constant	1 to 4294967295	10 ⁿ pulse/s ²	100	Immediately	Setup
Pn802	Forward/Reverse Signal Deceleration Constant	1 to 4294967295	10 ⁿ pulse/s ²	100	Immediately	Setup
Pn804	Zero-Speed Braking Time	0 to 100	1 s	0	After restart	Setup
Pn900	Acceleration Basic Unit Selection	0003 to 0006	–	0004	After Restart	Setup

■ Spindle Motor Rotation Direction

The rotation direction of the spindle motor depends on the combination of the /FWD signal, the /REV signal, and the polarity of the speed reference voltage (SCOM).

Polarity of Speed Reference Voltage (SCOM)		+	–
Operation Signals	/FWD signal ON	CCW (forward)	CW (reverse)
	/REV signal ON	CW (reverse)	CCW (forward)

For details on the speed reference voltage (SCOM), refer to 6.2 *Analog Speed Reference*.

■ Stopping the Spindle Motor

If the /FWD or /REV signal turns OFF while the spindle motor is operating, the spindle motor will stop due to regenerative braking. When the speed of the motor reaches zero, a base block is implemented after the time set in Pn804 elapses and the current to the spindle motor is turned OFF.

■ Setting of Forward/Reverse Signal Acceleration/Deceleration Constant

To adjust the acceleration time from a stopped condition to the rated speed and the deceleration time until the spindle motor stops from the rated speed, change the set values of the following parameters.

- Pn800 (Forward/Reverse Signal Acceleration Constant)
- Pn802 (Forward/Reverse Signal Deceleration Constant)

These parameters set the rate of acceleration and the rate of deceleration. They do not set the times directly.

The settings of Pn800 and Pn802 are disabled while the /SSC signal is ON and the STEP input is used for the speed reference.

<Supplementary Note>

Set 0 to Pn305 (Soft Start Acceleration Time) and Pn306 (Soft Start Deceleration Time).

Parameter Setting Example

The Forward/Reverse Signal Acceleration Constant (Pn800) is calculated as given below to accelerate the spindle motor to the maximum speed of $10,000 \text{ min}^{-1}$ in 5 seconds.

Forward/Reverse Signal Acceleration Constant = $(10,000 [\text{m}^{-1}] \times 4,096 [\text{pulses}] \div 60 [\text{s}] \div 5 [\text{s}]) = 136,533 [\text{pulses/s}^2]$

The setting unit for Pn800 is 10^4 pulses/s^2 (default setting of Pn900 is 4), so set Pn800 to 14. To increase the precision of the setting, set Pn900 to 3 to change the setting unit for Pn800 to 10^3 pulse/s^2 and then set Pn800 to 137.


This is the same as for the setting of the Forward/Reverse Signal Deceleration Constant (Pn802).

■ Precautions on Signals

- The spindle motor will stop if both the /FWD signal and the /REV signal are ON simultaneously. Operation will restart if either signal then turns OFF. Take suitable precautions. For details on signal combinations and the motor operation status, refer to *11.2.3 (1) Stopping Method for Spindle Motor after SV_OFF Command is Received*.
- The spindle motor will operate according to the speed reference if the /FWD signal or /REV signal turns ON. Always set the speed reference before starting operation.



- If an error occurs during operation, a base block is immediately implemented for the spindle motor and the current to the spindle motor is turned OFF.
- Before you turn ON the power supply, turn OFF both the /FWD signal and /REV signal. If the power supply is turned ON when either of these signals is ON, the spindle motor will not be able to operate.
- Wait at least 15 ms after the EMG signal, EMG2 signal, ESP signal, or /RDY signal turns ON before you turn ON the /FWD signal or /REV signal. The signal will not be accepted if either of these signals is turned ON before the EMG signal, EMG2 signal, ESP signal, or /RDY signal.



(5) Torque Limit Signal H/L (/TLH, /TLL)

The torque limit signals are used to limit the torque temporarily during the operation.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	/TLH	CN1-10	ON (closed)	Limits high-torque.
			OFF (open)	Normal operation (without torque limit)
	/TLL	CN1-11	ON (closed)	Limits low-torque.
			OFF (open)	Normal operation (without torque limit)

■ Related Parameters

Parameter No.	Description	When Enabled	Classification
Pn82A	n.□□□0 [Factory Setting]	/TLL Allocation	After restart Setup
	n.□□□1	/INC Allocation	
	n.□□□2	No allocation	

Parameter No.	Description	When Enabled	Classification
Pn82A	n.□□0□ [Factory Setting]	/TLH Allocation	After restart Setup
	n.□□1□	No allocation	

Parameter No.	Description	When Enabled	Classification
Pn807	n.□□□0 [Factory Setting]	Without torque limit auto judgement	After restart Setup
	n.□□□1	With torque limit auto judgement	

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn805	External Low-Torque Limit Level	0 to 800	1%	5	Immediately	Setup
Pn806	External High-Torque Limit Level	0 to 800	1%	10	Immediately	Setup

■ Precautions on Signals

- If Pn82A.1 is set to 0, pin 10 on CN1 is the /TLH signal.
- If pin 10 on CN1 turns ON, the /TLH signal function operates.
- When the /TLH signal is input, the torque limit that is set in Pn806 (External High-Torque Limit Level) is used.
- If Pn82A.0 is set to 0, pin 11 on CN1 is the /TLL signal.
- If pin 11 on CN1 turns ON, the /TLL signal function operates.
- When the /TLL signal is input, the torque limit that is set in Pn805 (External Low-Torque Limit Level) is used.
- The torque is limited while the /TLH signal or /TLL signal is ON. While the torque is limited, the /TLE signal (torque limited signal) is output.
- If both the /TLH signal and the /TLL signal are ON at the same time, the /TLL signal is given priority.
- The torque limit is valid while the motor is operating.
- These torque limits are disabled during emergency stops because priority is given to Pn406 (Emergency Stop Torque).
- If the value of Pn805 (External Low-Torque Limit Level) is larger than the value of Pn806 (External High-Torque Limit Level), the torque limit is clamped to the value set in Pn806.
- If Pn807.0 is set to 1 (Torque Limit Auto Judgement = Judged) and the motor operates at a constant speed when the /SV signal is OFF and the high-speed winding (single winding) is selected, the torque is automatically limited. The torque limit that is set in Pn805 (External Low-Torque Limit Level) is used.

- If Pn807.0 is set to 1 (Torque Limit Auto Judgement = Judged) and the /SV signal ON, the settings of Pn805 (External Low-Torque Limit Level) and Pn806 (External High-Torque Limit Level) are used.
- If you will not use the /TLH signal or /TLL signal, keep pin 10 or pin 11 turned OFF.

(6) Incremental Signal (/INC)

The /INC signal is used to perform incremental operation during orientation control.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	/INC	CN1-11	ON (closed)	Requests incremental positioning.
			OFF (open)	Normal operation (requests absolute orientation.)

■ Related Parameter

Parameter No.	Description	When Enabled	Classification
Pn82A	n.□□□0 [Factory Setting]	/TLL Allocation	After restart Setup
	n.□□□1	/INC Allocation	
	n.□□□2	No allocation	

■ Precautions on Signals

- If Pn82A.0 is set to 1, pin 11 on CN1 is the /INC signal.
- If pin 11 on CN1 turns ON, the /INC signal function operates.
- The /INC signal is valid only when it is input simultaneously with or before the /ORT signal.
- An INC Signal Error (A.98A) will occur if the /INC signal is ON when the power supply is turned ON or if it is turned ON without first executing absolute positioning. (The absolute positioning completed information is cleared if the motor is operated at 50 nmin^{-1} or higher.)
- An INC Signal Error (A.98A) will occur if the /INC signal is input when the motor is operating at 30 min^{-1} or faster.

(7) Soft Start Cancel Signal (/SSC)

This signal is used to cancel a soft start (Pn800 (Forward/Reverse Signal Acceleration Constant) and Pn802 (Forward/Reverse Signal Deceleration Constant)) to follow a reference speed, e.g., for jogging, without falling behind the speed reference.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	/SSC	CN1-12	ON (closed)	Cancels soft start.
			OFF (open)	Normal operation (does not cancel soft start.)

■ Related Parameter

Parameter No.	Description	When Enabled	Classification
Pn82A	n.□0□□ [Factory Setting]	/SSC Allocation	After restart Setup
	n.□1□□	/SV Allocation	

■ Precautions on Signals

- If Pn82A.2 is set to 0, pin 12 on CN1 is the /SSC signal.
- When the /SSC signal turns ON, acceleration is performed as quickly as possible with current-limiting acceleration/deceleration. The settings of Pn800 (Forward/Reverse Signal Acceleration Constant) and Pn802 (Forward/Reverse Signal Deceleration Constant) are ignored.
- If you will not use the /SSC signal, keep it OFF all the time.

(8) Servo Mode Signal (/SV)

When Pn82A.2 is set to 1, pin 12 on CN1 is the /SV signal.

The /SV signal serves as a command to change to servo mode.

When the /SV signal turns ON, servo mode is entered and the speed loop gain and other values are changed to the parameters for servo mode.

Refer to 16.1 *Operation Modes and Applicable Parameters* for the parameters that change for the /SV signal.

Servo Mode: Establishes and maintains feed linearity and continuously provides excitation current, even when the motor is stopped. It is used to preserve the control loop response and to increase the constraint when the motor is stopped, in the same way as a servo.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	/SV	CN1-12	ON (closed)	Requests to change to servo mode.
			OFF (open)	Standard mode (normal operation)


■ Related Parameters

Parameter No.		Description	When Enabled		Classification
Pn82A	n.□□□□ [Factory Setting]	/SSC allocation	After restart		Setup
	n.□1□□	/SV allocation			

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn432	Motor Flux Lower Level	10 to 100	1%	15	Immediately	Setup
Pn433	Servo Mode Flux Level for High-speed Winding	30 to 100	1%	100	Immediately	Setup
Pn434	Servo Mode Base Speed Ratio for High-speed Winding	100 to 500	1%	100	Immediately	Setup
Pn435	Servo Mode Flux Level for Low-speed Winding	30 to 100	1%	100	Immediately	Setup
Pn436	Servo Mode Base Speed Ratio for Low-speed Winding	100 to 500	1%	100	Immediately	Setup

These parameters are used to increase the rated torque control range, such as for tapping. As shown in the following diagram, set them according to the relationship between the flux levels (Pn433 and Pn435) and the

base speed ratios (Pn434 and Pn436).



Parameter No.	Description	When Enabled	Classification
Pn031	n.□□□0	After restart	Setup
	n.□□□1 [Factory Setting]		
	n.□0□□ [Factory Setting]		
	n.□1□□		

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn300	Speed Reference Input Gain 1	50 to 3000	0.01 V/ Base speed	600	Immediately	Setup
Pn30A	Speed Reference Input Gain 2	500 to 30000	0.001 V	10000	Immediately	Setup
Pn43D	Servo Mode Speed Reference Gain 1	0 to 10000	0.01%	10000	After restart	Setup
Pn43E	Servo Mode Speed Reference Gain 2	0 to 10000	0.01%	10000	After restart	Setup
Pn541	Rated Speed Setting	100 to 65535	1 min ⁻¹	65535	After restart	Setup

In servo mode, use Pn031 to set a factor to multiply with the base speed for analog speed references.

- When the /DAS Signal is OFF

The setting of Pn43D (Servo Mode Speed Reference Gain 1) is enabled.

To use servo mode speed reference gain 1, set Pn031.2 to 1 (switch speed reference gain). If you set Pn43D (Servo Mode Speed Reference Gain 1) to 0, the motor will not operate.

- When Pn031.0 = 0

The speed reference is determined from the spindle motor base speed for high-speed winding and the setting of Pn300.

$$\text{Analog speed reference} = (\text{Setting of Pn300}) / (\text{Base speed} \times \text{Pn43D} / 100) \text{ min}^{-1}$$

- When Pn031.0 = 1

The speed reference is determined from the spindle motor base speed for high-speed winding and the setting of Pn30A.

$$\text{Analog speed reference} = (\text{Setting of Pn30A}) / (\text{Rated speed} \times \text{Pn43D} / 100) \text{ min}^{-1}$$

- When the /DAS Signal is ON

The setting of Pn43E (Servo Mode Speed Reference Gain 2) is enabled.

To use servo mode speed reference gain 1, set Pn031.2 to 1 (switch speed reference gain). If you set Pn43E (Servo Mode Speed Reference Gain 2) to 0, the motor will not operate.

- The speed reference is determined from the spindle motor base speed for high-speed winding and the setting of Pn300.

$$\text{Analog speed reference} = (\text{Setting of Pn300}) / (\text{Base speed} \times \text{Pn43E}/100) \text{ min}^{-1}$$

- When Pn031.0 = 1

The speed reference is determined from the spindle motor base speed for high-speed winding and the setting of Pn30A.

$$\text{Analog speed reference} = (\text{Setting of Pn30A}) / (\text{Rated speed} \times \text{Pn43E}/100) \text{ min}^{-1}$$

■ Precautions on Signals

- If /SV signal is ON, the soft start that is set with Pn800 (Forward/Reverse Signal Acceleration Constant) and Pn802 (Forward/Reverse Signal Deceleration Constant) is canceled.
- If /ORT signal is ON, servo mode is used regardless of the signal specifications.
- If you create a position loop with the servo drive (spindle motor) and change to the position loop to perform tapping, use servo mode. To achieve a 100% excitation current, provide a delay of 200 to 300 ms. (Set this time on a timer in the host controller.)
If a position reference is received during this time, accurate operation will not be possible and vibration will occur.
- When feeding the spindle, e.g., for tapping, the tapping command is sent 200 to 300 ms after changing to /SV signal. Therefore, to continue tapping, a continuous command is used without turning /SV signal ON and OFF.

(9) Fault Reset Signal (/RST)


The /RST signal is used to reset the system after the protective circuit operates for overload protection and the probable cause is eliminated.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	/RST	CN1-13	ON (closed)	The errors are reset.
			OFF (open)	The errors are not reset.

■ Precautions on Signals

- The /RST signal is enabled only after the protective circuit operates.
- The errors cannot be reset with the /RST signal while the /FWD, /REV, or /ORT signal is ON.
- The ALARM RESET switch on the Digital Operator has the same function as the /RST signal except that it can be used to reset errors when the /FWD, /REV, or /ORT signal is ON. However, to restart operation, the /FWD, /REV, and /ORT signals must all be turned OFF first.
- The reset operation is performed when the /RST signal turns OFF after turning ON. Always turn OFF the /RST signal after you turn it ON.
- In the protective circuit sequence, errors take priority. The following figure shows a timing chart for the reset operation.



(10) Winding Selection Signal (/CHW)

The /CHW signal serves as a command to select the winding when using motor winding selection control. The winding can be selected even during operation.

■ Signal Specifications


Type	Signal Name	Pin No.	Output Status	Meaning
Input	/CHW	CN1-14	ON (closed)	Selects the low-speed winding.
			OFF (open)	Selects the high-speed winding.

■ Related Parameter

Parameter No.	Description	When Enabled	Classification
Pn01E	n.□□0□ [Factory setting]	—	After restart Setup
	n.□□1□	Mechanical winding selection	

■ Precautions on Signals

- After the /CHW signal is turned ON to select the winding, a base block will be maintained until the winding is actually changed. If this status continues for more than the preset time, a winding selection fault (A.690) will result and the spindle motor will stop.
- If the winding does not agree with the /CHW signal when the power supply is turned ON, the winding will be changed so that it agrees with the /CHW signal.



- When you turn ON the control power supply, check to make sure that switching the contacts in the winding selection device operates normally. Confirm that you can hear the sound of the contacts switching in the winding selection device.
- The windings are not changed in the following cases.
 - During position control
 - When the spindle motor speed exceeds the maximum speed of the low-speed winding when switching from the high-speed to the low-speed winding.
 - When there is an alarm (However, the winding is changed automatically under certain conditions when an alarm occurs.)
 - During a zero speed stop

(11) P/PI Control Selection Signal (/PPI)

This signal is used to change between proportional control and proportional-integral control for a speed controller.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	/PPI	CN1-15	ON (closed)	P control
			OFF (open)	PI control

■ Related Parameter

Parameter No.	Description	When Enabled	Classification
Pn82A	n.0□□□ [Factory Setting]	/PPI allocation	After restart Setup
	n.1□□□	/LM10 allocation	

■ Precautions on Signals

- If Pn82A.3 is set to 0, pin 15 on CN1 is the /PPI signal.
- If pin 15 on CN1 is ON, proportional control operates.
- If pin 15 on CN1 is OFF, proportional-integral control operates.
- When the /PPI signal turns ON, the speed controller changes to proportional control regardless of the operating status.
- If you will not use proportional control, keep pin 15 OFF all the time. (Proportional-integral control will always be used.)

(12) Load Ratio Meter Times Ten Selection Signal (/LM10)

The /LM10 signal is used to increase the sensitivity of the load ratio meter by a factor of 10 to improve the signal-to-noise ratio for light loads.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	/LM10	CN1-15	ON (closed)	Decouples the sensitivity of the load ratio meter.
			OFF (open)	Normal operation

■ Related Parameter

Parameter No.		Description	When Enabled	Classification
Pn82A	n.0□□□ [Factory Setting]	/PPI Allocation	After restart	Setup
	n.1□□□	/LM10 Allocation		

■ Precautions on Signals

- If Pn82A.3 is set to 1, pin 15 on CN1 is the /LM10 signal.
- If pin 15 on CN1 is ON, the sensitivity of the load ratio meter is decoupled.
- Refer to 6.6 *Load Ratio Meter Signal Output* for details on the related parameters.

(13) Orientation Signal (/ORT)

The /ORT signal serves as a command to start the orientation operation. The orientation operation causes the load shaft to promptly move to the preset position.

When the /ORT signal turns ON, orientation mode is entered and the speed loop gain and other values are changed to the parameters for orientation.


Refer to 16.1 *Operation Modes and Applicable Parameters* for the parameters that change for the /ORT signal.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	/ORT	CN1-16	ON (closed)	Starts orientation mode and the orientation operation.
			OFF (open)	Speed control mode

■ Precautions on Signals

- Turn OFF the /ORT signal after completing tool or workpiece replacement for positioning.
- To perform an emergency stop during orientation, turn OFF the /ORT signal. Operation cannot be restarted after the emergency stop if the /ORT signal is ON.
- Make sure that the /ORT signal is OFF when the power supply is turned ON. Operation cannot be restarted if the /ORT signal is ON.
- Keep CN1-16 turned OFF if the ORT signal is not used.
- Do not perform winding selection during orientation. You cannot perform winding selection with the speed which is under the orientation target speed.
- Wait at least 15 ms after the /RDY, EMG, EMG2, and ESP signals turn ON before you turn ON the /ORT signal. The signal will not be accepted if this signal is input before the /RDY, EMG, EMG2, and ESP signals.



(14) M Gear/L Gear Selection Signal (/MGR, /LGR)

The /MGR and /LGR signals are used to change parameters, such as the gear ratio and gain, to ensure the optimum control of the load according to the gear selection of the load shaft.

Refer to *16.1 Operation Modes and Applicable Parameters* for the parameters that change for the /MGR and the /LGR signals.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	/MGR	CN1-18	ON (closed)	Selects the M gear.
			OFF (open)	Selects the H gear.
	/LGR	CN1-17	ON (closed)	Selects the L gear.
			OFF (open)	Selects the H gear.

■ Precautions on Signals

- If pin 18 on CN1 turns ON, the /MGR signal function operates.
- If pin 17 on CN1 turns ON, the /LGR signal function operates.
- Use the gear selection signals as shown in the following table.

MGR	LGR	Meaning	Related Parameter
OFF	OFF	H gear is selected.	Pn83C
ON	–	M gear is selected.	Pn83D
OFF	ON	L gear is selected.	Pn83E

(15) Converter Emergency Stop Signal (ESP)

The ESP signal is used to perform an emergency stop of the spindle motor.

After the emergency stop waiting time elapses, the spindle motor decelerates to a stop. After the motor stops, the servo is turned OFF.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Input	ESP+, ESP-	CN1-11*, CN1-12	ON (closed)	Normal operation
			OFF (open)	After the emergency stop waiting time elapses, the spindle motor performs a zero-speed stop. After the motor stops, the servo is turned OFF.

* This is connector pin number for the power supply regenerative converter.

Parameter No.	Description	When Enabled	Classification
Pn01B	n.□□□0 [Factory setting]	After restart	Setup
	n.□□□1		

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn406	Emergency Stop Torque	0 to 800	1%	800	Immediately	Setup
Pn630	Emergency Stop Execution Delay Time	0 to 10000	1 ms	0	Immediately	Setup
Pn632	Emergency Stop Fault Detection Time	0 to 65535	1 ms	10000	Immediately	Setup

■ Precautions on Signals

- To enable this signal, set Pn01B.0 to 1. (The default setting is 0.)
- To cancel the emergency stop operation and enable operation, turn ON the EPS signal and turn OFF the /FWD, /REV, and /ORT signals.
- If you turn OFF the ESP signal during operation, the motor will decelerate to a stop at the torque that is set in Pn406. The upper limit is 120% of the maximum output of the spindle motor.
- If the spindle motor does not stop within the set time in Pn632 after ESP signal is input, an A.6B0 alarm (Emergency Stop Failure) will occur and the motor will coast to a stop.

6.2 Analog Speed Reference

This section describes the analog speed reference (SCOM).

The SCOM reference is an analog voltage that provides the speed reference for the spindle motor.

Speed Reference Specifications

Item	Specification
Connector Pin Number	CN1-3
Maximum Input Voltage	± 12 VDC
Input Impedance	60 kΩ

Spindle Motor Rotation Direction

The rotation direction of the spindle motor depends on the combination of the /FWD signal, the /REV signal, and the polarity of the speed reference voltage (SCOM).

Polarity of Speed Reference Voltage (SCOM)		+	-
Operation Signals	/FWD signal ON	CCW (forward)	CW (reverse)
	/REV signal ON	CW (reverse)	CCW (forward)


Related Parameters

Parameter No.	Description	When Enabled	Classification			
Pn031	n.□□□0	After restart	Setup			
	n.□□□1 [Factory Setting]					
	n.□□0□ [Factory Setting]					
	n.□□1□					
n.□□□0	Uses Speed Reference Input Gain 1 (Pn300).	After restart	Setup			
n.□□□1 [Factory Setting]	Uses Speed Reference Input Gain 2 (Pn30A).					
n.□□0□ [Factory Setting]	The upper limit is 105% of the rated speed.					
n.□□1□	The upper limit is 110% of the rated speed.					
Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn300	Speed Reference Input Gain 1	50 to 3000	0.01 V/ Base speed	600	Immediately	Setup
Pn30A	Speed Reference Input Gain 2	500 to 30000	0.001 V	10000	Immediately	Setup
Pn541	Rated Speed Setting	100 to 65535	1 min ⁻¹	65535	After restart	Setup

- When Using Pn300 (Speed Reference Input Gain 1)


The input voltage that is set for Pn300 (Speed Reference Input Gain 1) is added to operate the motor at the spindle motor base speed for high-speed winding.

The maximum input voltage is ±12 VDC. The upper limit of the motor speed depends on the setting of Pn031.1 (Speed Limit Level Selection). (When Pn031.1 is 0, the upper limit is 105% of the rated speed. When Pn031.1 is 1, the upper limit is 110% of the rated speed.)



For details on the /FWD and /REV signals, refer to 6.1.3 Details on Sequence Input Signals.

Parameter Setting Example (When the following spindle motor is used)




The speed reference input gain 1 is calculated as follows when 10 V is set as the speed reference voltage for the maximum speed:

$$\text{Speed reference input gain 1} = (10 \text{ V} \times 1500 \text{ min}^{-1}) \div 7000 \text{ min}^{-1} = 2.14 \text{ V}$$

Set Pn300 to 214. (The setting unit for Pn300 is 0.01 V/base speed.)

- When Using Pn30A (Speed Reference Input Gain 2)
 - Set the motor speed at the rated input voltage (at 100% speed reference) in Pn541 (Rated Speed Setting).
Example: If Pn30A is 10000 and Pn541 is 10000, the motor will operate at 10000 min⁻¹ for a speed reference voltage of 10 V. If the motor does not operate at the maximum speed even when Pn30A (Speed Reference Input Gain 2) is set to 10 V, increase the set value of Pn30A.
 - Set Pn541 (Rated Speed Setting) according to the motor specifications but not exceeding the maximum motor speed. If Pn541 (Rated Speed Setting) is set to a value that exceeds the maximum motor speed, the motor will operate at the maximum motor speed.
 - The maximum input voltage is ± 12 VDC. The upper limit of the motor speed depends on the setting of Pn031.1 (Speed Limit Level Selection). (When Pn031.1 is 0, the upper limit is 105% of the rated speed. When Pn031.1 is 1, the upper limit is 110% of the rated speed.)



■ Precautions on Reference

- The set value of the SCOM reference is enabled by turning ON the /FWD or /REV signal.
- If the /FWD or /REV signal is ON, the spindle motor may not be completely stopped even if the SCOM reference is set to 0 V. To stop the spindle motor completely, turn OFF both the /FWD and /REV signals.
- Use a twisted-shielded cable to wire the SCOM reference to improve noise immunity.

6.3 12-bit Digital Speed Reference

This section describes the 12-bit digital speed reference in detail.

■ D1 to D12 (12-bit Digital Speed Reference Signals 1 to 12)

Connector: CN2

Pins: 19 to 30

- If you set Pn850.0 (12-bit Digital Input Selection) to 0, pins 19 to 30 on CN2 are the digital speed reference.
- You can set the digital speed reference to 12-bit binary, 2-digit BCD, or 3-digit BCD. (The standard factory setting is for 12-bit binary.)
- Set the speed setting method for the digital speed reference in Pn850.1.

■ Related Parameter

Parameter No.	Description	When Enabled	Classification
Pn850	n.□□□0 [Factory Setting]	After restart	Setup
	n.□□□1		

* When Pn850.0 is set to 0, the setting of Pn850.1 is used.

When Pn850.0 is set to 1, the setting of Pn850.2 is used.

For details on the Pn850.0 = 1, refer to *Chapter 8 Orientation Control with a Motor Encoder*, *Chapter 9 Orientation Control with an External Encoder*, and *Chapter 10 Orientation Control with a Magnetic Sensor*.

Parameter No.	Description	When Enabled	Classification	
Pn850	n.□□0□ [Factory Setting]	After restart	Setup	
	n.□□1□			3-digit BCD
	n.□□2□			2-digit BCD
	n.□□3□			Internal speed setting

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn541*	Rated Speed Setting	100 to 65535	1 min ⁻¹	65535	After restart	Setup
Pn851	Internal Speed Setting 1	0 to 10000	0.01%	0		
Pn852	Internal Speed Setting 2	0 to 10000	0.01%	0		
Pn853	Internal Speed Setting 3	0 to 10000	0.01%	0		
Pn854	Internal Speed Setting 4	0 to 10000	0.01%	0		
Pn855	Internal Speed Setting 5	0 to 10000	0.01%	0		
Pn856	Internal Speed Setting 6	0 to 10000	0.01%	0		
Pn857	Internal Speed Setting 7	0 to 10000	0.01%	0		
Pn858	Internal Speed Setting 8	0 to 10000	0.01%	0		

* Pn541 (Rated Speed Setting) is used by the /ZSPD (speed detection) signal. Change the setting of Pn541 carefully because it will also change the speed detection level.

■ Speed Reference Selection

CN1-5 /DAS	Pn850.1	Speed Reference Selection
OFF	–	Analog speed setting
ON	0	12-bit binary
	1	3-digit BCD
	2	2-digit BCD
	3	Internal speed setting

- Changing the type of signal with the /DAS signal is effective only when the motor is stopped (when the /RDY signal is OFF or when operation, e.g., with the /FWD or other signals, is not possible due to an emergency stop or other reason).
- The direction for the signal speed (12-bit binary, 2-digit BCD, or 3-digit BCD) and the internal speed setting is determined by the /FWD and /REV contact signals from external devices.

■ Internal Speed Settings

Speed setting parameters: 8

Speed setting values: Set the percentages of Pn541 (Rated Speed Setting) in Pn851 to Pn858.

Setting range: 0 to 10000

Parameter No.	Name	CN2 Signal Name	Pin Number
Pn851	Internal input setting 1	D1	19
Pn852	Internal input setting 2	D2	20
Pn853	Internal input setting 3	D3	21
Pn854	Internal input setting 4	D4	22
Pn855	Internal input setting 5	D5	23
Pn856	Internal input setting 6	D6	24
Pn857	Internal input setting 7	D7	25
Pn858	Internal input setting 8	D8	26

- If you set Pn850.0 to 0, set Pn850.1 to 3, and turn ON the /DAS signal, the internal speed settings will be used to set the speed.
- If more than one of the D1 to D8 speed selection signals is ON at the same time, the speed with the lowest number is used. (For example, if D2 and D5 are ON at the same time, the speed for D2 is used.)
- If all of the set speed selection signals are OFF, a speed reference of 0 will be used.
- If you change the settings of the speed reference set values in Pn851 to Pn858 during operation, the new values will not take effect until the power supply is turned OFF and ON again.

■ Digital Speed Settings

Signal	CN2 Pin No.	12-bit Binary	3-bit BCD	2-bit BCD
D1	19	1	1	–
D2	20	2	2	–
D3	21	4	4	–
D4	22	8	8	–
D5	23	16	10	1
D6	24	32	20	2
D7	25	64	40	4
D8	26	128	80	8
D9	27	256	100	10
D10	28	512	200	20
D11	29	1024	400	40
D12	30	2048	800	80

- If you set Pn850.0 to 0, set Pn850.1 to 0, and turn ON the /DAS signal, 12-bit binary will be used to set the speed.
- If all of the signals are ON for 12-bit binary, the setting of Pn541 (Rated Speed Setting) will be used.
- If you set Pn850.0 to 0, set Pn850.1 to 1, and turn ON the /DAS signal, 3-digit BCD will be used to set the speed.
- If you set Pn850.0 to 0, set Pn850.1 to 2, and turn ON the /DAS signal, 2-digit BCD will be used to set the speed.
- For 2-digit BCD or 3-digit BCD, the setting of Pn541 (Rated Speed Setting) is used for a BCD value of 99 or 999.

Example 1: If Pn850.1 is set to 0 (12-bit binary) and D1, D3, D5, D7, and D9 are ON, the speed reference is as follows:

$$\text{Speed reference} = \frac{D1 + D3 + D5 + D7 + D9}{4095} \times \text{Pn541 (Rated speed setting)}$$

$$\text{Speed reference} = \frac{1 + 4 + 16 + 64 + 256}{4095} \times \text{Pn541 (Rated speed setting)}$$

$$\text{Speed reference} = \frac{341}{4095} \times \text{Pn541 (Rated speed setting)}$$

Example 2: If Pn850.1 is set to 1 (3-bit BCD) and D8, D9, and D10 are ON, the speed reference is as follows:

$$\text{Speed reference} = \frac{D8 + D9 + D10}{999} \times \text{Pn541 (Rated speed setting)}$$

$$\text{Speed reference} = \frac{80 + 100 + 200}{999} \times \text{Pn541 (Rated speed setting)}$$

$$\text{Speed reference} = \frac{380}{999} \times \text{Pn541 (Rated speed setting)}$$

Example 3: If Pn850.1 is set to 1 (3-bit BCD) and D11 and D12 are ON, the speed reference is as follows:

$$\text{Speed reference} = \frac{D11 + D12}{999} \times \text{Pn541 (Rated speed setting)}$$

$$\text{Speed reference} = \frac{400 + 800}{999} \times \text{Pn541 (Rated speed setting)}$$

$$\text{Speed reference} = \frac{1200^*}{999} \times \text{Pn541 (Rated speed setting)}$$

$$\text{Speed reference} = \frac{999}{999} \times \text{Pn541 (Rated speed setting)}$$

* The upper limit of 999 was exceeded, so the value is limited to 999.

Example 4: If Pn850.1 is set to 2 (2-bit BCD) and D8, D9, and D10 are ON, the speed reference is as follows:

$$\text{Speed reference} = \frac{D8 + D9 + D10}{99} \times \text{Pn541 (Rated speed setting)}$$

$$\text{Speed reference} = \frac{8 + 10 + 20}{99} \times \text{Pn541 (Rated speed setting)}$$

$$\text{Speed reference} = \frac{38}{99} \times \text{Pn541 (Rated speed setting)}$$

6.4 Sequence Output Signals

This section lists the sequence output signals and provides details on the status indications and signals. The output signals are output from the CN1 and CN3 connectors on the SERVOPACK. The sequence output signals are listed below.

6.4.1 Sequence Output Signals

(1) Output Signals on SERVOPACK CN1 Connector

CN1 Connector Pin No.	Signal Name	Function	Related Parameters
33	/ZSPD	Zero speed signal	Pn541 (Rated Speed Setting) Pn543 (Speed Detection Level) Pn544 (Speed Detection Hysteresis)
34	/AGR	Speed coincidence signal	Pn82C.0 (Speed Agree Signal Output at Zero Speed) Pn542 (Speed Coincidence Detection Width)
35	/SDET	Speed detection signal	Pn820 (Speed Detection Signal Level) Pn822 (Speed Detection Signal Hysteresis)
36	/TDET	Torque detection signal	Pn01C.0 (Output Load Factor Selection) Pn82C.1 (Torque Detection Signal Output) Pn823 (Torque Detection Signal Level) Pn824 (Torque Detection Signal Hysteresis)
37	/TLE	Torque limit signal	–
38	/ORG	Load shaft origin signal	–
39	/ORE	Orientation completed signal	When using a pulse encoder: Pn522 (Positioning Completed Width) Pn524 (Positioning Release Width) When using a magnetic sensor or for absolute positioning: Pn80D (Positioning Completed Width) Pn80E (Positioning Release Width) For incremental positioning: Pn522 (Positioning Completed Width) Pn524 (Positioning Release Width)
40	/CHWE	Winding selection completed signal	–
41	/FLTL	Fault signal	–
43, 44	FLTNO, FLTNC	Fault bit signal	–
46	/TALM	Alarm signal	–
26, 27, 28, 29	FC0 to FC3	Fault code signal 0 to 3	–

(2) Output Signals on SERVOPACK CN3 Connector


CN3 Connector Pin No.	Signal Name	Function	Related Parameters
10, 11	CC	Output to winding selection device	–

6.4.2 Status Display of Sequence Output Signals

The status of the output signals can be checked with the output signal monitor (Un006) and the output signal monitor 2 (Un034).

The output signal monitor (Un006) and the output signal monitor 2 (Un034) status are displayed as shown in the following figures. The top row indicates signals that are OFF (high level) and the bottom row indicates signals that are ON (low level). The bottom (ON) indicator is lit for all undefined digits. For details, refer to *13.3 Monitor Mode (Un□□□)*.


(1) Output Signal Monitor (Un006)

Un006 = 

Digit Number	Signal Name (Function)
1	/ZSPD (zero speed signal)
2	/AGR (speed coincidence signal)
3	CC (Output to the winding selector)
4	/SDET (speed detection signal)
5	/ORE (orientation completed signal)
6	/CHWE (winding selection completed signal)
7	/FLTL (fault signal)
8	FLT (fault bit signal)

Refer to *Chapter 13 Digital Operator* for the procedure on the Digital Operator.

(2) Output Signal Monitor 2 (Un034)

Un034 = 

Digit Number	Signal Name (Function)
1	/TDET (torque detection signal)
2	/TLE (torque limit signal)
3	/ORG (load shaft origin signal)
4	/TALM (alarm signal)
5	/FC0 (fault code signal 0)
6	/FC1 (fault code signal 1)
7	/FC2 (fault code signal 2)
8	/FC3 (fault code signal 3)


Refer to *Chapter 13 Digital Operator* for the procedure on the Digital Operator.

6.4.3 Details on Sequence Output Signals

This section provides information on each of sequence output signal. Pin numbers are given for independent drive operation. Refer to the manual for the host controller for sequence output signals and output addresses.


(1) Zero-speed Signal (/ZSPD)

The /ZSPD signal turns ON when the motor speed drops to below the speed that is set in Pn543 (Speed Detection Level). It will remain ON for at least 50 ms.



• Signal Specifications

Type	Specification	Pin No.	Output Status	Meaning
Output	/ZSPD	CN1-33	ON (closed)	Zero speed is being detected.
			OFF (open)	The motor is rotating.



Output Circuit

■ Related Parameters

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn541*	Rated Speed Setting	100 to 65535	1 min ⁻¹	65535	After restart	Setup
Pn543	Speed Detection Level	0 to 10000	0.01%	100	Immediately	Setup
Pn544	Speed Detection Hysteresis	0 to 10000	0.01%	10	Immediately	Setup

* Motor speed should be set according to the machine specifications at maximum speed or less. Under normal conditions, motor speed should be set at the maximum speed.

■ Parameter Setting Example

Example: Maximum speed of spindle motor: 12,000 min⁻¹

Speed detection level: 12 min⁻¹

Speed detection hysteresis: 6 min⁻¹

1) Set Pn541 to 12,000 min⁻¹.

2) Use the following formula to calculate the set value of Pn543 (Speed Detection Level [%]).

$$\begin{aligned}\text{Speed detection level} &= \frac{(\text{Speed detection set value})}{\text{Pn541}} \times 100 [\%] \\ &= \frac{12}{12000} \times 100 \\ &= 0.1\end{aligned}$$

Set Pn543 to 10.

(The setting unit for Pn543 is 0.01%.)

3) Use the following formula to calculate the set value of Pn544 (Speed Detection Hysteresis [%]).

$$\begin{aligned}\text{Speed detection hysteresis} &= \frac{(\text{Speed detection hysteresis})}{\text{Pn541}} \times 100 [\%] \\ &= \frac{6}{12000} \times 100 \\ &= 0.05\end{aligned}$$

Set Pn544 to 5.

(The setting unit for Pn544 is 0.01%.)


■ Precautions on Signals

- Set the zero speed detection level in Pn543 (Speed Detection Level) to a value within the setting range Pn544 (Speed Detection Hysteresis).
- Set Pn543 and Pn544 to percentages of Pn541 (Rated Speed Setting).
- The /ZSPD signal is output regardless of the status of the /FWD or /REV output. Therefore, the /ZSPD signal can be used as an interlock signal for hazard prevention.
- If Pn541 is set to a value that exceeds the maximum speed, the actual speed will be clamped to the maximum speed of the motor.
- If the zero speed detection level is set to a low value and the lower limit of the hysteresis width is below 0, the lower limit of the hysteresis width is limited to 0, and therefore the zero speed detection signal is not output.

(2) Speed Coincidence Signal (/AGR)


The /AGR signal turns ON when the motor speed enters the range that is set in Pn542 (Speed Coincidence Detection Width) based on the analog speed reference (SCOM). The /AGR signal will not turn ON during a base block or while the winding is being changed.

Set the range for the /AGR signal in Pn542 (Speed Coincidence Detection Width). (Set a value from $\pm 10\%$ to $\pm 50\%$ of rated speed.)



■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Output	/AGR	CN1-34	ON (closed)	The motor speed is within the set range.
			OFF (open)	The motor speed exceeds the set range.



Output Circuit

■ Related Parameters


Parameter No.	Description	When Enabled	Classification
Pn82C	n.□□□0 [Factory Setting]	After restart	Setup
	n.□□□1		

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn542	Speed Coincidence Detection Width	10 to 50	1%	15	Immediately	Setup

Setting example of Pn542

Maximum speed of spindle motor: 10000 min⁻¹

Pn542 = 10% setting




■ Precautions on Signals

- The /AGR signal is not output when the control power supply is turned ON because a base block is implemented.
- The /AGR signal is not output during winding selection.
- When the /AGR signal turns ON, it will remain ON for at least 50 ms.
- For operation with a host controller's program, the /AGR signal serves as the answer to the S signal (spindle rotation reference) to move to the next step.


(3) Speed Detection Signal (/SDET)

The /SDET signal will turn OFF when the motor speed exceeds the upper limit of the speed detection level threshold and it will turn ON when the motor speed goes below the lower limit of the speed detection level threshold.



■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Output	/SDET	CN1-35	ON (closed)	The motor speed is below the speed that is set in Pn820.
			OFF (open)	The motor speed is equal to or above the speed that is set in Pn820.



Output Circuit

■ Related Parameters

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn820	Speed Detection Level	0 to 2097152000	1 pulse/s	40960	After restart	Setup
Pn822	Speed Detection Hysteresis	0 to 10000	0.01%	1000	After restart	Setup

Use the following formulas to calculate the settings for the upper and lower limits of the speed detection level threshold.

Upper limit of the speed detection level threshold
 = Speed detection level [pulses/s] + (Speed detection level [pulses/s] × Speed detection hysteresis [%])

Lower limit of the speed detection level threshold
 = Speed detection level [pulses/s] – (Speed detection level [pulses/s] × Speed detection hysteresis [%])

The upper limit of the speed detection level is the maximum speed of the motor and the lower limit is a motor speed of 0 min⁻¹.

■ Parameter Setting Example

The following example shows how to set the speed detection level to the equivalent of a motor speed of 1000 min⁻¹.

$$\text{Pn820 (Speed Detection Level)} = 1000[\text{min}^{-1}] \times 4096[\text{pulse}] / 60[\text{s}] = 68266.7 \approx 68267[\text{pulse/s}]$$

When Pn822 (Speed Detection Hysteresis) is set to 10%, the following formulas are used to calculate the settings for the upper and lower limits of the speed detection level threshold for the speed detection level that was calculated above.

$$\begin{aligned} &\text{Upper limit of the speed detection level threshold} \\ &= 68267[\text{pulse/s}] + (68267[\text{pulse/s}] \times 0.1) = 75093.7[\text{pulse/s}] \text{ (Equivalent to } 1100[\text{min}^{-1}]) \end{aligned}$$

$$\begin{aligned} &\text{Lower limit of the speed detection level threshold} \\ &= 68267[\text{pulse/s}] - (68267[\text{pulse/s}] \times 0.1) = 61440.3[\text{pulse/s}] \text{ (Equivalent to } 900[\text{min}^{-1}]) \end{aligned}$$

■ Precautions on Signals

The operation of the /SDET signal is not affected by the settings of the /FWD and /REV signals.

(4) Torque Detection Signal (/TDET)

The /TDET signal is ON while the value of the torque reference is less than the set value.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Output	/TDET	CN1-36	ON (closed)	The torque reference is below the setting.
			OFF (open)	The torque reference is equal or above the setting.

■ Related Parameters

Parameter No.	Description	When Enabled	Classification
Pn01C	n.□□□0 [Factory Setting]	After restart	Setup
	n.□□□1		
	n.□□□2		
	n.□□□3		

Parameter No.	Description	When Enabled	Classification
Pn82C	n.□□0□ [Factory Setting]	After restart	Setup
	n.□□1□		

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn823	Torque Detection Signal Level	50 to 3000	0.1%	100	Immediately	Setup
Pn824	Torque Detection Signal Hysteresis	0 to 100	0.1%	10	Immediately	Setup

Use the following formulas to calculate the torque detection level threshold.

Torque detection level threshold (/TDET signal ON → OFF)
 = Standard torque value [N·m] × (Torque detection signal level [%]^{*} + Torque detection signal hysteresis [%])

Torque detection level threshold (/TDET signal OFF → ON)
 = Standard torque value [N·m] × (Torque detection signal level [%]^{*} - Torque detection signal hysteresis [%])


* Load factor is set in Pn01C.0.

■ Parameter Setting Example

Spindle motor: UAKAJ-04C

Pn823 (Torque detection signal level) = 100 = 10%

Pn824 (Torque detection signal hysteresis) = 10 = 1%



Example 1: Pn01C.0 = 0 (Outputs load factor as 120% of maximum output.)

$$\begin{aligned} & \text{Torque detection level threshold (/TDET signal ON} \rightarrow \text{OFF)} \\ &= 29.3/1.2[\text{N}\cdot\text{m}] \times (10 + 1) / 100 \\ &= 2.69[\text{N}\cdot\text{m}] \end{aligned}$$

$$\begin{aligned} & \text{Torque detection level threshold (/TDET signal OFF} \rightarrow \text{ON)} \\ &= 29.3/1.2[\text{N}\cdot\text{m}] \times (10 - 1) / 100 \\ &= 2.20[\text{N}\cdot\text{m}] \end{aligned}$$

Example 2: Pn01C.0 = 1 (Outputs load factor as 100% of maximum output.)

$$\begin{aligned} & \text{Torque detection level threshold (/TDET signal ON} \rightarrow \text{OFF)} \\ &= 29.3[\text{N}\cdot\text{m}] \times (10 + 1) / 100 \\ &= 3.22[\text{N}\cdot\text{m}] \end{aligned}$$

$$\begin{aligned} & \text{Torque detection level threshold (/TDET signal OFF} \rightarrow \text{ON)} \\ &= 29.3[\text{N}\cdot\text{m}] \times (10 - 1) / 100 \\ &= 2.64[\text{N}\cdot\text{m}] \end{aligned}$$

Example 3: Pn01C.0 = 2 (Outputs load factor as 100% of instantaneous rated output.)

$$\begin{aligned} & \text{Torque detection level threshold (/TDET signal ON} \rightarrow \text{OFF)} \\ &= 23.6[\text{N}\cdot\text{m}] \times (10 + 1) / 100 \\ &= 2.60[\text{N}\cdot\text{m}] \end{aligned}$$

$$\begin{aligned} & \text{Torque detection level threshold (/TDET signal OFF} \rightarrow \text{ON)} \\ &= 23.6[\text{N}\cdot\text{m}] \times (10 - 1) / 100 \\ &= 2.12[\text{N}\cdot\text{m}] \end{aligned}$$


Example 4: Pn01C.0 = 3 (Outputs load factor as 100% of continuous rated output.)

$$\begin{aligned} & \text{Torque detection level threshold (/TDET signal ON} \rightarrow \text{OFF)} \\ &= 14[\text{N}\cdot\text{m}] \times (10 + 1) / 100 \\ &= 1.54[\text{N}\cdot\text{m}] \end{aligned}$$

$$\begin{aligned} & \text{Torque detection level threshold (/TDET signal OFF} \rightarrow \text{ON)} \\ &= 14[\text{N}\cdot\text{m}] \times (10 - 1) / 100 \\ &= 1.26[\text{N}\cdot\text{m}] \end{aligned}$$

■ Precautions on Signals

- You can use the /TDET signal to check the torque limit operation and the load condition.
- When the /TDET signal turns OFF, it will remain OFF for at least 50 ms.
- The value that is set in Pn01C.0 (Output Load Factor Selection) determines the reference torque.
- You can set hysteresis in Pn824 (Torque Detection Signal Hysteresis).
- You can use Pn82C.1 (Torque Detection Signal Output) to set whether to output the /TDET signal during acceleration/deceleration. If you set this parameter to not output the signal for acceleration/deceleration, the /TDET signal will not be output from the start of acceleration/deceleration to the end of acceleration/deceleration.
- As shown in the following figure, the reference torque attenuates at speeds that are higher than the base speed, and therefore the thresholds also change accordingly.




(5) Torque Limit Signal (/TLE)

The /TLE signal is ON while either the /TLL or /TLH torque limit signal is being input. Use the /TLE signal to check the status of the /TLL and /TLH signals.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Output	/TLE	CN1-37	ON (closed)	A torque limit signal is being input.
			OFF (open)	A torque limit signal is not being input.




Output Circuit

(6) Load Shaft Origin Signal (/ORG)

This signal is used as a magnetic sensor signal. If the external speed is $1,000 \text{ min}^{-1}$ or less, one pulse is output for every rotation of the load shaft.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Output	/ORG	CN1-38	ON (closed)	At center of magnetic sensor
			OFF (open)	Others




Output Circuit

(7) Orientation Completion Signal (/ORE)

The /ORE signal turns ON when the load shaft approaches the preset stop position after the /ORT signal is turned ON. While the /ORE signal is ON, resistive torque to external force will be generated and position offset will be compensated. Replace tools or workpieces while the /ORE signal is ON.

■ Signal Specifications


Type	Signal Name	Pin No.	Output Status	Meaning
Output	/ORE	CN1-39	ON (closed)	Orientation is completed normally.
			OFF (open)	<ul style="list-style-type: none"> • Orientation is executing. • Orientation is not completed normally. • Orientation is not executed.



Output Circuit

■ Related Parameters

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn522	Positioning Completed Width	0 to 1073741824	1 pulse	5	Immediately	Setup
Pn524	Positioning Release Width	1 to 1073741824	1 pulse	10	Immediately	Setup
Pn80C	Load Shaft Positioning Origin (Using a Magnetic Sensor)	-200 to 200	0.01 deg	0	Immediately	Setup
Pn80D	Positioning Completed Width (Using a Magnetic Sensor)	0 to 200	0.1 deg	5	Immediately	Setup
Pn80E	Positioning Release Width (Using a Magnetic Sensor)	0 to 200	0.1 deg	10	Immediately	Setup
Pn80F	Magnetic Sensor Signal Standardization Angle	50 to 200	0.1 deg	50	After restart	Setup



■ Precautions on Signals

- The /ORE signal will turn OFF if the external force is high and the deviation of the position is excessive. In that case, arrange a sequence to result an orientation fault.
- If the motor stops without executing orientation correctly, the /ORE signal will not turn ON.
- If you use a pulse encoder, adjust the positioning completed width with Pn522 and the positioning release width with Pn524.
- If you use a magnetic sensor for absolute positioning, adjust the positioning completed width with Pn80D and the positioning release width with Pn80E.
- If you use a magnetic sensor for incremental positioning, adjust the positioning completed width with Pn522 and the positioning release width with Pn524.
- If you use a magnetic sensor and a pulse encoder, adjust the positioning completed width with Pn522 and the positioning release width with Pn524.


(8) Winding Selection Completion Signal (/CHWE)

This is the completion signal for the winding selection operation.

The /CHWE signal is ON during normal operation. The /CHWE signal turns OFF when the /CHW signal function is executed. It then turns OFF when the winding selection operation has been completed.

■ Signal Specifications


Type	Signal Name	Pin No.	Output Status	Meaning
Output	/CHWE	CN1-40	ON (closed)	Winding selection is completed.
			OFF (open)	Winding is being selected.



Output Circuit

■ Precautions on Signals

- If the /CHWE signal does not change within the preset time after the /CHW signal turns ON, a winding selection fault (A.690) will result and the spindle motor will stop.
- If the winding selection operation is performed during constant-speed operation, the /AGR signal will also turn OFF during the winding selection operation.




(9) Fault Signal (/FLTL)

If a protective circuit operates for an overcurrent or an overload, the current to the spindle motor is immediately turned OFF and the spindle motor coasts to a stop. The /FLTL signal is output when the current is turned OFF.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Output	/FLTL	CN1-41	ON (closed)	Normal operation
			OFF (open)	An error occurs.



Output Circuit

■ Precautions on Signals


- The /FLTL signal turns OFF when a fault occurs and is ON during normal operation.
- The output conditions for the /FLTL signal are the same as those for the FLT signal.
- When the /FLTL signal is output, turn OFF the operation signals (/FWD, /REV, and /ORT) and display a failure at the host system.
- An alarm will occur when the /FLTL signal is output.

(10) Fault Bit Signal (FLT)

If a protective function operates for an overcurrent or an overload, the current to the spindle motor is immediately turned OFF and the spindle motor coasts to a stop. The FLT signal changes at the same time that the current is turned OFF. When the protective function operates, the relay contacts are switched. Changeover contacts are used.

■ Signal Specifications

Type	Signal Name	Pin No.	Meaning
Output	FLT	CN1-43 [FLTNO]	ON (closed): An error was detected. OFF (open): Normal operation
		CN1-44 [FLTNC]	ON (closed): Normal operation OFF (open): An error was detected.
		CN1-45 [FLTCOM]	-: Fault bit output common



Output Circuit

■ Precautions on Signals


- When an error occurs, turn OFF the /FWD, /REV, and /ORT signals and display a failure at the host system.
- When a protective function operates, the FLTNO signal turns ON and an alarm will occur. Check the alarm number.

(11) Alarm Signal (/TALM)

The /TALM signal is output when a warning or alarm occurs. Operation will continue. If a warning, such as an overload warning (A.910) continues for more than a specific amount of time, it will become an alarm.

■ **Signal Specifications**

Type	Signal Name	Pin No.	Output Status	Meaning
Output	/TALM	CN1-46	ON (closed)	A warning occurs.
			OFF (open)	Normal operation




Output Circuit

(12) Fault Code Signals 0 to 3 (FC0 to FC3)

The fault code signals give the leftmost digit of the alarm number in binary. For details on fault codes, refer to *15.2.1 List of Alarms*.

■ **Signal Specifications**

Type	Signal Name	Pin No.
Output	FC0	CN1-26
	FC1	CN1-27
	FC2	CN1-28
	FC3	CN1-29



Output Circuit

6.5 Speed Meter Signal Output (SM)

You can connect an external speed meter to monitor the motor speed.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Output	SM	CN1-47	Analog voltage	Gives the spindle motor speed.

■ Speed Meter Specifications

- The speed meter signal outputs a DC voltage signal that is proportional to the speed. The rotation direction is ignored.
- The speed meter signal outputs the rated voltage (10 V) for the motor speed set in Pn541 (Rated Speed Setting).
- You can use Pn84C (Speed Meter Gain Adjustment Value) to adjust the level of the speed meter signal.
- Pn84C (Speed Meter Gain Adjustment Value) is used only to adjust the speed meter. It does not affect the actual speed.
- Use the following specifications to select the voltmeter to use for the speed meter.

Item	Specification
Type	Voltmeter
Operating Principle	Movable coil
Rating	10 V full scale
Internal Resistance	10 k Ω
Class	2.5 or higher

■ Related Parameters

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn541	Rated Speed Setting	100 to 65535	1 min ⁻¹	65535	After restart	Setup
Pn84C	Speed Meter Gain Adjustment Value	90 to 150	0.01	100	Immediately	Setup

<Supplementary Note>

- Use CN1-48 for the 0 V from the voltmeter.
- You cannot set an offset with the SERVOPACK. If an offset is required for the output, adjust it at the meter.

6.6 Load Ratio Meter Signal Output

(1) Load Ratio Meter Signal Output Signal (LM)

The LM signal is an analog voltage output that is used to display the load ratio.

■ Signal Specifications

Type	Signal Name	Pin No.	Output Status	Meaning
Output	LM	CN1-50	Analog voltage	Gives the spindle motor load ratio.

■ Load Ratio Meter Specifications

The output standard for the load ratio meter can be changed in the setting of Pn01C.0. With the default setting, a load ratio of 120% is displayed for the maximum motor output. Use the following specifications to select the voltmeter.

Item	Specification
Type	Voltmeter
Operating Principle	Movable coil
Rating	10 V full scale
Internal Resistance	10 k Ω
Class	2.5 or higher

■ Related Parameters

Parameter No.	Meaning	When Enabled	Classification
Pn01C	n.□□□0 [Factory Setting]	After restart	Setup
	n.□□□1		
	n.□□□2		
	n.□□□3		

Parameter No.	Name	Setting Range	Units	Factory Setting	When Enabled	Classification
Pn43F	Load Ratio Meter Filter Time Constant	0 to 5000	1 ms	100	Immediately	Setup
Pn84D	Load Ratio Gain Adjustment	90 to 150	0.01%	100	Immediately	Setup
Pn84E	Load Ratio Meter Full Scale Value	100 to 1000	1%	200	Immediately	Setup

The level for the LM signal can be adjusted in Pn84E (Load Ratio Meter Full Scale Value). The output will be 10 V for the load rate that is set in Pn84E. The maximum output voltage is 10 V. The slope of the voltage output can be adjusted in the setting of Pn84D (Load Ratio Meter Gain Adjustment).

<Supplementary Note>

- Use CN1-49 for the 0 V from the voltmeter.
- You cannot set an offset with the SERVOPACK. If an offset is required for the output, adjust it at the meter.

6.7 Encoder Pulse Input Circuit


Phase A, B, and C (origin) signals (PA, /PA, PB, /PB, PC, /PC) are input into the CN3 connector on the SERVOPACK from the 1024 P/R motor encoder. The input signals have the following specifications.

(1) Signal Configuration

90° phase-difference, two-phase pulse (A and B), and marker pulse (C)


(2) Input Circuit Configuration

The input circuit is a line receiver with RS-422-A specifications.




* indicates twisted-pair shielded wires.

(3) Input Phase



6.8 Encoder Pulse Output Circuit

Phase A, B, and C (origin) signals (PAO, /PAO, PBO, /PBO, PCO, /PCO) are output from the motor encoder. The output signals have the following specifications and can be used for position feedback.



IMPORTANT


The pulse output will change when the power supply is turned ON. Do not count these output pulses at the external device.


(1) Signal Configuration

90° phase-difference, two-phase pulse (A and B), and marker pulse (C)

(2) Output Circuit Configuration


The output circuit is a line receiver with RS-422-A specifications. Use a line receiver with specifications matching the RS-422-A specifications for signal exchange as shown in the following connection example.



*1.  indicates twisted-pair shielded wires.

*2. Use an SN75175 receiver or other receiver that is suitable for EIA RS-422-A.

(3) Output Phase



Winding Selection Control

7.1 Features of the Winding Selection Wide Constant Power Drive	7-2
7.2 Connection Diagram	7-3
7.3 Spindle Motor Characteristics	7-4
7.4 Winding Selection Operation	7-5
7.5 Winding Selection Methods	7-6
7.5.1 M Code Winding Selection Method	7-6
7.5.2 Automatic Winding Selection Methods	7-8
7.6 Winding Selection Control Precautions	7-11

7.1 Features of the Winding Selection Wide Constant Power Drive

Winding selection for the spindle motor is an effective way to extend the constant output control range of the Servo Drive that drives the main shaft. Winding selection control provides the following features.

■ Wide Constant Power Control Range

A constant power range of 1:12 can be obtained without using a gearbox.

■ Small Controller Capacity

When expanding the constant power control range using the AC main shaft drive, the Motor current must also be expanded in the low-speed area, and the controller capacity must also be increased. When using winding selection, a constant power control of 1:12 can be obtained using a standard controller capacity, simply by changing the Motor winding connections.

■ Good Control Stability


Winding selection enables optimum control by dividing the constant power control range into low-speed coils and high-speed coils. Consequently, stable control can be obtained by increasing the loop gain as well.

■ Special Magnetic Contactor for Winding Selection

The magnetic contactor is a compact model developed for winding selection. The contactor has a mechanical life of 5 million operations minimum.

7.2 Connection Diagram

As shown in the following diagram, this system requires winding selection signals in addition to speed reference signals such as the FWD and REV signals. A special magnetic contactor that can be driven directly from the SERVOPACK with transfer contacts is also used to switch the winding.




7.3 Spindle Motor Characteristics

Motors with switchable windings with a 1:12 constant power range have a 1:4 constant power range for both the low-speed and high-speed windings, as shown in the following diagram.

This can be written as $S_{ML}/S_{BL} = S_{MH}/S_{BH} = 4$. Also, the base speed ratio and maximum speed ratio are set to $S_{BH}/S_{BL} = S_{MH}/S_{ML} = 3$ to optimize the motor characteristics.

Consequently, the rated output will occur for both the low-speed and high-speed windings between S_{BH} and S_{ML} , so winding selection is performed within this speed range.


- Note 1. If the same output occurs in both the low-speed and high-speed windings between S_{BH} and S_{ML} , the load ratio meter signal may be offset by approximately $\pm 10\%$.
2. S_{BL} : The base speed of the low-speed windings.
 S_{ML} : The maximum speed of the low-speed windings.
 S_{BH} : The base speed of the high-speed windings.
 S_{MH} : The maximum speed of the high-speed windings.



IMPORTANT


■ **Low-speed Winding Application Precautions**
 The characteristics may not be achieved if the speed range exceeds the S_{ML} for the low-speed windings. Do not allow the speed to exceed the S_{ML} with the low-speed windings.

The following diagram shows the characteristics of the motor output.



7.4 Winding Selection Operation

The timing chart for switching from low-speed to high-speed windings is shown in the following diagram.



Note: The status of the auxiliary contacts (CN3 CA1, CA2) of the magnetic contactor for winding selection can be checked with the input signal monitor (Un035) from the Digital Operator. When the auxiliary contacts are ON, the 2nd digit of Un035 will show ON (i.e., the bottom indicator will be lit).


7.5 Winding Selection Methods

When performing winding selection, design the reference circuits referring to the following three methods, to make sufficient use of the spindle motor characteristics.

7.5.1 M Code Winding Selection Method

The numeric control M codes (M41: Low-speed winding and M42: High-speed winding) are used to switch the windings. The winding selection is treated as an electric gear. This is shown in the following flowchart and timing chart.

(1) Flowchart



*1. Operations within the dotted lines are SERVOPACK internal signal processes.

*2. M41: Low-speed winding selection

M42: High-speed winding selection

S reference: Main shaft rotation speed reference (main shaft)


S_{CHW}: Winding selection speed (spindle motor)

(In the diagram, $S_{BH} \geq S_{CHW} \leq S_{ML}$)


K: Gearbox ratio (When main shaft is traveling at $4,000 \text{ min}^{-1}$, if the spindle motor is operating at $5,000 \text{ min}^{-1}$, $K = 0.8$.)

Speed reference: Motor speed reference.

The relationship between the speed reference and S reference for M41 and M42 is shown in the diagram on the right.



(2) Timing Chart




7.5.2 Automatic Winding Selection Methods

This section explains the automatic winding selection methods. There are two methods.

(1) Using the SERVOPACK Speed Detection Signal

The flowchart and timing chart for performing automatic winding selection judging from the actual motor speed alone using the SERVOPACK speed detection signal (/SDET) are shown below.

■ Flowchart



*1. Operations within the dotted lines are SERVOPACK internal signal processes.

*2. S_{CHW} : Winding selection speed (spindle motor)

ΔS : Switching speed hysteresis width

Set S_{CHW} and ΔS as shown below.


Within the diagram,

$S_{CHW} - \Delta S \geq S_{BH}$

$S_{CHW} + \Delta S \leq S_{BH}$


$$Pn820 (SD_{LVL}) = \frac{S_{CHW}}{Pn541 (S100)} \times 100 (\%)$$

$$Pn822 (SD_{HYS}) = \frac{\Delta S}{Pn541 (S100)} \times 100 (\%)$$



Refer to *Chapter 13 Digital Operator* for details on the setting parameters.


■ Timing Chart



(2) Using Speed Reference and the SERVOPACK Speed Detection Signal

This method performs winding selection by judging whether the speed reference and actual motor speed are within the high-speed winding selection range or the low-speed winding selection range, using the speed reference and the SERVOPACK speed detection signal (/SDET). Compared with the changing method that uses only the speed detection signal, signal processing is increased, but the frequency of magnetic contactor changing can be reduced. The flowchart and timing chart are shown below.

■ Flowchart




- Note 1. []: Indicates signal processing that is performed inside the SERVOPACK.
 Note 2. Set the same values in Pn543 (SD_{LVL}: Speed Detection Level) and Pn544 (SD_{HYS}: Speed Detection Hysteresis) in the SERVOPACK as for the S_{CHW} (winding selection speed) and ΔS (switching speed hysteresis width) in the host controller.

■ Winding Selection Conditions

Speed	Speed Reference	
	$\geq S_{CHW} - \Delta S$	$\leq S_{CHW} + \Delta S$
Speed $\geq S_{CHW} - \Delta S$ (/SDET OFF)	High-speed winding selected	Winding selection not performed
Speed $\leq S_{CHW} + \Delta S$ (/SDET ON)	Winding selection not performed	Low-speed winding selected


■ Timing Chart



7.6 Winding Selection Control Precautions

Refer to the following precautions when designing winding selection control.

- If the signal wire breaks or the magnetic contactor for winding selection malfunctions, the motor will stop, and the operation program will not proceed. At this time, perform an overtime check after the set time, notify the operators immediately, and stop the winding selection operation by judging it to be defective (alarm A.690: Winding Selection Operation Fault).
- For automatic changing using motor speed detection, winding selection will be performed whenever the changing speed S_{CHW} is passed, so the frequency of magnetic contactor operations will be high.
- If using the main shaft drive on the lathe, automatic winding selection will be performed when changing speed is reached even during cutting. As shown in the following diagram, during rough cutting, considerable roughness will occur during changing, but as the cutting approaches completion, the difference will be lost. As this data also makes clear, there are several characteristics in actual use, but if accuracy in particular is essential, check the accuracy of the cut surface.
- Cutting Surface Accuracy for a Lathe



Note: Test conditions

- Cut object: S45C (ϕ 100 round bar)
- Cutting tool: Ultra-hard cutting tool
- Cutting speed: 150 m/min
- Cutting feed: 0.2 mm/revolution

Orientation Control with a Motor Encoder

8.1 Overview	8-2
8.2 Connection Diagram	8-3
8.3 Stop Position Reference Signals	8-4
8.3.1 Connecting the Stop Position Reference Signals	8-4
8.3.2 Status Indications of the Stop Position Reference Signals	8-4
8.3.3 Stop Position Reference Signal Details	8-4
8.4 Orientation Control Details	8-6
8.4.1 Orientation Signal (/ORT)	8-6
8.4.2 Orientation Completed Signal (/ORE)	8-6
8.4.3 Operation of Orientation Control with a Motor Encoder for Absolute Positioning	8-7
8.4.4 Operation of Orientation Control with a Motor Encoder for Incremental Positioning	8-11
8.4.5 Precautions for Orientation Control	8-12
8.5 Related Parameters	8-13


8.1 Overview

Orientation control with a motor encoder is used to position a machine to any position within one revolution. It is designed to be used for replacing tools and workpieces.

The motor encoder signal is used to divide 1 revolution into 4,096 steps (i.e., a resolution of 0.088°).

Positioning is performed to the position determined by Pn850.0 (12-bit Digital Reference Signal Selection) and Pn850.2 (Orientation Control Stop Position Reference Code).


The device configuration diagram is shown below. The load shaft and motor shaft must be coupled 1:1 and there must be no play.



8.2 Connection Diagram

The connection diagram for orientation control with a motor encoder is shown below.

- Note 1. For a connection diagram that uses a winding selection device, refer to 7.2 *Connection Diagram*.
 2. Do not change the winding while executing orientation control. Refer to 6.1 *Sequence Input Signals* for details.



Connection Diagram for Orientation Control with a Motor Encoder

8.3 Stop Position Reference Signals


This section describes the connections of the stop position reference signals, the status indications, and the signals.

8.3.1 Connecting the Stop Position Reference Signals

The stop position reference signals are connected to CN2 on the converter.

8.3.2 Status Indications of the Stop Position Reference Signals

You can check the status of the stop position reference signals in the Un037 and Un038 control signals. The indications are shown on the display on the Digital Operator. For details, refer to *Chapter 13 Digital Operator*.



8.3.3 Stop Position Reference Signal Details

■ D1 to D12 (Stop Position Reference Signals)

If you set Pn850.0 (12-bit Digital Reference Signal Selection for D1 to D12) to 1, pins 19 to 30 on CN2 are used as the stop position reference signals.

If pins 19 to 30 on CN2 turn ON, the function operates. Pins 19 to 30 correspond to signals D1 to D12.

- These are the reference signals for the stop position when you use a motor encoder for arbitrary position stop control.
- The stop position reference is input from an external device with the load shaft origin as 0.
- You can select either 12-bit binary or 3-digit BCD for the position reference.

Absolute	Binary	Data: 12 bits	0° to 359.9° (000 to FFF hex)
	BCD	Sign: 1 bit Data: 3 digits (11 bits)	-θ to +θ (-799 to +799 decimal)
Incremental	Binary	Sign: 1 bit Data: 11 bits	-2,047 to 2,047 pulses (-000 to +7FF hex)
	BCD	Sign: 1 bit Data: 3 digits (11 bits)	-θ to +θ (-799 to +799 decimal)

- If the sign bit is ON, the value is negative. If it is OFF, the value is positive.
- θ is found by multiplying the 3-digit BCD data and the BCD Stop Position Reference Resolution (Pn819). However, θ must be less than 360°.

- The following table shows the relationship between the reference signals and the number of pulses.

Signal	CN2 Pin No.	Binary		BCD
		Unsigned	Signed	Signed
D1	19	1	1	1
D2	20	2	2	2
D3	21	4	4	4
D4	22	8	8	8
D5	23	16	16	10
D6	24	32	32	20
D7	25	64	64	40
D8	26	128	128	80
D9	27	256	256	100
D10	28	512	512	200
D11	29	1024	1024	400
D12	30	2048	Sign	Sign

- For signed binary, the meaning of the signals depends on the polarity of the sign.

Positive Sign

Sum of the number of pulses for ON bits

$$\begin{array}{cccccccccc}
 0 & 0 & 1 & 0 & 1 & 0 & 0 & 1 & 0 & 0 & 1 \\
 & & : & & : & & : & & : & & : \\
 & & 256+ & & 64 & + & 8 & + & 1 & = & 329
 \end{array}$$

Negative Sign

Negative value of the sum of the number of pulses for ON bits

$$-(256 + 64 + 3 + 1) = -329$$

- For incremental operation, a binary reference of 180° or larger is not possible. With a BCD reference, references up to $\pm 360^\circ$ are possible depending on the setting of the BCD Stop Position Reference Resolution (Pn819).

8.4 Orientation Control Details

This section provides detailed information on orientation control with a motor encoder.

8.4.1 Orientation Signal (/ORT)

This section describes the input signals that are used to perform orientation control with a motor encoder.

Type	Signal Name	Pin No.	Meaning	Changes during Operation
Input	/ORT	CN1-16	The orientation operation starts when CN1-16 turns ON.	Possible


- Note 1. As long as the /ORT signal remains ON for orientation control with a motor encoder, the Servo will remain ON and position control will remain in effect even after positioning has been completed. Therefore, do not turn OFF the ORT signal until replacement of the tool or workpiece has been completed. Regardless of the status of the /FWD and /REV signals, orientation will be performed according to the current speed.
2. For details on operation for the combination of the /FWD, /REV, and /ORT signals, refer to 6.1.3 *Details on Sequence Input Signals*.

8.4.2 Orientation Completed Signal (/ORE)

The /ORE signal is output when orientation control with a motor encoder has been completed.

Type	Signal Name	Pin No.	Meaning
Output	/ORE	CN1-39	Turns ON when orientation has been completed normally.

The /ORE signal turns ON after pulse distribution for orientation has been completed and the difference between the target position and the current position is within the positioning completed width continuously for 60 ms. The /ORE signal turns OFF when the difference between the target position and the current position is equal to or greater than the positioning release width.



The /ORE signal is output only when the /ORT signal is ON.

8.4.3 Operation of Orientation Control with a Motor Encoder for Absolute Positioning

The operation that is performed for absolute positioning for orientation control with a motor encoder depends on the motor speed as described in the following table.

Absolute Speed	Basic Operation	Latch Operation	Control Mode
Current speed > Target speed	The speed is decelerated to the target speed by using speed control according to the deceleration rate that is specified in the parameters. Then, positioning is performed to the target position using the operation for when the current speed is less than or equal to the target speed.	Not executed.	Speed control
Current speed ≤ Target speed	The speed is accelerated to the target speed by using position control according to the acceleration rate that is specified in the parameters. After the target position is reached, a latch is requested for the phase-C signal. After the latch is completed, positioning is performed toward the target position. However, if the latch is not completed within one revolution of the latch request, deceleration is started.	Execution is started.	Position control


- Note 1. The target position, target speed, and acceleration/deceleration rates are set in the parameters.
 2. Positioning is performed in the current direction of rotation of the spindle motor. If the motor is stopped, positioning is performed in the forward direction of rotation.

If you set Pn850.0 to 1, the orientation control stop position reference is enabled and you can perform orientation control arbitrary position stopping. Normally, a digital speed reference is used, so the standard setting of Pn850.0 is 0. When Pn850.0 is set to 0, preset position stopping control is used.

The /ORE signals turns ON when orientation has been completed normally. If the phase-C latch cannot be performed for some reason, the motor decelerates to a stop. The /ORE signal remains OFF. If that occurs, timeout processing must be performed at the host.

An example of the orientation operation that uses the /ORT signal is given below. This examples uses forward operation, but reverse operation is essentially the same.

- From /FWD Signal ON to /ORT Signal ON When Current Speed > Target Speed




If the /ORT signal turns ON when the motor is operating for the /FWD signal at a speed that is higher than the target speed, the spindle motor performs the following operations.

1. The axis decelerates with speed control according to Pn815 (Orientation Deceleration Constant).
2. After Pn812 (Orientation Target Speed) is reached, control is changed to position control. A latch request is issued in the SERVOPACK and the motor waits for completion of the latch.
3. After the latch is completed, positioning is performed according to Pn850.2 (Orientation Control Stop Position Reference Code). If position offset does not occur for 60 ms after positioning is completed, the /ORE signal turns ON.

Note: If the /ORT signal is turned OFF when both the /FWD and the /REV signals are OFF, the /ORE signal is turned OFF and the power supply to the motor is turned OFF (Servo OFF).

- From /FWD Signal ON to /ORT Signal ON When Current Speed \leq Target Speed




If the /ORT signal turns ON when the motor is operating for the /FWD signal at a speed that is equal to or lower than the target speed, the spindle motor performs the following operations.

1. The axis accelerates with position control according to Pn813 (Orientation Acceleration Constant). A latch request is issued in the SERVOPACK and the motor waits for completion of the latch.
2. After Pn812 (Orientation Target Speed) is reached, the target speed is maintained.
3. After the latch is completed, positioning is performed according to Pn850.2 (Orientation Control Stop Position Reference Code). If position offset does not occur for 60 ms after positioning is completed, the /ORE signal turns ON.

- Note 1. If the /ORT signal is turned OFF when both the /FWD and the /REV signals are OFF, the /ORE signal is turned OFF and the power supply to the motor is turned OFF (Servo OFF).
2. If the latch is completed before the target speed is reached, positioning is started according to Pn850.2.

- From /FWD Signal OFF Status to /ORT Signal ON Status (Current Speed = 0)



If the /ORT signal turns ON when the motor is stopped (i.e., when both the /FWD and /REV signals are OFF), the spindle motor performs the following operations.

1. The axis accelerates with position control according to Pn813 (Orientation Acceleration Constant). A latch request is issued in the SERVOPACK and the motor waits for completion of the latch.
 2. After Pn812 (Orientation Target Speed) is reached, the target speed is maintained.
 3. After the latch is completed, positioning is performed according to Pn850.2 (Orientation Control Stop Position Reference Code). If a position offset does not occur for 60 ms after positioning is completed, the /ORE signal turns ON.
- Note 1. If the /ORT signal is turned OFF when both the /FWD and the /REV signals are OFF, the /ORE signal is turned OFF and the power supply to the motor is turned OFF (Servo OFF).
2. If the latch is completed before the target speed is reached, positioning is started according to Pn850.2.


8.4.4 Operation of Orientation Control with a Motor Encoder for Incremental Positioning

Incremental positioning is used to position to a new stop position by adding a specific amount of rotation (angle) to the previous stop reference position or to the current stop position.

If, after completing stopping at a preset position, you input the incremental signal and then input the orientation signal, the servo loop stops the motor at the new stop position and a completion signal is output at the same time.

In this mode, the motor is advanced by the specified amount of rotation each time the orientation signal is input.

A time chart for the operation of incremental positioning is given below.



Note: If you perform incremental operation, make sure that the position does not move while the orientation signal is OFF.


If the position moves, the stop position accuracy will be lost.

To perform arbitrary position stop control, set Pn850.0 (12-bit Digital Reference Signal Selection) to an orientation control stop position reference.

8.4.5 Precautions for Orientation Control

Observe the following precautions when designing a system that uses orientation control.

- If you perform an emergency stop during orientation, you will not be able to start operation again until you turn OFF the /ORT signal.
- Make sure that the /ORT signal is OFF when the power supply is turned ON. Operation cannot be restarted if the /ORT signal is ON.
- Wait at least 15 ms after the EMG signal, EMG2 signal, ESP signal, or /RDY signal turns ON before you turn ON the /ORT signal. The /ORT signal will not be accepted if it is turned ON before the EMG signal, EMG2 signal, ESP signal, or /RDY signal.



- For orientation operation, the shaft is stopped at the reference position after the origin signal (phase C signal) of the encoder is detected and then the orientation completed (/ORE) signal is output. The position where the origin signal was detected is cleared when the motor speed reaches 50 min^{-1} after stopping. (It is cleared even if the motor is turned by an external force.) If the /ORT signal is input after the origin signal detection position is cleared, the motor will operate to detect the origin signal. Implement any necessary safety measures.
- If the /ORT signal is input again while the origin signal detection position is recorded, the motor will not operate to detect the origin signal. Therefore, if the /ORT signal stop position is the current position, the motor will not operate and the orientation completed (/ORE) signal will be output immediately.
- However, there is no way to externally confirm the status of origin signal detection. When you input the /ORT signal, assume the possibility of the motor operating and create a sequence that confirms that the orientation completed (/ORE) signal changes the status from OFF to ON.
- The rotation direction of positioning is as follows:

Before Origin Signal Detection

The motor will operate in the direction set in Pn81C.0 (Orientation Positioning Rotation Direction).

When the Origin Signal Detection Position Is Still Recorded

When the /ORT signal is input again, the rotation direction is determined automatically to ensure shortest-path control.

You cannot specify the rotation direction.

8.5 Related Parameters

The parameters that must be set for orientation control are listed in the following table.

Pn522	Positioning Completed Width (Using an Encoder)				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0 to 1073741824	1 pulse	5	Immediately	Setup
Pn524	Positioning Release Width (Using an Encoder)				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	1 to 1073741824	1 pulse	10	Immediately	Setup
Pn80A	Load Shaft Positioning Origin (Using an Encoder)				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0 to 1073741824	1 pulse	0	Immediately	Setup
Pn812	Orientation Target Speed				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0 to 40960	10 pulse/s	3413	Immediately	Setup
Pn813	Orientation Acceleration Constant				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	1 to 4294967295	10 ⁿ pulse/s ²	70	Immediately	Setup
Pn815	Orientation Deceleration Constant				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	1 to 4294967295	10 ⁿ pulse/s ²	70	Immediately	Setup
Pn819	BCD Stop Position Reference Resolution				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0.1 to 180.0	0.1 deg	1.0	After restart	Setup
Pn900	Acceleration Basic Unit Selection (acceleration rate multiplier selection)				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0003 to 0006	–	0004	After restart	Setup

Note: Do not change Pn81A to Pn815 during execution of orientation.

Parameter No.	Description	When Enabled	Classification
Pn81C	n.□□□0 [Factory Setting]	Automatically selected rotation direction	After restart Setup
	n.□□□1	Same direction as the forward/reverse run signal	
	n.□□□2	Forward rotation of load shaft	
	n.□□□3	Reverse rotation of load shaft	

Parameter No.	Description	When Enabled	Classification
Pn81C	n.□□0□ [Factory Setting]	Previous stop reference position	After restart Setup
	n.□□1□	Current stop position	

Parameter No.	Description	When Enabled	Classification
Pn81C	n.0□□□ [Factory Setting]	Tuneup enabled	After restart Setup
	n.1□□□	Tuneup disabled	

Note: Set Pn81C.3 to 1 for orientation control with a motor encoder.

Parameter No.	Description	When Enabled	Classification
Pn850	n.□□□0 [Factory Setting]	Digital speed reference	After restart Setup
	n.□□□1	Orientation control stop position reference	

- Note 1. When Pn850.0 is set to 0, the setting of Pn850.1 is used.
For details on setting Pn850.0 to 0, refer to 6.3 *12-bit Digital Speed Reference*.
2. When Pn850.0 is set to 1, the setting of Pn850.2 is used.

Parameter No.	Description	When Enabled	Classification
Pn850	n.□0□□ [Factory Setting]	12-bit binary	After restart Setup
	n.□1□□	BCD 3-digit	
	n.□2□□	Reserved (Do not change.)	

■ Orientation Speed Setting Example

The setting is as follows for 500 min^{-1} with a 12-bit encoder (4,096 pulses):

$$\text{Target speed} = 500[\text{min}^{-1}] \times 4,096[\text{pulse}]/60[\text{s}] = 34,133.3[\text{pulse/s}]$$

The setting unit for the parameter is 10 pulses/s, so set Pn812 to 3,413. The target speed is clamped to the maximum speed if the setting exceeds the maximum speed.

■ Orientation Acceleration Rate Setting Example

The setting is as follows with a 12-bit encoder (4,096 pulses) to accelerate to $10,000 \text{ min}^{-1}$ in 5 seconds when the motor is stopped:

$$\text{Acceleration} = (10,000[\text{min}^{-1}] \times 4,096[\text{pulse}]/60[\text{s}])/5[\text{s}] = 136,533.3[\text{pulse}/\text{s}^2]$$

The setting unit for the parameter is $10^4 \text{ pulses}/\text{s}^2$ (Pn900 default setting is 4), so set Pn813 to 14. If a more precise setting is required, set Pn900 to 3.

Parameters	Names	Set Values	Operation for Parameter Setting
Pn813 Pn815	Acceleration Rate Deceleration Rate (position control)	Set the acceleration and deceleration rates as four unsigned bytes. Unit: $\times 10^n \text{ pulse}/\text{s}^2$	
		1 to 2147483647	Operation is performed according to the settings. However, the acceleration/deceleration rates are clamped to the maximum acceleration/deceleration rate (8,388,608,000,000 pulses/s ²). The minimum acceleration/deceleration rate is 7,812 pulse/s ² .
		2147483648 to 4294967294	The acceleration/deceleration rates are clamped to 2147483647.
		4294967295	Operation is performed at the maximum acceleration/deceleration rates.
		0	This value is lower than the lower limit and cannot be set.
Pn800 Pn802 Pn813 Pn815	Acceleration Rate Deceleration Rate (speed control)	Set the acceleration and deceleration rates as four unsigned bytes. Unit: $\times 10^n \text{ pulse}/\text{s}^2$	
		1 to 2147483647	Operation is performed according to the settings. The minimum acceleration/deceleration rate is 7,812 pulse/s ² .
		2147483648 to 4294967294	The acceleration/deceleration rates are clamped to 2147483647.
		4294967295	Operation is performed at the maximum acceleration/deceleration rates.
		0	This value is lower than the lower limit and cannot be set.

■ Positioning Completed Width and Positioning Release Width

If the positioning release width is smaller than the positioning completed width, the same value as the positioning completed width will be used internally.


Orientation Control with an External Encoder

9.1 Overview	9-2
9.2 Connection Diagram	9-3
9.3 Orientation Specifications	9-4
9.3.1 Standard Specifications	9-4
9.3.2 External Encoder Specifications	9-4
9.4 External Dimensions	9-5
9.5 External Encoder Connector Pin Arrangement	9-5
9.6 Encoder Attachment and Wiring Precautions	9-6
9.7 Stop Position Reference Signals	9-7
9.7.1 Connecting the Stop Position Reference Signals	9-7
9.7.2 Status Indications of the Stop Position Reference Signals	9-7
9.7.3 Stop Position Reference Signal Details	9-7
9.8 Orientation Control Details	9-9
9.8.1 Orientation Signal (/ORT)	9-9
9.8.2 Orientation Completed Signal (/ORE)	9-9
9.8.3 Operation of Orientation Control with an External Encoder for Absolute Positioning	9-10
9.8.4 Operation of Orientation Control with an External Encoder for Incremental Positioning	9-14
9.8.5 Precautions for Orientation Control	9-15
9.9 Related Parameters	9-16
9.10 Adjustment Procedure for Orientation Control Mode with an External Encoder	9-19


9.1 Overview

Orientation control with an external encoder is used to position a machine to any position within one revolution. It is designed to be used for replacing tools and workpieces.

The external encoder signal is used to divide 1 revolution into 4,096 steps (i.e., a resolution of 0.088°). Positioning is performed to the position determined by Pn850.0 (12-bit Digital Reference Signal Selection) and Pn850.2 (Orientation Control Stop Position Reference Code).



9.2 Connection Diagram



Connection Diagram for Orientation Control with an External Encoder

9.3 Orientation Specifications

9.3.1 Standard Specifications

The standard specifications for orientation control with a load shaft encoder are given in the following table.

Item	Specifications for Orientation with Load Shaft Encoder
Positioning Method	Absolute or incremental
Positioning Detection Method	Main shaft angle detection with phase A, B, and C pulses from load shaft encoder
Stop Position ^{*1}	Stopping at position specified with external reference or internal setting based on the load shaft origin ^{*2} The angular resolution is 0.088° (360°/4,096).
Stop Position Repeat Accuracy ^{*1}	±0.2° max.
Resistance Torque ^{*1}	Continuous rated torque/±0.1° displacement ^{*3}
Encoder Model	NE-1024-2MDF-068 (for attaching to load shaft)

*1. This value does not include backlash, eccentricity, or other mechanical error.

*2. The origin is obtained by setting value in Load Shaft Positioning Origin (Pn80A) from the rising edge of the encoder's phase-C pulse during forward rotation. The setting is made in parameter memory.

*3. Depending on the gain setting, it may not be possible to output the continuous rated torque. Also, the displacement may increase for rapid load fluctuations.

9.3.2 External Encoder Specifications


The external encoder specifications are given in the following table.

Item	Specifications	
Model	NE-1024-2MDF-068-11	NE-1024-2MDF-068-12
Maximum Speed* (min ⁻¹)	6000	8000
Power Supply	5 VDC ±5%, 350 mA	
Number of Pulses	Phases A and B: 1,024 pulses/rotation	
	Phase C: 1 pulse/rotation	
Outputs	Balanced output via line driver for each phase	
	AM26LS31 or equivalent	
Maximum Response Frequency	200 kHz	
Accumulated Pitch Error	Within 20% of phase A and B signal cycle	
Pitch Error	Within 10% of phase A and B signal cycle	
Input Shaft Moment of Inertia	$170 \times 10^{-3} \text{ kgf} \cdot \text{cm} \cdot \text{s}^2 \text{ max.}$	
Input Shaft Torque	1 kgf · cm max.	
Allowable Input Shaft Load	Thrust: 5 kg max. static, 10 kg max. dynamic	
	Radial: 10 kg max. static, 20 kg max. dynamic	
Structure	IP54 (with connector facing down)	
Output Connector	Encoder side: 97F3102E20-29P or equivalent	
	Cable side: MS3106A20-29S or equivalent DDK Ltd.	
Mass	1 kg	
Surrounding Air Temperature Range	0 to 60°C	
Humidity	85% RH max. (with no condensation)	

* The maximum speed is the maximum speed limit in actual operation.

9.4 External Dimensions


The external encoder dimensions are given in the following figure.



- Note 1. Backlash may cause offset in positions. Attach the encoder to eliminate backlash as much as possible.
- 2. There are also external encoders without flanges.
- 3. Consult your Yaskawa representative for external encoders for built-in motors.

9.5 External Encoder Connector Pin Arrangement

The connector pin arrangement of the external encoder connector is shown below.



Encoder side: 97F3102E20-29P

- Cable side: MS3106A20-29S (straight plug, solid shell)
- MS3106B20-29S (straight plug, two-piece shell)
- MS3108B20-29S (L-shaped plug, two-piece shell)


A	B	C	D	E	F	G	H	I
PA	PC	PB	-	FG	-	-	+5 V	-
K	L	M	N	P	R	S	T	-
0 V	-	-	/PA	/PC	/PB	-	-	-

Note: The connector is made by DDK Ltd.


9.6 Encoder Attachment and Wiring Precautions

Observe the following precautions when you attach and wire the encoder.

- The signal cable between the SERVOPACK and external encoder must be 20 m max.
- Yaskawa Controls provides signal cables with the following specifications. If necessary, purchase a cable in a standard length separately.

Order Number	BDP8409123
Manufacturer	Hitachi Cable, Ltd.
Basic Specifications	Composite KQVV-SW AWG 22×3C AWG 26×6P
Internal Structure and Lead Colors	B1 to B6 are twisted pair cables.  A ₁ : Red A ₂ : Black A ₃ : Yellow-green B ₁ : Blue - Light blue B ₂ : Yellow - Light yellow B ₃ : Green - Light green B ₄ : Orange - Light orange B ₅ : Purple - Violet B ₆ : Gray - Light gray
Standard Specifications	Standard lengths: 5 m, 10 m, and 20 m The end of the wires are not prepared (connectors are not attached).

- Note 1. The signal cable carries only a few volts. Separate it from power lines.
 2. If the load shaft turns clockwise for forward operation when the encoder is viewed from the end of the shaft, reverse phases A and B as shown in the following diagram.



9.7 Stop Position Reference Signals


This section describes the connections of the stop position reference signals, the status indications, and the signals.

9.7.1 Connecting the Stop Position Reference Signals

The stop position reference signals are connected to CN2 on the converter.

9.7.2 Status Indications of the Stop Position Reference Signals

You can check the status of the stop position reference signals in the Un037 and Un038 control signals. The indications are shown on the display on the Digital Operator. For details, refer to *Chapter 13 Digital Operator*.



9.7.3 Stop Position Reference Signal Details

■ D1 to D12 (Stop Position Reference Signals)

If you set Pn850.0 (12-bit Digital Reference Signal Selection for D1 to D12) to 1, pins 19 to 30 on CN2 are used as the stop position reference signals.

If pins 19 to 30 on CN2 turn ON, the function operates. Pins 19 to 30 correspond to signals D1 to D12.

- These are the reference signals for the stop position when you use an external encoder for arbitrary position stop control.
- The stop position reference is input from an external device with the load shaft origin as 0.
- You can select either 12-bit binary or 3-digit BCD for the position reference.

Absolute	Binary	Data: 12 bits	0° to 359.9° (000 to FFF hex)
	BCD	Sign: 1 bit Data: 3 digits (11 bits)	-θ to +θ (-799 to +799 decimal)
Incremental	Binary	Sign: 1 bit Data: 11 bits	-2,047 to 2,047 pulses (-000 to +7FF hex)
	BCD	Sign: 1 bit Data: 3 digits (11 bits)	-θ to +θ (-799 to +799 decimal)

- If the sign bit is ON, the value is negative. If it is OFF, the value is positive.
- θ is found by multiplying the 3-digit BCD data and the BCD Stop Position Reference Resolution (Pn819). However, θ must be less than 360°.

- The following table shows the relationship between the reference signals and the number of pulses.

Signal	CN2 Pin No.	Binary		BCD
		Unsigned	Signed	Signed
D1	19	1	1	1
D2	20	2	2	2
D3	21	4	4	4
D4	22	8	8	8
D5	23	16	16	10
D6	24	32	32	20
D7	25	64	64	40
D8	26	128	128	80
D9	27	256	256	100
D10	28	512	512	200
D11	29	1024	1024	400
D12	30	2048	Sign	Sign

- For signed binary, the meaning of the signals depends on the polarity of the sign.

Positive Sign

Sum of the number of pulses for ON bits

$$\begin{array}{cccccccccc}
 0 & 0 & 1 & 0 & 1 & 0 & 0 & 1 & 0 & 0 & 1 \\
 & & : & & : & & : & & : & & \\
 & & 256+ & & 64 & + & 8 & + & 1 & = & 329
 \end{array}$$

Negative Sign

Negative value of the sum of the number of pulses for ON bits

$$-(256 + 64 + 8 + 1) = -329$$

- For incremental operation, a binary reference of 180° or larger is not possible. With a BCD reference, references up to ±360° are possible depending on the setting of the BCD Stop Position Reference Resolution (Pn819).

9.8 Orientation Control Details

This section describes detailed information on orientation control with an external encoder.

9.8.1 Orientation Signal (/ORT)

This section describes the input signals that are used to perform orientation control with an external encoder.

Type	Signal Name	Pin No.	Meaning	Changes during Operation
Input	/ORT	CN1-16	The orientation operation with an external encoder starts when CN1-16 turns ON.	Possible


- Note 1. As long as the /ORT signal remains ON for orientation control with an external encoder, the Servo will remain ON and position control will remain in effect even after positioning has been completed. Therefore, do not turn OFF the /ORT signal until replacement of the tool or workpiece has been completed. Regardless of the status of the /FWD and /REV signals, orientation will be performed according to the current speed.
2. For details on operation for the combination of the /FWD, /REV, and /ORT signals, refer to 6.1.3 *Details on Sequence Input Signals*.

9.8.2 Orientation Completed Signal (/ORE)

The /ORE signal is output when orientation control with an external encoder has been completed.

Type	Signal Name	Pin No.	Meaning
Output	/ORE	CN1-39	Turns ON when orientation with an external encoder has been completed normally.

The /ORE signal turns ON after pulse distribution for orientation has been completed and the difference between the target position and the current position is within the positioning completed width continuously for 60 ms. The /ORE signal turns OFF when the difference between the target position and the current position is equal to or greater than the positioning release width.



The /ORE signal is output only while the /ORT signal is ON.

9.8.3 Operation of Orientation Control with an External Encoder for Absolute Positioning

Absolute positioning is used to move to a specified stop position based on the load shaft origin. Therefore, if the specified stop position is 0° , the shaft stops at the load shaft origin. If it is 90° , the shaft stops at 90° past the origin in the clockwise direction.

The operation that is performed for absolute positioning for orientation control with an external encoder depends on the motor speed as described in the following table.

Absolute Speed	Basic Operation	Latch Operation	Control Mode
Current speed > Target speed	The speed is decelerated to the target speed by using speed control according to the deceleration rate that is specified in the parameters. Then, positioning is performed to the target position using the operation for when the current speed is less than or equal to the target speed.	Not executed.	Speed control
Current speed \leq Target speed	The speed is accelerated to the target speed by using position control according to the acceleration rate that is specified in the parameters. After the target position is reached, a latch is requested for the phase-C signal. After the latch is completed, positioning is performed toward the target position. However, if the latch is not completed within one revolution of the latch request, deceleration is started.	Execution is started.	Position control


- Note 1. The target position, target speed, and acceleration/deceleration rates are set in the parameters.
 2. Positioning is performed in the current direction of rotation of the spindle motor. If the motor is stopped, positioning is performed in the forward direction of rotation.

If you set Pn850.0 to 1, the orientation control stop position reference is enabled and you can perform orientation control arbitrary position stopping. Normally, a digital speed reference is used, so the standard setting of Pn850.0 is 0. When Pn850.0 is set to 0, preset position stopping control is used.

The /ORE signal turns ON when orientation with an external encoder has been completed normally. If the phase-C latch cannot be performed for some reason, the motor decelerates to a stop. The /ORE signal remains OFF. If that occurs, timeout processing must be performed at the host.

An example of the operation of orientation with an external encoder that uses the /ORT signal is given below. This examples uses forward operation, but reverse operation is essentially the same.

- From /FWD Signal ON to /ORT Signal ON When Current Speed > Target Speed




If the /ORT signal turns ON when the motor is operating for the /FWD signal at a speed that is higher than the target speed, the spindle motor performs the following operations.

1. The axis decelerates with speed control according to Pn815 (Orientation Deceleration Constant).
2. After Pn812 (Orientation Target Speed) is reached, control is changed to position control. A latch request is issued in the SERVOPACK and the motor waits for completion of the latch.
3. After the latch is completed, positioning is performed according to Pn850.2 (Orientation Control Stop Position Reference Code). If the position offset does not occur for 60 ms after positioning is completed, the /ORE signal turns ON.

Note: If the /ORT signal is turned OFF when both the /FWD and /REV signals are OFF, the /ORE signal is turned OFF and the power supply to the motor is turned OFF (Servo OFF).


- From /FWD Signal ON to /ORT Signal ON When Current Speed \leq Target Speed



If the /ORT signal turns ON when the motor is operating for the /FWD signal at a speed that is equal to or lower than the target speed, the spindle motor performs the following operations.

1. The axis accelerates with position control according to Pn813 (Orientation Acceleration Constant). A latch request is issued in the SERVOPACK and the motor waits for completion of the latch.
 2. After Pn812 (Orientation Target Speed) is reached, the target speed is maintained.
 3. After the latch is completed, positioning is performed according to Pn850.2 (Orientation Control Stop Position Reference Code). If the position offset does not occur for 60 ms after positioning is completed, the /ORE signal turns ON.
- Note 1. If the /ORT signal is turned OFF when both the /FWD and /REV signals are OFF, the /ORE signal is turned OFF and the power supply to the motor is turned OFF (Servo OFF).
2. If the latch is completed before the target speed is reached, positioning is started according to Pn850.2 (Orientation Control Stop Position Reference Code).

- From /FWD Signal OFF Status to /ORT Signal ON Status (Current Speed = 0)



If the /ORT signal turns ON when the motor is stopped (i.e., when both the /FWD and /REV signals are OFF), the spindle motor performs the following operations.

1. The axis accelerates with position control according to Pn813 (Orientation Acceleration Constant). A latch request is issued in the SERVOPACK and the motor waits for completion of the latch.
2. After Pn812 (Orientation Target Speed) is reached, the target speed is maintained.
3. After the latch is completed, positioning is performed according to Pn850.2 (Orientation Control Stop Position Reference Code). If the position offset does not occur for 60 ms after positioning is completed, the /ORE signal turns ON.

Note 1. If the /ORT signal is turned OFF when both the /FWD and /REV signals are OFF, the power supply to the motor is turned OFF (Servo OFF).

2. If the latch is completed before the target speed is reached, positioning is started according to Pn850.2 (Orientation Control Stop Position Reference Code).


9.8.4 Operation of Orientation Control with an External Encoder for Incremental Positioning

Incremental positioning is used to position to a new stop position by adding a specific amount of rotation (angle) to the previous stop reference position or to the current stop position.

If, after completing stopping at a preset position, you input the incremental signal and then input the orientation signal, the servo loop stops the motor at the new stop position and a completion signal is output at the same time.

In this mode, the motor is advanced by the specified amount of rotation each time the orientation signal is input.

A time chart for the operation of incremental positioning is given below.



Note: If you perform incremental operation, make sure that the position does not move while the orientation signal is OFF.


If the position moves, the stop position accuracy will be lost.

To perform arbitrary position stop control, set Pn850.0 (12-bit Digital Reference Signal Selection) to an orientation control stop position reference.

9.8.5 Precautions for Orientation Control

Observe the following precautions when designing a system that uses orientation control.

- If you perform an emergency stop during orientation, you will not be able to start operation again until you turn OFF the /ORT signal.
- Make sure that the /ORT signal is OFF when the power supply is turned ON. Operation cannot be restarted if the /ORT signal is ON.
- Wait at least 15 ms after the EMG signal, EMG2 signal, ESP signal, or /RDY signal turns ON before you turn ON the /ORT signal. The /ORT signal will not be accepted if it is turned ON before the EMG signal, EMG2 signal, ESP signal, or /RDY signal.



- For orientation operation, the shaft is stopped at the reference position after the origin signal (phase C signal) of the encoder is detected and then the orientation completed (/ORE) signal is output. The position where the origin signal was detected is cleared when the motor speed reaches 50 min^{-1} after stopping. (It is cleared even if the motor is turned by an external force.) If the /ORT signal is input after the origin signal detection position is cleared, the motor will operate to detect the origin signal. Implement any necessary safety measures.
- If the /ORT signal is input again while the origin signal detection position is recorded, the motor will not operate to detect the origin signal. Therefore, if the /ORT signal stop position is the current position, the motor will not operate and the orientation completed (/ORE) signal will be output immediately.
- However, there is no way to externally confirm the status of origin signal detection. When you input the /ORT signal, assume the possibility of the motor operating and create a sequence that confirms that the orientation completed (/ORE) signal changes the status from OFF to ON.
- The rotation direction of positioning is as follows:
 - Before Origin Signal Detection
 - The motor will operate in the direction set in Pn81C.0 (Orientation Positioning Rotation Direction).
 - When the Origin Signal Detection Position Is Still Recorded
 - When the /ORT signal is input again, the rotation direction is determined automatically to ensure shortest-path control.
 - You cannot specify the rotation direction.

9.9 Related Parameters

The parameters that must be set for orientation control are listed in the following table.

Pn522	Positioning Completed Width (Using an Encoder)				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0 to 1073741824	1 pulse	5	Immediately	Setup
Pn524	Positioning Release Width (Using an Encoder)				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	1 to 1073741824	1 pulse	10	Immediately	Setup
Pn80A	Load Shaft Positioning Origin (Using an Encoder)				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0 to 1073741824	1 pulse	0	Immediately	Setup
Pn812	Orientation Target Speed				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0 to 40960	10 pulse/s	3413	Immediately	Setup
Pn813	Orientation Acceleration Constant				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	1 to 4294967295	10 ⁿ pulse/s ²	70	Immediately	Setup
Pn815	Orientation Deceleration Constant				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	1 to 4294967295	10 ⁿ pulse/s ²	70	Immediately	Setup
Pn817	Reference Pulses per Machine Rotation				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	1 to 1073741823	1 pulse	4096	After restart	Setup
Pn819	BCD Stop Position Reference Resolution				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0.1 to 180.0	0.1 deg	1.0	After restart	Setup
Pn83C	Gear Ratio 1				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	400 to 25000	0.0001	10000	After restart	Tuning
Pn83D	Gear Ratio 2				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	400 to 25000	0.0001	10000	After restart	Tuning
Pn83E	Gear Ratio 3				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	400 to 25000	0.0001	10000	After restart	Tuning
Pn900	Acceleration Basic Unit Selection (acceleration rate multiplier selection)				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0003 to 0006	–	0004	After restart	Setup

Note: Do not change Pn812 to Pn815 during execution of orientation.

Parameter No.		Meaning	When Enabled	Classification
Pn81C	n.□□□0 [Factory Setting]	Automatically selected rotation direction	After restart	Setup
	n.□□□1	Same direction as the forward/reverse run signal		
	n.□□□2	Forward rotation of load shaft		
	n.□□□3	Reverse rotation of load shaft		

Parameter No.		Meaning	When Enabled	Classification
Pn81C	n.□□0□ [Factory Setting]	Previous stop reference position	After restart	Setup
	n.□□1□	Current stop position		

Parameter No.		Meaning	When Enabled	Classification
Pn81C	n.0□□□ [Factory Setting]	Tuneup enabled	After restart	Setup
	n.1□□□	Tuneup disabled		

Parameter No.		Meaning	When Enabled	Classification
Pn850	n.□□□0 [Factory Setting]	Digital speed reference	After restart	Setup
	n.□□□1	Orientation control stop position reference		

Note: When Pn850.0 is set to 1, the setting of Pn850.2 is used.

Parameter No.		Meaning	When Enabled	Classification
Pn850	n.□0□□ [Factory Setting]	12-bit binary	After restart	Setup
	n.□1□□	BCD 3-digit		
	n.□2□□	Reserved (Do not change.)		

■ Orientation Speed Setting Example

The setting is as follows for 500 m^{-1} with a 12-bit encoder (4,096 pulses):

$$\text{Target speed} = 500 [\text{m}^{-1}] \times 4,096 [\text{pulses}]/60 [\text{s}] = 34,133.3 [\text{pulses/s}]$$

The setting unit for the parameter is 10 pulses/s, so set Pn812 to 3,413.

The target speed is clamped to the maximum speed if the setting exceeds the maximum speed.

■ Orientation Acceleration Rate Setting Example

The setting is as follows with a 12-bit encoder (4,096 pulses) to accelerate to $10,000 \text{ m}^{-1}$ in 5 seconds when the motor is stopped:

$$\text{Acceleration} = (10,000 [\text{m}^{-1}] \times 4,096 [\text{pulses}]/60 [\text{s}])/5 [\text{s}] = 136,533.3 [\text{pulses/s}^2]$$

The setting unit for the parameter is 10^4 pulses/s^2 (Pn900 default setting is 4), so set Pn813 to 14. If a more precise setting is required, set Pn900 to 3.

Parameters	Description	Set Values	Operation for Parameter Setting
Pn813 Pn815	Acceleration Rate Deceleration Rate (position control)	Set the acceleration and deceleration rates with four unsigned bytes. Unit: $\times 10^4 [\text{pulses/s}^2]$	
		1 to 2147483647	Operation is performed according to the settings. However, the acceleration/deceleration rates are clamped to the maximum acceleration/deceleration rate (8,388,608,000 pulses/s ²). The minimum acceleration/deceleration rate is 7,812 pulse/s ² .
		2147483648 to 4294967294	The acceleration/deceleration rates are clamped to 2147483647.
		4294967295	Operation is performed at the maximum acceleration/deceleration rates.
		0	This value is lower than the lower limit and cannot be set.
Pn800 Pn802 Pn813 Pn815	Acceleration Rate Deceleration Rate (speed control)	Set the acceleration and deceleration rates with four unsigned bytes. Unit: $\times 10^4 [\text{pulses/s}^2]$	
		1 to 2147483647	Operation is performed according to the settings. The minimum acceleration/deceleration rate is 7,812 pulse/s ² .
		2147483648 to 4294967294	The acceleration/deceleration rates are clamped to 2147483647.
		4294967295	Operation is performed at the maximum acceleration/deceleration rates.
		0	This value is lower than the lower limit and cannot be set.

■ Positioning Completed Width and Positioning Release Width

If the positioning release width is smaller than the positioning completed width, the same value as the positioning completed width will be used internally.

9.10 Adjustment Procedure for Orientation Control Mode with an External Encoder

Use the following flowchart to make adjustments.
Always make these adjustments when you replace the motor, SERVOPACK, or encoder.

Basic Items and Procedure	Details				
<pre> graph TD A[Turn power supply OFF and ON again.] --> B[Make initial settings.] B --> C{Are gear ratio settings correct?} C -- NO --> D[Correct gear ratio parameters in controller.] D --> C C -- YES --> E[Execute tuneup function (Fn024). Refer to 13.4.18 Turnup Function (Fn024) for details on tuneup function.] E --> F{Does shaft stop at load shaft positioning origin for forward and reverse operation?} F -- NO --> G[Investigate with error diagnosis.] F -- YES --> H[Select control parameter display with Load Shaft Positioning Origin (Pn80A).] H --> I[Set positioning origin data and press [JOG & SVON] Key.] I --> J[Stop at newly set origin.] J --> K{Is stop position correct?} K -- NO --> I K -- YES --> L((1)) </pre>	<p>Initial Settings: Change parameter settings with Digital Operator.</p> <ul style="list-style-type: none"> • Select orientation type with Pn01A.0. • Set Pn81C.3 to 0. • Set Pn002.3. <p>Gear Ratio Parameters</p> <table border="0"> <tr> <td>Pn83C: Gear ratio 1</td> <td rowspan="3">} 0.0400 to 2.5000</td> </tr> <tr> <td>Pn83D: Gear ratio 2</td> </tr> <tr> <td>Pn83E: Gear ratio 3</td> </tr> </table> <p>Check Input Signals Interface Input Status (Un005)</p> <p>U n 0 0 5 = </p> <p>Tuneup Operation*</p> <p>Load Shaft Positioning Origin</p>	Pn83C: Gear ratio 1	} 0.0400 to 2.5000	Pn83D: Gear ratio 2	Pn83E: Gear ratio 3
Pn83C: Gear ratio 1	} 0.0400 to 2.5000				
Pn83D: Gear ratio 2					
Pn83E: Gear ratio 3					

* Orientation completed (/ORE) signal is not output during tuneup.

(cont'd)

Basic Items and Procedure	Details
<pre> graph TD Start(()) --> Step1[Turn OFF orientation (/ORT) signal.] Step1 --> Step2[Set Pn81C.3 to 1 after completion of tuneup.] Step2 --> Step3[Adjust control parameters for machine specifications.] Step3 --> Step4[Turn ON orientation (/ORT) signal.] Step4 --> Dec1{Position accuracy insufficient or hunting occurs?} Dec1 -- YES --> Step5[Adjust 5th Position Loop Gain (Pn832).] Step5 --> Step4 Dec1 -- NO --> Step6[Turn OFF orientation (/ORT) signal.] Step6 --> Step7[Select middle gear.] Step7 --> Step8[Turn ON orientation (/ORT) signal.] Step8 --> Dec2{Position accuracy insufficient or hunting occurs?} Dec2 -- YES --> Step9[Adjust 6th Position Loop Gain (Pn836).] Step9 --> Step8 Dec2 -- NO --> Step10[Turn OFF orientation (/ORT) signal.] Step10 --> Step11[Select low gear.] Step11 --> Step12[Turn ON orientation (/ORT) signal.] Step12 --> Dec3{Position accuracy insufficient or hunting occurs?} Dec3 -- YES --> Step13[Adjust 7th Position Loop Gain (Pn83A).] Step13 --> Step12 Dec3 -- NO --> Step14[Turn OFF orientation (/ORT) signal.] Step14 --> Step15[END] </pre>	<p>If fault occurs during tuneup, reset and repeat tuneup operation.</p> <p>Tuneup Completion</p> <ul style="list-style-type: none"> Set Pn81C.3 (Tuneup Operation) to 1 after completion of tuneup. <p>High Gear Selected</p> <p>5th Position Loop Gain (Pn832)</p> <ul style="list-style-type: none"> Increase gain if /ORE signal is not output near stop position. Decrease gain if load shaft is not stable even if /ORE signal is output. <p>Checking Middle Gear Selection</p> <p>Interface Input Status (Un033)</p> <p>U n 0 3 3 = Digit</p> <p>↑ Lit when middle gear is selected.</p> <p>6th Position Loop Gain (Pn836)</p> <ul style="list-style-type: none"> Increase gain if /ORE signal is not output near stop position. Decrease gain if load shaft is not stable even if /ORE signal is output. <p>Checking Low Gear Selection*</p> <p>Interface Input Status (Un033)</p> <p>U n 0 3 3 = Digit</p> <p>↑ Lit when low gear is selected.</p> <p>7th Position Loop Gain (Pn83A)</p> <ul style="list-style-type: none"> Increase gain if /ORE signal is not output near stop position. Decrease gain if load shaft is not stable even if /ORE signal is output.

* Omit adjusting low gear if selecting is not in machine specifications.


Orientation Control with a Magnetic Sensor

10.1 Overview	10-2
10.2 Connection Diagram	10-3
10.3 Orientation Specifications	10-4
10.3.1 Standard Specifications	10-4
10.3.2 Magnet Specifications	10-4
10.3.3 Magnetic Sensor Specifications	10-5
10.4 External Dimensions	10-6
10.4.1 Magnet	10-6
10.4.2 Magnetic Sensor	10-7
10.5 Connections between Devices	10-8
10.5.1 Magnetic Sensor Signal	10-8
10.5.2 Stop Position Reference	10-8
10.6 Control Signal Connector Pin Arrangements	10-9
10.7 Mounting the Magnet and Magnetic Sensor	10-10
10.8 Mounting Precautions	10-11
10.9 Stop Position Reference Signals	10-13
10.9.1 Status Indications of the Stop Position Reference Signals	10-13
10.9.2 Stop Position Reference Signal Details	10-13
10.10 Orientation Control Details	10-15
10.10.1 Orientation Signal (/ORT)	10-15
10.10.2 Orientation Completed Signal (/ORE)	10-16
10.10.3 Feedback Speed Selection	10-16
10.10.4 Operation of Orientation Control with a Magnetic Sensor for Preset Position Stopping Control	10-16
10.10.5 Operation of Orientation Control with a Magnetic Sensor for Incremental Positioning	10-19
10.10.6 Precautions for Orientation Control	10-20
10.11 Related Parameters	10-21
10.12 Adjustment Procedure for Orientation Control Mode with a Magnetic Sensor	10-24


10.1 Overview

You can mount a magnet to a rotating part of the load shaft and mount a magnetic sensor on a fixed object to detect the position and move the shaft to a specific angular position. The following are required to perform this type of control: forward rotation signal, reverse rotation signal, speed reference, positioning reference orientation signal, magnet, and magnet sensor.

After positioning with the magnetic sensor, you can use incremental operation for arbitrary position stopping control. To do so, a stop position reference is also required.



10.2 Connection Diagram



Connection Diagram for Orientation Control with a Magnetic Sensor

Orientation Control with a Magnetic Sensor

10.3 Orientation Specifications

This section provides the specifications of the devices that are required for magnetic sensor orientation.

10.3.1 Standard Specifications

The standard specifications for orientation control with a magnetic sensor are given in the following table.

Item	Specifications
Positioning Detection Method	A magnet and magnetic sensor are used to detect changes in the position from changes in the magnetic flux.
Stop Position ^{*1}	The shaft is stopped at the position where the magnet is directly facing the center of the magnetic sensor head. Adjustment is possible with a control parameter within a range of $\pm 2^\circ$.
Stop Position Repeat Accuracy ^{*1}	$\pm 0.2^\circ$ max.
Resistance Torque ^{*1}	Continuous rated torque/ $\pm 0.1^\circ$ displacement ^{*2}
Magnet	Model: MG-1378BS (standard) or MG-1444S
Magnetic Sensor	Model: FS-1378C (standard) or FS-200A

*1. This value applies when the magnet is mounted on the circumference of a load shaft with a diameter of 120 mm. It does not include mechanical error or error caused by external magnetic fields.

*2. Depending on the gain setting, it may not be possible to output the continuous rated torque.




10.3.2 Magnet Specifications

The specifications of the magnet are given in the following table.

Item	Specifications	
	MG-1378BS	MG-1444S
Detection Range (mm)	± 15	± 7
Allowable Speed (min^{-1}) (when magnet is mounted to circumference of 200-mm diameter)	6700	10,000
Mass (g)	33	15
Manufacturer	Macome Corporation	

10.3.3 Magnetic Sensor Specifications

The specifications of the magnetic sensor are given in the following table.

Item	Specifications			
	FS-1378C		FS-200A	
Power Supply Voltage	15 VDC $\pm 5\%$		12 VDC $\pm 10\%$	
Current Consumption	100 mA max.		50 mA max.	
Position Signal for Control Level Offset Output Impedance	± 4 V min. ± 0.2 V max. 1.5 k Ω		± 8 V min. ± 0.2 V max. 1.5 k Ω	
Position Signal for Monitoring Range Offset	30° min. *1 (+2.4 V max.) ± 0.5 V max.			
Surrounding Air Temperature Range	-10 to 50°C			
Output Terminals	A round connector is attached. (Manufacturer: Tajimi Electronics Co., Ltd.) A: Position signal + B: SG C: +15 V D: Position signal - E: Range signal - *2 F: Range signal + *2		A 5-m cable is attached. 6-mm-dia., 4-core cabtyre cable Wiring Red: +12 V Black: SG Green: Output + White: Output -	
Manufacturer	Macome Corporation			

*1. This value applies when the magnet is mounted on the circumference of a load shaft with a diameter of 120 mm.


*2. The range signal on terminals E and F can be used for monitoring.

10.4 External Dimensions

The dimensions of the magnet and magnet sensor are given in the following figures.


10.4.1 Magnet

■ MG-1378BS



Unit: mm


■ MG-1444S




Unit: mm

10.4.2 Magnetic Sensor

■ FS-1378C



■ FS-200A




10.5 Connections between Devices

This section describes the connections between the devices used for magnetic sensor orientation control.

10.5.1 Magnetic Sensor Signal


■ Using the FS-1378C



Note 1. Use a two-pair 0.3-mm² twisted-paired vinyl cable with braided copper shielding. The wiring distance is 20 m max.


2. \overline{P} indicates shielded twisted-pair cable.

■ Using the FS-200A



10.5.2 Stop Position Reference

The stop position reference is used to stop the motor at a user-specified position using orientation control with a magnetic sensor.



Note: Refer to 5.2.5 *I/O Signals* for the connector pin arrangement.

10.6 Control Signal Connector Pin Arrangements

The terminal and pin arrangements of the control signal connectors are shown below.

■ SERVOPACK Connector (CN10)


14	SIG-	7	-
13	SIG+	6	-
12	+15 V	5	0 V
11	-	4	-
10	+12 V	3	0 V
9	-	2	-
8	-	1	-

PCB connector: 10214-52A2PL

Cable connector: 10114-3000PE (soldered)
10314-52A0-008 (case)

- Note 1. The terminal arrangement is viewed from the mating side of the PCB connector.
2. The connector is manufactured by Sumitomo 3M Corporation.

■ FS-1378C Magnetic Sensor



TRC116-21A10-7M Magnetic Sensor Connector


TRC116-12A10-7F Cable Connector

- Note 1. The pin arrangement is viewed from the mating side of the sensor connector.
2. The cable connector is provided with the magnetic sensor.
3. The connector is manufactured by Tajimi Electronics Co., Ltd.

10.7 Mounting the Magnet and Magnetic Sensor

The magnet is mounted directly to the load shaft as shown in the following diagram. The magnetic sensor is mounted to a part that does not rotate, but must be mounted so that the positioning of the center of the magnet is aligned exactly with the center of the magnetic sensor.

■ Mounting Diagram



■ Mounting Dimensions

The mounting dimensions are given in the following table.

Sign	Name	MG-1378BS and FS-1378C	MG-1444S and FS-200A
R	Radius of rotating part where magnet is mounted*1	60 to 70 mm	60 to 70 mm
L	Gap (between center of magnet and magnetic sensor)*2	6 mm (6 to 8 mm)	5 mm (3 to 7 mm)
ΔL	Gap (between tip of magnet and magnetic sensor)*2	1 to 2 mm	1 to 2 mm
Manufacturer	Misalignment between magnet and center of magnetic sensor*3	0.5 mm max.	0.5 mm max.
δ	Angular misalignment from base surface*3	0.2° max.	0.2° max.

*1. When you select the radius of the rotating part to which to mount the magnet, consider the maximum allowable speed of the magnet.

*2. The value of L is the recommended value. Adjust the gap to satisfy the value of ΔL .

*3. When the mechanical central shaft (e.g., the spindle nose key in the machining center) has been matched, make sure that the misalignment between the magnet and the center of the magnetic sensor, and the accuracy of the magnet mounting, are within specifications.

Make sure that the base surface is parallel to the tangent of the circumference at the point where the center line of the magnet intersects with the rotating circumference where the magnet is mounted.

10.8 Mounting Precautions

Observe the following precautions when you mount the magnet and magnetic sensor.

■ Mount the Magnet to the Load Shaft

The position control loop is configured using the detected magnetic field of the magnet. Mount the magnet on the load shaft (e.g., the main shaft of the machine tool).

If you use a belt or gear transmission mechanism between the shaft to which the magnet is mounted and the load shaft, there is a risk that the stop position will be offset due to load shaft belt slipping or gear backlash.

■ Do Not Install a Magnetic Body Near the Magnet

Use non-magnetic materials for the rotating body to which the magnet is mounted. Also make sure that there are no iron particles sticking to the magnet.

The presence of a magnetic body near the magnet may distort the magnetic field, resulting in incorrect position detection and preventing the shaft from stopping in the correct stop position.

Do not place devices that emit magnetic fields (solenoids, magnets, etc.) near the magnet or magnetic sensor.

The presence of another device that emits a magnetic field near the magnet may distort the magnetic field, resulting in incorrect position detection and preventing the shaft from stopping in the correct stop position.


■ Handle the Magnet and Magnetic Sensor with Care

When you mount the magnet and magnetic sensor, do not damage them mechanically.

The magnet rotates at high speed, so damage may result in unexpected accidents. Also, the magnetic sensor is a high-precision device. If external force is applied that results in internal distortion, detection accuracy will be reduced.

■ Do Not Subject the Magnetic Sensor Amplifier or Cables to Oil or Water

Do not allow oil or water to come into contact with the magnetic sensor amplifier or cables. In particular, if water or oil comes into frequent contact with the sensor head, perform waterproof countermeasures on the bushings using a filler, as shown in the following figure.





If dirty oil or water enters the magnetic sensor or cables, there is a risk that insulation properties will be reduced, resulting in errors in signal detection and control operations.

■ The Wiring Distance Is 20 Meters Maximum

Make sure that the wiring distance between the magnetic sensor amplifier and the orientation card is 20 m maximum. The magnetic sensor detection signal has a low voltage, so if the wiring is too long, the sensor will be easily affected by error voltages and noise voltages, resulting in inaccurate positioning.

■ Be Careful of the Polarity

When you mount the magnet and magnetic sensor, pay attention to the polarity, and mount the devices correctly as shown in the following figure. Even if the magnet and magnetic sensor are incorrectly mounted with the reverse polarity, the orientation card will still respond to signals, so control will be possible.




10.9 Stop Position Reference Signals

This section describes the status indications and signals.

10.9.1 Status Indications of the Stop Position Reference Signals

You can check the status of the stop position reference signals in the Un037 and Un038 control signals. The Digital Operator displays the status with the indicators that are shown below. Refer to *Chapter 13 Digital Operator* for the Digital Operator procedures.



10.9.2 Stop Position Reference Signal Details

This section describes the stop position reference signals.

■ D1 to D12 (Stop Position Reference Signals)

If you set Pn850.0 (12-bit Digital Reference Signal Selection for D1 to D12) to 1, pins 19 to 30 on CN2 are used as the stop position reference signals.

If pins 19 to 30 on CN2 turn ON, the function operates. Pins 19 to 30 correspond to signals D1 to D12.

- These are the reference signals for the stop position when you use a magnetic sensor and a magnet for arbitrary position stop control (incremental movement).
- The stop position reference is input from an external device with the load axis origin as 0.
- You can select either 12-bit binary or 3-digit BCD for the position reference.

Incremental	Binary	Sign: 1 bit Data: 11 bits	-2,047 to 2,047 pulses (-000 to +7FF hex)
	BCD	Sign: 1 bit Data: 3 digits (11 bits)	- θ to + θ (-799 to +799 decimal)

- If the sign bit is ON, the value is negative. If it is OFF, the value is positive.
- θ is found by multiplying the 3-digit BCD data and the BCD Stop Position Reference Resolution (Pn819). However, θ must be less than 360°.

- The following table shows the relationship between the reference signals and the number of pulses.

Signal	CN2 Pin No.	Binary	BCD
		Signed	Signed
D1	19	1	1
D2	20	2	2
D3	21	4	4
D4	22	8	8
D5	23	16	10
D6	24	32	20
D7	25	64	40
D8	26	128	80
D9	27	256	100
D10	28	512	200
D11	29	1024	400
D12	30	Sign	Sign

- For signed binary, the meaning of the signals depends on the polarity of the sign.

Positive Sign

Sum of the number of pulses for ON bits

$$\begin{array}{cccccccccccc}
 0 & 0 & 1 & 0 & 1 & 0 & 0 & 1 & 0 & 0 & 1 \\
 & & : & & : & & & : & & & : \\
 & & 256 & + & 64 & + & & 8 & + & & 1 = 329
 \end{array}$$

Negative Sign

Negative value of the sum of the number of pulses for ON bits

$$-(256 + 64 + 3 + 1) = -329$$


- For incremental operation, a binary reference of 180° or larger is not possible. With a BCD reference, references up to ±360° are possible depending on the setting of the BCD Stop Position Reference Resolution (Pn819).

Supplementary Note

The input signal circuits for the stop position reference for orientation control with magnetic sensor are the same as those given in 6.1 *Sequence Input Signals*.

10.10 Orientation Control Details

This section describes details information on orientation control with a magnetic sensor.

 IMPORTANT	<p>■ Precautions for Orientation Control</p> <p>In the following cases, always perform tuneup and adjust the parameters before you use orientation.</p> <ul style="list-style-type: none"> • Before you use orientation for the first time after attaching the SERVOPACK to the machine • After you replace the motor, magnet or magnetic sensor • After changing the wiring between devices <p>Refer to 13.4.18 <i>Turnup Function (Fn024)</i> for details on the tuneup operation.</p>
---	--

For orientation control with a magnetic sensor, assume that one rotation of the load shaft equals 4,096 pulses. Therefore, if you set 4,096 for the orientation target speed (Pn812), the orientation speed will be 600 min⁻¹.

10.10.1 Orientation Signal (/ORT)

This section describes the input signals that are used to perform orientation control with a magnetic sensor.

Type	Signal Name	Pin No.	Meaning	Changes during Operation
Input	/ORT	CN1-16	The orientation operation with a magnetic sensor starts when CN1-16 turns ON.	Possible


- Note 1. As long as the /ORT signal remains ON for orientation control with a magnetic sensor, the Servo will remain ON and position control will remain in effect even after positioning has been completed. Therefore, do not turn OFF the /ORT signal until replacement of the tool or workpiece has been completed. Regardless of the status of the /FWD and /REV signals, orientation will be performed according to the current speed.
2. For details on operation for the combination of the /FWD, /REV, and /ORT signals, refer to 6.1.3 *Details on Sequence Input Signals*.

10.10.2 Orientation Completed Signal (/ORE)

The /ORE signal is output when orientation control with a magnetic sensor has been completed.

Type	Signal Name	Pin No.	Description
Output	/ORE	CN1-39	Turns ON when orientation with a magnetic sensor has been completed normally.

The /ORE signal turns ON after pulse distribution for motion processing has been completed and the difference between the target position and the current position is within the positioning completed width continuously for 60 ms. The /ORE signal turns OFF when the difference between the target position and the current position is equal to or greater than the positioning release width.



The /ORE signal is output only while the /ORT signal is ON.

For preset position stopping control with a magnetic sensor, you can use Pn80D to adjust the positioning completed width and Pn80E to adjust the positioning release width.

For arbitrary position stopping control with incremental operation, you can use Pn522 to adjust the positioning completed width and Pn524 to adjust the positioning release width.

10.10.3 Feedback Speed Selection

With orientation control with magnetic sensor, you can select the speed control method for preset position stopping control with Pn01A.1 (Magnetic Sensor Orientation Stopping Speed Control Selection).

If there is excessive vibration when stopping, setting Pn01A.1 to 1 may reduce the amount of vibration.

Parameter No.	Description	When Enabled	Classification
Pn01A	n.□□0□ [Factory setting]	After restart	Setup
	n.□□1□		

Note: The setting is effective only while the /ORE signal is ON.

10.10.4 Operation of Orientation Control with a Magnetic Sensor for Preset Position Stopping Control

Orientation control with a magnetic sensor is used to move to a specified stop position based on the load shaft origin.

The operation that is performed for preset position stopping control for orientation control with a magnetic sensor depends on the motor speed as described in the following table.

Absolute Speed	Basic Operation	Latch Operation	Control Mode
Current speed > Target speed	The speed is decelerated to the target speed by using speed control according to the deceleration rate that is specified in the parameters. Then, positioning is performed to the target position using the operation for when the current speed is less than or equal to the target speed.	Not executed.	Speed control

(cont'd)


Absolute Speed	Basic Operation	Latch Operation	Control Mode
Current speed ≤ Target speed	The speed is accelerated to the target speed by using position control according to the acceleration rate that is specified in the parameters. After the target position is reached, a latch is requested for the center of the magnetic sensor signal. After the latch is completed, positioning is performed toward the target position.	Execution is started.	Position control

- Note 1. The target position, target speed, and acceleration/deceleration rates are set in the parameters.
 2. Positioning is performed in the current direction of rotation of the spindle motor. If the motor is stopped, positioning is performed in the forward direction of rotation.

The /ORE signal turns ON when orientation control with a magnetic sensor has been completed normally. If for any reason the value of the magnetic sensor was not detected correctly within one rotation of the load shaft, alarm A.687 will occur.

An example of the operation of magnetic sensor orientation control with a magnetic sensor that uses the /ORT signal is given below. This examples uses forward operation, but reverse operation is essentially the same.

- From /FWD Signal ON to /ORT Signal ON When Current Speed > Target Speed




If the /ORT signal turns ON when the motor is operating for the /FWD signal at a speed that is higher than the target speed, the spindle motor performs the following operations.

1. The axis decelerates with speed control according to Pn815 (Orientation Deceleration Constant).
2. After Pn812 (Orientation Target Speed) is reached, control is changed to position control. A latch request is issued in the SERVOPACK and the motor waits for completion of the latch.
3. After the latch is completed, positioning is performed toward the positioning origin. If the position offset does not occur for 60 ms after positioning is completed, the /ORE signal turns ON.

Note: If the /ORT signal is turned OFF when both the /FWD and /REV signals are OFF, the /ORE signal is turned OFF and the power supply to the motor is turned OFF (Servo OFF).

- From /FWD Signal ON to /ORT Signal ON When Current Speed \leq Target Speed




If the /ORT signal turns ON when the motor is operating for the /FWD signal at a speed that is equal to or lower than the target speed, the spindle motor performs the following operations.

1. The axis accelerates with position control according to Pn813 (Orientation Acceleration Constant). A latch request is issued in the SERVOPACK and the motor waits for completion of the latch.
2. After Pn812 (Orientation Target Speed) is reached, the target speed is maintained.
3. After the latch is completed, positioning is performed toward the positioning origin. If the position offset does not occur for 60 ms after positioning is completed, the /ORE signal turns ON.

Note 1. If the /ORT signal is turned OFF when both the /FWD and /REV signals are OFF, the /ORE signal is turned OFF and the power supply to the motor is turned OFF (Servo OFF).

2. If the latch is completed before the target speed is reached, positioning is started toward the positioning origin.

- From /FWD Signal OFF Status to /ORT Signal ON Status (Current Speed = 0)



If the /ORT signal turns ON when the motor is stopped (i.e., when both the /FWD and /REV signals are OFF), the spindle motor performs the following operations.

1. The axis accelerates with position control according to Pn813 (Orientation Acceleration Constant). A latch request is issued in the SERVOPACK and the motor waits for completion of the latch.
2. After Pn812 (Orientation Target Speed) is reached, the target speed is maintained.
3. After the latch is completed, positioning is performed toward the positioning origin. If the position offset does not occur for 60 ms after positioning is completed, the /ORE signal turns ON.

Note 1. If the /ORT signal is turned OFF when both the /FWD and /REV signals are OFF, the power supply to the motor is turned OFF (Servo OFF).

2. If the latch is completed before the target speed is reached, positioning is started toward the positioning origin.


10.10.5 Operation of Orientation Control with a Magnetic Sensor for Incremental Positioning

Incremental positioning is used to position to a new stop position by adding a specific amount of rotation (angle) to the previous stop reference position or to the current stop position.

If, after completing stopping at a preset position, you input the incremental signal and then input the orientation signal, the servo loop stops the motor at the new stop position and a completion signal is output at the same time.

In this mode, the motor is advanced by the specified amount of rotation each time the orientation signal is input.

A time chart for the operation of incremental positioning is given below.




Note: If you perform incremental operation, make sure that the position does not move while the orientation signal is OFF.

If the position moves, the stopping position accuracy will be lost.

10.10.6 Precautions for Orientation Control

Observe the following precautions when designing a system that uses orientation control.

- If you perform an emergency stop during orientation, you will not be able to start operation again until you turn OFF the /ORT signal.
- Make sure that the /ORT signal is OFF when the power supply is turned ON. Operation cannot be restarted if the /ORT signal is ON.
- Wait at least 15 ms after the EMG signal, EMG2 signal, ESP signal, or /RDY signal turns ON before you turn ON the /ORT signal. The /ORT signal will not be accepted if it is turned ON before the EMG signal, EMG2 signal, ESP signal, or /RDY signal.



- For orientation operation, the shaft is stopped at the reference position after the origin signal at the center of the magnetic sensor is detected and then the orientation completed (/ORE) signal is output.
- If the load shaft speed is too fast when you position to the origin after the origin signal is detected at the magnetic sensor, there will be detection offset for the origin signal. As a result, position error will occur in the stopping position. Implement any necessary safety measures.
- The position where the origin signal was detected is cleared if the motor speed exceeds 50 min^{-1} or the load shaft origin signal (/ORG) becomes inactive after stopping. (It is cleared even if the motor is turned by an external force.) If the /ORT signal is input after the origin signal detection position is cleared, the motor will operate to detect the origin signal. Implement any necessary safety measures.
- If the /ORT signal is input again while the origin signal detection position is recorded, the motor will not operate to detect the origin signal. Therefore, if the /ORT signal stop position is the current position, the motor will not operate and the orientation completed (/ORE) signal will be output immediately.
- However, there is no way to externally confirm the status of origin signal detection. When you input the /ORT signal, assume the possibility of the motor operating and create a sequence that confirms that the orientation completed (/ORE) signal changes the status from OFF to ON.
- The rotation direction of positioning is as follows:

Before Origin Signal Detection

The motor will operate in the direction set in Pn81C.0 (Orientation Positioning Rotation Direction).

When the Origin Signal Detection Position Is Still Recorded

When the /ORT signal is input again, the rotation direction is determined automatically to ensure shortest-path control.

You cannot specify the rotation direction.

10.11 Related Parameters

The parameters that must be set for orientation control are listed in the following table.

Pn80C	Load Shaft Positioning Origin (Using a Magnetic Sensor)				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	-200 to 200	0.01 deg	0	Immediately	Setup
Pn80D	Positioning Completed Width (Using a Magnetic Sensor)				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0 to 200	0.1 deg	5	Immediately	Setup
Pn80E	Positioning Release Width (Using a Magnetic Sensor)				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0 to 200	0.1 deg	10	Immediately	Setup
Pn80F	Magnetic Sensor Signal Standardization Angle				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	50 to 200	0.1 deg	50	After restart	Setup
Pn812	Orientation Target Speed				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0 to 40960	10 pulse/s	3413	Immediately	Setup
Pn813	Orientation Acceleration Constant				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	1 to 4294967295	10 ⁿ pulse/s ²	70	Immediately	Setup
Pn815	Orientation Deceleration Constant				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	1 to 4294967295	10 ⁿ pulse/s ²	70	Immediately	Setup
Pn819	BCD Stop Position Reference Resolution				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0.1 to 180.0	0.1 deg	1.0	After restart	Setup
Pn83C	Gear Ratio 1				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	400 to 25000	0.0001	10000	After restart	Tuning
Pn83D	Gear Ratio 2				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	400 to 25000	0.0001	10000	After restart	Tuning
Pn83E	Gear Ratio 3				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	400 to 25000	0.0001	10000	After restart	Tuning
Pn900	Acceleration Basic Unit Selection (acceleration rate multiplier selection)				Classification
	Setting Range	Unit	Factory Setting	When Enabled	
	0003 to 0006	–	0004	After restart	Setup

Note: Do not change Pn812 to Pn815 during execution of orientation.

Parameter No.	Meaning	When Enabled	Classification
Pn81C	n.□□□0 [Factory Setting]	Automatically selected rotation direction	After restart Setup
	n.□□□1	Same direction as the forward/reverse run signal	
	n.□□□2	Forward rotation of load shaft	
	n.□□□3	Reverse rotation of load shaft	

Parameter No.	Meaning	When Enabled	Classification
Pn81C	n.□□0□ [Factory Setting]	Previous stop reference position	After restart Setup
	n.□□1□	Current stop position	

Parameter No.	Meaning	When Enabled	Classification
Pn81C	n.0□□□ [Factory Setting]	Tuneup enabled	After restart Setup
	n.1□□□	Tuneup disabled	

Parameter No.	Meaning	When Enabled	Classification
Pn850	n.□0□□ [Factory Setting]	12-bit binary	After restart Setup
	n.□1□□	BCD 3-digit	
	n.□2□□	Reserved (Do not change.)	

■ Orientation Speed Setting Range

Set the orientation speed to within the following range.

40 min^{-1} to 800 min^{-1}

If the setting is outside of this range, a Magnetic Sensor Signal Disconnection Error alarm (A.687) will occur. If you use a magnetic sensor, one revolution of load shaft is regarded as 4096 pulses.

■ Orientation Speed Setting Example

The setting is as follows for 500 m^{-1} :

Target speed = $500 [\text{m}^{-1}] \times 4,096 [\text{pulses}]/60 [\text{s}] = 34,133.3 [\text{pulses/s}]$

The setting unit for the parameter is 10 pulses/s, so set Pn812 to 3,413.

The target speed is clamped to the maximum speed if the setting exceeds the maximum speed.

■ Orientation Acceleration Rate Setting Example

The setting is as follows to accelerate to $10,000 \text{ m}^{-1}$ in 5 seconds when the motor is stopped:

$$\text{Acceleration} = (10,000 [\text{m}^{-1}] \times 4,096 [\text{pulses}]/60 [\text{s}])/5 [\text{s}] = 136,533.3 [\text{pulses/s}^2]$$

The setting unit for the parameter is 10^4 pulses/s^2 (Pn900 default setting is 4), so set Pn813 to 14.
If a more precise setting is required, set Pn900 to 3.

Parameters	Description	Set Values	Operation for Parameter Setting
Pn813 Pn815	Acceleration Rate Deceleration Rate (position control)	Set the acceleration and deceleration rates with four unsigned bytes. Unit: $\times 10^n$ [pulses/s ²]	
		1 to 2147483647	Operation is performed according to the settings. However, the acceleration/deceleration rates are clamped to the maximum acceleration/deceleration rate (8,388,608,000,000 pulses/s ²). The minimum acceleration/deceleration rate is 7,812 pulse/s ² .
		2147483648 to 4294967294	The acceleration/deceleration rates are clamped to 2147483647.
		4294967295	Operation is performed at the maximum acceleration/deceleration rates.
		0	This value is lower than the lower limit and cannot be set.
Pn800 Pn802 Pn813 Pn815	Acceleration Rate Deceleration Rate (speed control)	Set the acceleration and deceleration rates with four unsigned bytes. Unit: $\times 10^n$ [pulses/s ²]	
		1 to 2147483647	Operation is performed according to the settings. The minimum acceleration/deceleration rate is 7,812 pulse/s ² .
		2147483648 to 4294967294	The acceleration/deceleration rates are clamped to 2147483647.
		4294967295	Operation is performed at the maximum acceleration/deceleration rates.
		0	This value is lower than the lower limit and cannot be set.

■ Positioning Completed Width and Positioning Release Width

If the positioning release width is smaller than the positioning completed width, the same value as the positioning completed width will be used internally.

■ Setting Method for Magnetic Sensor Signal Standardization Angle (Pn80F)

You must set the standardization angle for the detection sensitivity for the magnetic sensor signal. The formula for calculating the magnetic sensor signal standardization angle (Pn80F) is given below.

$$\text{Magnetic sensor signal standardization angle [deg]} = 180 [\text{deg}] \times \text{Detection range [mm]} \div \text{Installation diameter [mm]} \div \pi$$

If the magnetic sensor signal standardization angle is greater than 20.0, set Pn80F to 20.0. Confirm the model of the magnet and use the following corresponding value for the detection range.

MG-1378BS: 15 mm,
MG-1444S: 7 mm

10.12 Adjustment Procedure for Orientation Control Mode with a Magnetic Sensor

Use the following flowchart to make adjustments.
Always make these adjustments when you replace the motor, SERVOPACK, or encoder.

Basic Items and Procedure	Details				
<pre> graph TD A[Turn power supply OFF and ON again.] --> B[Make initial settings.] B --> C{Are gear ratio settings correct?} C -- NO --> D[Correct gear ratio parameters in controller.] D --> C C -- YES --> E[Select high gear.] E --> F[Execute tuneup function (Fn024). Refer to 13.4.18 Turnup Function (Fn024) for details on tuneup function.] F --> G{Does shaft stop at load shaft positioning origin?} G -- NO --> H[Investigate with error diagnosis.] G -- YES --> I[Select control parameter display with Load Shaft Positioning Origin (Pn80A).] I --> J[Set positioning origin data and press SVON Key.] J --> K[Stop at newly set origin.] K --> L{Is stop position correct?} L -- NO --> H L -- YES --> M[①] </pre>	<p>Initial Settings: Change parameter settings with Digital Operator.</p> <ul style="list-style-type: none"> • Set Pn01A.0 to 2. • Set Pn80F. • Set Pn81C.3 to 0. <p>Gear Ratio Parameters</p> <table border="0"> <tr> <td>Pn83C: Gear ratio 1</td> <td rowspan="3">} 0.0400 to 2.5000</td> </tr> <tr> <td>Pn83D: Gear ratio 2</td> </tr> <tr> <td>Pn83E: Gear ratio 3</td> </tr> </table> <p>Check Input Signals Interface Input Status (Un005)</p> <p>Un005 = </p> <p>Tuneup Operation*</p> <p>Load Shaft Positioning Origin</p>	Pn83C: Gear ratio 1	} 0.0400 to 2.5000	Pn83D: Gear ratio 2	Pn83E: Gear ratio 3
Pn83C: Gear ratio 1	} 0.0400 to 2.5000				
Pn83D: Gear ratio 2					
Pn83E: Gear ratio 3					

* Orientation completed (/ORE) signal is not output during tuneup.

(cont'd)


Basic Items and Procedure	Details
<pre> graph TD Start((1)) --> A[Turn OFF orientation (/ORT) signal.] A --> B[Set Pn81C.3 to 1 after completion of tuneup.] B --> C[Adjust control parameters for machine specifications.] C --> D[Turn ON orientation (/ORT) signal.] D --> E{Position accuracy insufficient or hunting occurs?} E -- YES --> F[Adjust 5th Position Loop Gain (Pn832).] F --> D E -- NO --> G[Select middle gear.] G --> H[Turn ON orientation (/ORT) signal.] H --> I{Position accuracy insufficient or hunting occurs?} I -- YES --> J[Adjust 6th Position Loop Gain (Pn836).] J --> H I -- NO --> K[Turn OFF orientation (/ORT) signal.] K --> L[Select low gear.] L --> M[Turn ON orientation (/ORT) signal.] M --> N{Position accuracy insufficient or hunting occurs?} N -- YES --> O[Adjust 7th Position Loop Gain (Pn83A).] O --> M N -- NO --> P[Turn OFF orientation (/ORT) signal.] P --> Q[END] </pre>	<p>If fault occurs during tuneup, reset and repeat tuneup operation.</p> <p>Tuneup Completion</p> <ul style="list-style-type: none"> Set Pn81C.3 (Tuneup Operation) to 1 after completion of tuneup. <p>High Gear Selected</p> <p>5th Position Loop Gain (Pn832)</p> <ul style="list-style-type: none"> Increase gain if /ORE signal is not output near stop position. Decrease gain if load shaft is not stable even if /ORE signal is output. Or change the setting of Pn01A.1 and turn OFF the power supply and turn it ON again. <p>Checking Middle Gear Selection</p> <p>Interface Input Status (Un033)</p> <p>U n 0 3 3 = Digit</p> <p style="margin-left: 150px;">Lit when middle gear is selected.</p> <p>6th Position Loop Gain (Pn836)</p> <ul style="list-style-type: none"> Increase gain if /ORE signal is not output near stop position. Decrease gain if load shaft is not stable even if /ORE signal is output. Or change the setting of Pn01A.1 and turn OFF the power supply and turn it ON again <p>Checking Low Gear Selection*</p> <p>Interface Input Status (Un033)</p> <p>U n 0 3 3 = Digit</p> <p style="margin-left: 150px;">Lit when low gear is selected.</p> <p>7th Position Loop Gain (Pn83A)</p> <ul style="list-style-type: none"> Increase gain if /ORE signal is not output near stop position. Decrease gain if load shaft is not stable even if /ORE signal is output. Or change the setting of Pn01A.1 and turn OFF the power supply and turn it ON again

* Omit adjusting low gear if selecting is not in machine specifications.

11.1 Panel Display	11-2
11.1.1 Status Display	11-2
11.1.2 Alarm and Warning Display	11-2
11.1.3 Hard Wire Base Block Display	11-2
11.1.4 RDY and ALM LEDs	11-2
11.2 Basic Functions Settings	11-3
11.2.1 Spindle Motor Settings	11-3
11.2.2 Spindle Motor Rotation Direction	11-7
11.2.3 Stopping Spindle Motor after SV_OFF Command or Alarm Occurrence	11-7
11.2.4 Instantaneous Power Interruption Settings	11-9
11.2.5 Setting Motor Overload Detection Level	11-10
11.2.6 Limiting Torque	11-12
11.3 Trial Operation	11-13
11.3.1 Preparations for Trial Operation	11-13
11.3.2 Trial Operation Example	11-15
11.4 Hard Wire Base Block (HWBB) Function	11-16
11.4.1 Precautions for the Hard Wire Base Block (HWBB) State	11-16
11.4.2 Hard Wire Base Block (HWBB) State	11-17
11.4.3 Resetting the HWBB State	11-18
11.4.4 Error Detection in HWBB Signal	11-18
11.4.5 Connection Example and Specifications of Input Signals (HWBB Signals)	11-19
11.4.6 Operation with SigmaWin+	11-20
11.4.7 External Device Monitor (EDM)	11-20
11.4.8 Application Example of HWBB Function	11-21
11.4.9 Confirming HWBB Function	11-22
11.4.10 Attaching the HWBB Jumper Connector	11-22

11.1 Panel Display

The servo status can be checked on the panel display of the SERVOPACK.
 Also, if an alarm or warning occurs, its alarm or warning number is displayed.
 For the panel display of the converter, refer to the 3.2.1 *Power Regeneration Converter*.



11.1.1 Status Display


The display shows the following status.

Display	Meaning
	Rotation Detection (/TGON) Lights if motor speed exceeds the value set in Pn502. (Factory setting: 20 min ⁻¹)
	Baseblock Lights for baseblock (Motor power OFF).
	Reference Input Lights when a reference is being input.

11.1.2 Alarm and Warning Display


If an alarm or warning occurs, the display will change in the following order.

Example: Alarm A.400



11.1.3 Hard Wire Base Block Display

If a hard wire base block (HWBB) occurs, the display will change in the following order.



11.1.4 RDY and ALM LEDs


The following table shows the meanings of the RDY and ALM lights.

Name	Color	Meaning
Ready (RDY)	Green	Lit: Control CPU operates normally. Blink: The digital operator is connected.
Alarm (ALM)	Red	During an alarm occurrence.

11.2 Basic Functions Settings

11.2.1 Spindle Motor Settings

If a spindle motor is used, set the parameters as given below by using SigmaWin+.




IMPORTANT

Make the correct settings for the items described in this section.
An incorrect setting may result in spindle motor operation failure or incorrect operation.

(1) Spindle Motor Constant Settings


Write the motor constants of the spindle motor to use to the SERVOPACK using the following procedures.

1. Prepare the motor parameter file to write to the SERVOPACK.
2. In the SigmaWin+ component main window, click **Setup**, and then click **Motor Parameter SERVOPACK Write**. A warning message appears, reminding you of the possible danger.




Click **Cancel** to return to the main window without writing motor parameters in the SERVOPACK.


3. Click **OK**. The following box appears, and the SERVOPACK starts reading the parameter information.




When the reading was completed successfully, the following box appears.




4. Click **Ref.**, and the following box appears.



5. Select the motor parameter file from Yaskawa, and then click **Open**. No information is displayed in the Motor parameter SERVOPACK write - File Select box.




6. Click **Next**. The following box appears.




Click **Cancel** to return to the main window without writing motor parameters in the SERVOPACK. Click **Back** to return to the Motor parameter SERVOPACK write - File select box.

7. Click **Write**. The following message appears.




Click **No** to cancel writing.


8. Click **Yes**. The following box appears, and the motor parameter scale writing starts.



If the motor parameters were written normally, the following box appears.



9. Click **Complete**, and the following box appears.



10. Click **OK**. Turn OFF the power and then ON again to validate the written data.

(2) Settings for the Winding Selection

Set the winding selection in Pn01E.1 to match the specifications of the spindle motor.

Parameter			Meaning
No.	Name	Setting	
Pn01E.1	Winding Selection	n.□□0□ [Factory setting]	None
		n.□□1□	Mechanical winding selection


11.2.2 Spindle Motor Rotation Direction

The direction of the motor's rotation can be determined by the combination of the /FWD signal, the /REV signal, and the speed reference voltage (SCOM).

Polarity of Speed Reference Voltage (SCOM)		Positive (+)	Negative (-)
Operation Signal	/FWD signal ON	CCW (Forward)	CW (Reverse)
	/REV signal ON	CW (Reverse)	CCW (Forward)

11.2.3 Stopping Spindle Motor after SV_OFF Command or Alarm Occurrence

The stopping method can be selected after the SV_OFF command is received or an alarm occurs.

 IMPORTANT	<ul style="list-style-type: none"> Do not use the servo drive with a load moment of inertia that exceeds the allowable value. Doing so may result in damage or failure of the resistors or power elements in the SERVOPACK. Coasting is used as the stopping method for the spindle motor if the main circuit power supply (L1, L2, L3) or the control power supply (24 V or 0 V) is turned OFF during operation without turning OFF the servo.
---	---

(1) Stopping Method for Spindle Motor after SV_OFF Command is Received

Whether the servo is ON or OFF is determined by the status of the /FWD and /REV signals.

- When Servo Is ON
 - /FWD signal is ON and /REV signal is OFF.
 - /FWD signal is OFF and /REV signal is ON.
- When Servo Is OFF
 - /FWD and /REV signals are both ON.
 - /FWD and /REV signals are both OFF.

The following table shows the status of the spindle motor for various combinations of the /FWD and /REV signals and the servo ON/OFF status.

/FWD Signal	/REV Signal	Servo ON/OFF	Spindle Motor Status
ON	ON	Servo turns OFF.	Decelerates to a stop. The current is then turned OFF.
ON	OFF	Servo ON	Operation is possible.*
OFF	ON	Servo ON	Operation is possible.*
OFF	OFF	Servo turns OFF.	Decelerates to a stop. The current is then turned OFF.

* Spindle motor operation will start when a speed reference is input while operation is enabled.

(2) Stopping Method for Spindle Motor When an Alarm Occurs

There are two types of alarms: Gr.1 and Gr.2.

Gr.1: The motor coasts to a stop.

Gr.2: The motor is stopped according to the setting in Pn00B.1 if an alarm occurs. Pn00B.1 is factory-set to stop the motor by setting the speed reference to "0." By setting Pn00B.1 to 1, the motor stops using the same method as Gr.1.

Refer to 15.2.1 *List of Alarms* to determine if the alarm that occurred is Gr.1 or Gr.2.

■ Stopping Method for Spindle Motor for Gr.1 Alarms

The stopping method of the motor when a Gr.1 alarm occurs is coasting to a stop.


■ Stopping Method for Spindle Motor for Gr.2 Alarms

Parameter	Stop Mode	Mode After Stopping	When Enabled	Classification
Pn00B				
n.□□0□ [Factory setting]	Zero-speed stopping*	Coast	After restart	Setup
n.□□1□	Coast			

* Zero-speed stopping: The speed reference is set to 0 to stop quickly.

11.2.4 Instantaneous Power Interruption Settings

If the power interruption time is shorter than 50 ms, the motor will continue operation. If it is longer than 50 ms, a power failure during converter drive operation alarm (A.41C) will occur and the motor's power will be turned OFF.



IMPORTANT

- The holding time of the control power supply (24 VDC) depends on the capability of the power supply (provision of power supply: user's responsibility). Check the power supply before using the application.
- If the load on the motor during the power interruption is large, an undervoltage alarm (A.410) or a converter DC undervoltage alarm (A.41A) may occur.

11.2.5 Setting Motor Overload Detection Level


In this SERVOPACK, the detection timing of the warnings and alarms can be changed by changing how to detect an overload warning (A.910) and overload (low load) alarm (A.720).

The overload characteristics and the detection level of the overload (high load) alarm (A.710) cannot be changed.

(1) Changing Detection Timing of Overload Warning (A.910)

The overload warning level is set by default to 20% so that an overload warning is detected in 20% of the time required to detect an overload alarm. The time required to detect an overload warning can be changed by changing the setting of the overload warning level (Pn52B). This protective function enables the warning output signal (/WARN) to serve as a protective function and to be output at the best timing for your system.

The following graph shows an example of the detection of an overload warning when the overload warning level (Pn52B) is changed from 20% to 50%. An overload warning is detected in half of the time required to detect an overload alarm.



Pn52B	Overload Warning Level				Classification
			Speed	Position	
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	1 to 100	1%	20	Immediately	Setup

(2) Changing Detection Timing of Overload (Low Load) Alarm (A.720)


An overload (low load) alarm (A.720) can be detected earlier to protect the motor from overloading. The time required to detect an overload alarm can be shortened by using the derated motor base current obtained with the following equation. The detection level of the overload (high load) alarm (A.710) cannot be changed.

$$\text{Motor base current} \times \text{Derating of base current at detecting overload of motor (Pn52C)} = \text{Derated motor base current}$$

Motor base current: Threshold value of motor current to start calculation for overload alarm
 Derating of base current at detecting overload of motor (Pn52C): Derating of motor base current

The following graph shows an example of the detection of an overload alarm when Pn52C is set to 50%. The calculation for the overload of motors starts at 50% of the motor base current and then an overload alarm will be detected earlier.

Changing the setting of Pn52C will change the detection timing of the overload alarm, so the time required to detect the overload warning will also be changed.



Pn52C	Derating of Base Current at Detecting Overload of Motor				Classification
			<input type="checkbox"/> Speed	<input type="checkbox"/> Position	
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	10 to 100	1%	100	After restart	Setup

11.2.6 Limiting Torque

This function limits the output torque to protect the machine.

Set the torque limit for motor acceleration in Pn430. Set the torque limit for motor deceleration in Pn431. The direction of motor rotation is not affected.

Pn430	Torque Limit (Powering) <input type="checkbox"/> Speed <input type="checkbox"/> Position				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 800	1%	150	Immediately	Setup
Pn431	Torque Limit (Regeneration) <input type="checkbox"/> Speed <input type="checkbox"/> Position				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 800	1%	150	Immediately	Setup

The setting unit is a percentage of the rated torque.

- Note 1. If the setting is too low, the torque may be insufficient for acceleration or deceleration of the motor.
 2. The maximum torque of the motor is used whenever the value exceeds the maximum torque.

11.3 Trial Operation

This section describes a trial operation.

11.3.1 Preparations for Trial Operation

Perform the following preparations before you perform trial operation.

Step	Item	Description	Reference
1	Installation and mounting	Install the SERVOPACK and converter according to the installation conditions and confirm that the installation conditions have been met.	4.2.1 <i>Installation Requirements</i>
2	Wiring and connections	<p>Connect the power supply and peripheral devices to the SERVOPACK and converter. Be particularly careful of the following points.</p> <ul style="list-style-type: none"> • Select peripheral devices that meet the specifications and wire them correctly. • Wire the main circuit power input terminals (L1, L2, and L3) and control power input terminals (CN7A and CN7B) correctly. • Connect the motor output terminals (U, V, and W) and motor correctly. • Connect the ground terminal (⊕) correctly. • Connect the converter and SERVOPACK correctly (including the main circuit DC power supply (P and N), control power supply (CN7A and CN7B), and local bus (CN5 and CN5A)). • Make sure that there are no loose parts on the servomotor. <p>Note: If the spindle motor has been stored for a long time before trial operation, inspect the spindle motor according to the maintenance and inspection procedures. For information on maintenance and inspections, refer to 15.1 <i>Inspection and Maintenance</i>.</p>	1.1 <i>System Configurations, Chapter 5 Wiring</i>
3	Checking the power supply voltage	<p>Confirm that the power supply voltage is correct.</p> <ul style="list-style-type: none"> • Main Circuit Power Supply Voltage 200 V Class: Three-phase 200 to 230 VAC, 50/60 Hz 400 V Class: Three-phase 380 to 480 VAC, 50/60 Hz Allowable voltage fluctuation: +10% to -15% Allowable frequency fluctuation: ±5% Voltage unbalance: 5% maximum • Control Power Supply Voltage 24 DVC Allowable voltage fluctuation: ±15% Output hold time: 100 ms minimum 	3.2.1 <i>Power Regeneration Converter</i>
4	Turning ON the control power supply	Turn ON the control power supply. An alarm will occur in the SERVOPACK.	■ <i>Panel Display in 3.2.1 (1) Basic Specifications, 11.1 Panel Display</i>
5	Setting spindle motor parameters	Use the SigmaWin+ to set the motor constants.	11.2.1 (1) <i>Spindle Motor Constant Settings</i>

(cont'd)

Step	Item	Description	Reference
6	Turning the control power supply OFF and back ON	<p>Turn the control power supply OFF and back ON.</p> <p>Normal Startup The indicators will be as follows: Converter: The READY indicator will light in green. (This indicates that the CPU in the power regeneration converter has started normally.) SERVOPACK: The RDY indicator will light in green. (This indicates that the CPU in the SERVOPACK has started normally.) The RDY indicator will blink in green. (This indicates that the digital operator is connected.)</p> <p>Error during Startup The indicators will be as follows: Converter: The READY indicator will not light. (This indicates that the CPU in the power regeneration converter did not start normally.) The ALARM indicator will light in red (This indicates that an alarm occurred.) SERVOPACK: The RDY indicator will not light. (This indicates that the CPU in the SERVOPACK did not start normally.) The ALM indicator will light in red (This indicates that an alarm occurred.)</p> <p>Check the 7-segment display and the data display on the digital operator, or check the error information on the SigmaWin+.* For details, refer to <i>Chapter 15 Inspection, Maintenance, and Troubleshooting</i>. * If the RDY indicator (green) on SERVOPACK is not lit, communications with the SigmaWin+ may not be possible.</p>	<p>■ <i>Panel Display in 3.2.1 (1) Basic Specifications, 11.1 Panel Display</i></p>
7	Setting the spindle motor	Set the winding selection in Application Function Select Switch 1E (Pn01E.1) based on the spindle motor specifications.	<i>11.2.1 Spindle Motor Settings</i>
8	Checking for alarms	Confirm that no alarms have occurred in the converter or SERVOPACK.	—
9	Turning ON the main circuit power supply	<p>Turn ON the main circuit power supply. Confirm that the converter or SERVOPACK are in the following condition. The CHARGE indicator must be lit in orange. (This indicates that the main circuit power supply is ON.) Note: The indicators that lit when the control power supply was turned ON should still be lit.</p>	<p>■ <i>Panel Display in 3.2.1 (1) Basic Specifications</i></p>
10	Checking the spindle motor cooling fan	Confirm that the air direction for the spindle motor cooling fan is correct.	—

11.3.2 Trial Operation Example

An example of trial operation is given below.

Step	Operation	Reference
1	Check the power supply and input signal circuits again, and then turn ON the control power supply to the SERVOPACK and the power supply regenerative converter.	–
2	Adjust the speed reference input gain 2 (Pn30A).	16.2 <i>List of Parameters</i>
3	Turn ON the main circuit power supply to the SERVOPACK.	–
4	Make sure that the analog speed reference (SCOM) is 0 V and then turn ON the /FWD or /REV signal. The servo will turn ON. Note: If the spindle motor shaft rotates a little even when the speed reference input is 0 V, adjust the reference offset so that the spindle motor shaft does not rotate at all.	6.1 <i>Sequence Input Signals</i> 6.2 <i>Analog Speed Reference</i>
5	Gradually increase the analog speed reference (SCOM) voltage from 0 V. The default setting is for 6 V/base speed.	
6	Check the speed reference value in the speed reference monitor (Un001).	
7	Check the motor speed in the motor speed monitor (Un000).	13.3 <i>Monitor Mode</i> (Un□□□)
8	Make sure that the values in steps 6 and 7 (i.e., Un001 and Un000) are equivalent.	
9	Check the direction of motor rotation.	–
10	Return the speed reference input to 0 V.	6.2 <i>Analog Speed Reference</i>
11	Turn OFF the /FWD or /REV signal. The servo will turn OFF.	–

11.4 Hard Wire Base Block (HWBB) Function




IMPORTANT

This HWBB function is not relevant to Machinery directive, 2006/42/EC.

The Hard Wire Base Block function (hereinafter referred to as HWBB function) is a function designed to baseblock the motor (shut off the motor current) by using the hardwired circuits.

Each circuit for two channel input signals blocks the run signal to turn off the power module that controls the motor current, and the motor current is shut off. (Refer to the diagram below.)



Note: For HWBB function signal connections, the input signal is the 0 V common and the output signal is the source output. This is opposite to other signals described in this manual. To avoid confusion, the ON and OFF status of signals for HWBB function are defined as follows:

ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.

OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.

11.4.1 Precautions for the Hard Wire Base Block (HWBB) State


Observe the following precautions in the HWBB state.

- The motor will rotate in an application where external force is applied to the motor (for example, gravity on the vertical axis). Take measures to secure the motor, such as installing a mechanical brake.
- The spindle motor coasts to a stop in case of the power module failure, etc. Make sure that safety is ensured even in that situation.
- The HWBB function does not shut off the power to the SERVOPACK or electrically isolate it. Take measures to shut off the power to the SERVOPACK when performing maintenance on it.


11.4.2 Hard Wire Base Block (HWBB) State

The SERVOPACK will be in the following state if the HWBB function operates. If the /HWBB1 or /HWBB2 signal is OFF, the HWBB function will operate and the SERVOPACK will enter a hard wire baseblock (HWBB) state.

- The HWBB function operates after the motor power is turned OFF.




- The HWBB function operates while the motor power is ON.




11.4.3 Resetting the HWBB State

Usually after the FWD and the REV signals are turned OFF and then the spindle motor power is turned OFF, the SERVOPACK will then enter a hard wire baseblock (HWBB) state with the /HWBB1 and /HWBB2 signals turned OFF. By then turning the /HWBB1 and /HWBB2 signals ON in this state, the SERVOPACK will enter a baseblock (BB) state and can receive the FWD and the REV signals.



If the /HWBB1 and /HWBB2 signals are OFF but the FWD signal or the REV signal is ON, the HWBB state will be maintained after the /HWBB1 and /HWBB2 signals are turned ON.

Turn both the FWD signal and the REV signal OFF, so the SERVOPACK will be in a BB state. Then turn the FWD signal or the REV signal ON again.




Note: Even if the motor power is turned OFF by turning OFF the main circuit power, the HWBB status is retained until the FWD and the REV signals are turned OFF.

11.4.4 Error Detection in HWBB Signal

If only the /HWBB1 or /HWBB2 signal is input, an A.Eb1 alarm (HWBB Function Signal Input Timing Error) will occur unless the other signal is input within 10 seconds. This makes it possible to detect failures, such as disconnection of the HWBB signals.

11.4.5 Connection Example and Specifications of Input Signals (HWBB Signals)

A connection example and specifications of input signals (HWBB signals) are shown below.




IMPORTANT

For HWBB function signal connections, the input signal is the 0 V common and the output signal is the source output. This is opposite to other signals described in this manual. To avoid confusion, the ON and OFF status of signals for HWBB function are defined as follows:

ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.

OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.

(1) Connection Example




(2) Specifications

Type	Signal Name	Pin No.	Status	Meaning
Input	/HWBB1	CN12-3	ON	Does not use the HWBB function. (normal operation)
		CN12-4	OFF	Uses the HWBB function. (motor current shut-off request)
	/HWBB2	CN12-5	ON	Does not use the HWBB function. (normal operation)
		CN12-6	OFF	Uses the HWBB function. (motor current shut-off request)

The input signals (HWBB signals) have the following electrical characteristics.

Items	Characteristics	Remarks
Internal Impedance	6.8 kΩ	—
Operation Movable Voltage Range	+24 V±5%	—
Maximum Delay Time	20 ms	Time from the /HWBB1 and /HWBB2 signals are OFF to the HWBB function operates.

If the HWBB function is requested by turning OFF the /HWBB1 and /HWBB2 input signals on the two channels, the power supply to the motor will be turned OFF within 20 ms (see below).



Note: The OFF status is not recognized if the total OFF time of the /HWBB1 and /HWBB2 signals is 0.5 ms or shorter.

11.4.6 Operation with SigmaWin+

The HWBB function works while the SERVOPACK operates with SigmaWin+.

If any of the following utility functions is being used with the /HWBB1 and /HWBB2 signals turned OFF, the SERVOPACK cannot be operated by turning ON the /HWBB1 and /HWBB2 signals. Cancel the utility function first, and then set the SERVOPACK to the utility function mode again and restart operation.

- JOG operation
- Origin search
- Program JOG operation
- Automatic offset-adjustment of motor current detection signal

11.4.7 External Device Monitor (EDM)

The external device monitor (EDM) functions to monitor failures in the HWBB function. The relation of the EDM, /HWBB1, and /HWBB2 signals is shown below.

Signal Name	Logic			
/HWBB1	ON	ON	OFF	OFF
/HWBB2	ON	OFF	ON	OFF
EDM	OFF	OFF	OFF	ON



IMPORTANT

For HWBB function signal connections, the input signal is the 0 V common and the output signal is the source output. This is opposite to other signals described in this manual. To avoid confusion, the ON and OFF status of signals for HWBB function are defined as follows:

ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.


OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.

■ Failure Detection Signal for EDM Signal

Detection of failures in the EDM circuit can be checked using the following four status of the EDM signal in the table.

■ Connection Example

The following diagram shows an example of the connections required for the EDM signal.



■ Specifications

Type	Signal Name	Pin No.	Status	Meaning
Out-put	EDM	CN12-7 CN12-8	ON	The base blocks established by both the /HWBB1 and the /HWBB2 signals are working normally.
			OFF	The base blocks established by the /HWBB1, the /HWBB2, or both signals are not working normally.


Electrical characteristics of EDM signal are as follows.

Items	Characteristics	Remarks
Maximum Input Voltage	30 VDC	—
Maximum Current	50 mADC	—
Maximum Voltage Drop at ON	3.5 V	Voltage between EDM1+ and EDM1- when current is 50 mA
Maximum Delay Time	20 ms	Time from the change in /HWBB1 or /HWBB2 until the change in EDM

11.4.8 Application Example of HWBB Function

An example of using HWBB function is shown below.

(1) Connection Example




When a guard opens, both of signals, the /HWBB1 and the /HWBB2, turn OFF, and the EDM signal is ON. Since the feedback is ON when the guard closes, the device is reset, and the /HWBB1 and the /HWBB2 signals turn ON, and the operation becomes possible.

(2) Failure Detection Method

In case of a failure such as the /HWBB1 or the /HWBB2 signal remains ON, the device is not reset when the guard closes because the EDM signal keeps OFF. Therefore starting is impossible, then the failure is detected.

In this case, an error in the external device, disconnection or short-circuiting of the external wiring, or a failure in the SERVOPACK must be considered. Find the cause and correct the problem.

(3) Usage Example




11.4.9 Confirming HWBB Function

When starting the equipment or replacing the SERVOPACK for maintenance, be sure to conduct the following confirmation test on the HWBB function after wiring.

- Make sure that the seven-segment display or Digital Operator displays Hbb/HBB and that the motor does not operate when the /HWBB1 and /HWBB2 signals are OFF.
- You can check the ON/OFF status of the /HWBB1 and /HWBB2 signals in bit 7 of Un005.
Note: If the monitor display does not agree with the signal ON/OFF status, there may be an error in the external device, the external wiring may be disconnected or short-circuited, or the SERVOPACK may be faulty. Find and correct the problem.
- Use a feedback circuit input indicator or similar method on the connected device and make sure that the EDM signal is OFF during normal operation.

11.4.10 Attaching the HWBB Jumper Connector

If you do not use the HWBB function, attach the enclosed HWBB jumper connector to CN12.



Adjustments

- 12.1 Adjustments 12-2
- 12.2 Monitoring Analog Signals 12-3
 - 12.2.1 CN6 Connector for Analog Monitor 12-3
 - 12.2.2 Monitor Signal 12-3
 - 12.2.3 Setting Monitor Factor 12-4
 - 12.2.4 Related Parameters 12-5
- 12.3 Anti-Resonance Control Adjustment Function 12-6
 - 12.3.1 Anti-Resonance Control Adjustment Function 12-6
 - 12.3.2 Related Parameters 12-16

12.1 Adjustments

Adjustments (tuning) are performed to optimize the responsiveness of the SERVOPACK.


The responsiveness is determined by the servo gain that is set in the SERVOPACK.

The servo gain is set using a combination of parameters, such as speed loop gain, filters, moment of inertia ratio. These parameters influence each other. Therefore, the servo gain must be set considering the balance between the set values.

Generally, the responsiveness of a machine with high rigidity can be improved by increasing the servo gain. If the servo gain of a machine with low rigidity is increased, however, the machine will vibrate and the responsiveness may not be improved. In such case, it is possible to suppress the vibration with a variety of vibration suppression functions in the SERVOPACK.

The servo gain is adjusted at the factory. You normally do not need to adjust it, but sometimes adjustment is required depending on the condition of your machine.

If necessary, use the following flowchart to make the adjustment.




12.2 Monitoring Analog Signals

Check the operating status of the machine and signal waveform when adjusting the servo gain. Connect a measuring instrument, such as a memory recorder, to analog monitor connector (CN6) on the SERVOPACK to monitor analog signal waveform.

The settings and parameters for monitoring analog signals are described in the following sections.

12.2.1 CN6 Connector for Analog Monitor


To monitor analog signals, connect a measuring instrument with cable (JZSP-CA01-E) to the CN6 connector.



Line Color	Signal Name	Factory Setting
White	Analog monitor 1	Torque reference: 1 V/100% rated torque
Red	Analog monitor 2	Motor speed: 1 V/1000 min ⁻¹
Black (2 lines)	GND	Analog monitor GND: 0 V

12.2.2 Monitor Signal

The shaded parts in the following diagram indicate analog output signals that can be monitored.



The following signals can be monitored by selecting functions with parameters Pn006 and Pn007. Pn006 is used for analog monitor 1 and Pn007 is used for analog monitor 2.

Parameter		Description		
		Monitor Signal	Unit	Remarks
Pn006 Pn007	n.□□00 [Pn007 Factory Setting]	Motor speed	1 V/1000 min ⁻¹	—
	n.□□01	Speed reference	1 V/1000 min ⁻¹	—
	n.□□02 [Pn006 Factory Setting]	Torque reference	1 V/ (Max. torque/1.2)	—
	n.□□03	Position error	0.05 V/1 pulse	0 V at speed/torque control
	n.□□05	Position reference speed	1 V/1000 min ⁻¹	—
	n.□□06	Reserved	—	—
	n.□□08	Positioning completed	Completed: 5 V Not completed: 0 V	Completion indicated by output voltage.
	n.□□0B	Reserved	—	—
	n.□□0C	Completion of position reference	Completed: 5 V Not completed: 0 V	Completion indicated by output voltage.
	n.□□46	Load meter	6 V/100%	—

12.2.3 Setting Monitor Factor



The output voltages on analog monitors 1 and 2 are calculated by the following equations.

$$\text{Analog monitor 1 output voltage} = (-1) \times \left(\begin{array}{l} \text{Signal selection} \\ (\text{Pn006}=\text{n.00}\square\square) \end{array} \times \begin{array}{l} \text{Multiplier} \\ (\text{Pn552}) \end{array} + \begin{array}{l} \text{Offset voltage [V]} \\ (\text{Pn550}) \end{array} \right)$$

$$\text{Analog monitor 2 output voltage} = (-1) \times \left(\begin{array}{l} \text{Signal selection} \\ (\text{Pn007}=\text{n.00}\square\square) \end{array} \times \begin{array}{l} \text{Multiplier} \\ (\text{Pn553}) \end{array} + \begin{array}{l} \text{Offset voltage [V]} \\ (\text{Pn551}) \end{array} \right)$$

<Example>

Analog monitor output at n.□□00 (motor speed setting)



Note: Linear effective range: within ± 8 V
Output resolution: 16-bit

12.2.4 Related Parameters

Use the following parameters to change the monitor factor and the offset.

Pn550	Analog Monitor 1 Offset Voltage [Speed] [Position]				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	-10000 to 10000	0.1 V	0	Immediately	Setup
Pn551	Analog Monitor 2 Offset Voltage [Speed] [Position]				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	-10000 to 10000	0.1 V	0	Immediately	Setup
Pn552	Analog Monitor Magnification (× 1) [Speed] [Position]				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	-10000 to 10000	× 0.01	100	Immediately	Setup
Pn553	Analog Monitor Magnification (× 2) [Speed] [Position]				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	-10000 to 10000	× 0.01	100	Immediately	Setup

12.3 Anti-Resonance Control Adjustment Function

This section describes the anti-resonance control adjustment function.


Note: Anti-resonance control adjustment function can be executed from the SigmaWin+ or from a Digital Operator. This section provides details on anti-resonance control adjustment function and describes how to perform it with the SigmaWin+. Refer to *13.4.20 Anti-Resonance Control Adjustment Function (Fn204)* for the procedure to execute anti-resonance control adjustment with the Digital Operator.

12.3.1 Anti-Resonance Control Adjustment Function


The anti-resonance control adjustment function increases the effectiveness of the vibration suppression after adjusting servo gains. This function is effective in supporting anti-resonance control adjustment if the vibration frequencies are from 100 to 1,000 Hz.

Use this function only if fine-tuning is required, or vibration detection is failed and readjustment is required.

Adjust servo gains to increase the responsiveness after performing this function.

 IMPORTANT	<ul style="list-style-type: none"> • This function detects vibration between 100 and 1,000 Hz. Vibration will not be detected for frequencies outside of this range, and instead, "F----" will be displayed. • Vibration can be reduced more effectively by increasing the anti-resonance damping gain (Pn163). The amplitude of vibration may become larger if the damping gain is excessively high. Increase the damping gain from about 0% to 200% in 10% increments while checking the effect of vibration reduction. If the effect of vibration reduction is still insufficient at a gain of 200%, cancel the setting, and lower the servo gain.
---	---

(1) Preparation

 WARNING
<ul style="list-style-type: none"> • Before you execute anti-resonance adjustment function, make sure that the moment of inertia ratio (Pn103) is set correctly. If the setting of the moment of inertia is not correct, normal control may not be possible and vibration may occur. • Make sure that a trial operation has been performed without any trouble. Failure to observe this warning may result in injury or damage to the product. • Install a safety brake on the machine. Failure to observe this warning may result in injury or damage to the product.

Check the following settings before performing anti-resonance control adjustment function.

The message "NO-OP" indicating that the settings are not appropriate will be displayed, if the following condition is not met.

- The write prohibited setting (Fn010) must not be set to write-protect parameters.
- The main circuit power supply must be ON.
- All alarms must be cleared.
- The hard wire base block (HWBB) must be disabled.
- Torque limit is set correctly.
For details, refer to *11.2.6 Limiting Torque*.

(2) Anti-Resonance Control Adjustment Function Operating Procedure

With this function, an operation reference is sent, and the function is executed while vibration is occurring.

Anti-resonance control adjustment function is performed from the SigmaWin for Σ -V-SD (MT). The following methods can be used for the anti-resonance control adjustment function.

- With Undetermined Vibration Frequency
- With Determined Vibration Frequency

The operating procedure from the SigmaWin+ is described here.


WARNING

- When this function is executed, the related parameters will be set automatically. This may cause the response characteristics to vary greatly before and after execution of this function. To ensure safety, make sure that an emergency stop can be applied at any time.
Failure to observe this warning may result in injury or damage to the product.
- Do not touch the rotating section of the motor while power is being supplied to the motor.
Failure to observe this warning may result in injury or damage to the product.
- Be sure to carefully read the SigmaWin+ Operation Manual before executing this function.
Special care must be taken for the following.
 - Before executing this function, make sure that the emergency stop (power off) can be activated when needed.
This function will automatically set parameters when used. As a result, the response speeds may change considerably after execution. Before executing this function, make sure that the emergency stop (power off) can be activated when needed.
 - The moment of inertia (mass) must be correctly set to execute this function.
If it is not correctly set, satisfactory anti-resonance control cannot be achieved.
 - This function is generally only used to adjust the servo gain, as you should avoid considerable change in the frequency.
If the frequency is changed while the anti-resonance control adjustment function is being used, the current anti-resonance control effect will be lost. Care must be taken when automatic frequency detection is executed in Auto Detect mode.
 - If vibration cannot be suppressed by executing this function, cancel execution and reduce the servo gain by other methods such as custom tuning.
 - Use an adjustment method such as custom tuning to improve response characteristics after executing this function.
When the servo gain is increased during an adjustment such as custom tuning, vibration may be generated again. In this case, execute the anti-resonance control adjustment function again for fine adjustment.

The anti-resonance control adjustment function supports the adjustment of anti-resonance control effective for vibration frequencies from 100 to 1,000 Hz when servo gain is increased. Vibration can be suppressed by setting vibration frequency by auto detection or by manual setting to adjust damping gain. Input a reference and execute this function when there is vibration.


■ With Undetermined Vibration Frequency

1. In the SigmaWin+ component main window, click **Tuning** and then click **Tuning**.




Click **Cancel** to return to the SigmaWin for Σ -V-SD (MT) component main window without executing tuning.


2. Click **Execute**. The following window appears.




3. Click **Advanced adjustment**. The following box appears.




4. Click **Custom tuning**. The following box appears.




5. Select the tuning mode from the **Tuning mode** box and the mechanism from the **Mechanism selection** box, and then click **Next**. The following box appears.




- Enter the correct moment of inertia ratio and then click **Next**. The following window appears.




- Click **Anti-res Ctrl Adj**. The following window appears.



8. Click **Auto Detect** to set the frequency and click **Start adjustment**. The following window appears.



9. Adjust the damping gain by clicking the setting arrows.




Click **Reset** to reset the settings to their original values during adjustment.

10. When tuning is completed, click the **Finish** Button. The settings that were changed will be saved in the SERVOPACK, and the main Tuning Dialog Box will appear again.


■ With Determined Vibration Frequency

1. In the SigmaWin+ component main window, click **Tuning** and then click **Tuning**.




Click **Cancel** to return to the SigmaWin for Σ -V-SD (MT) component main window without executing tuning.


2. Click **Execute**. The following window appears.




3. Click **Advanced adjustment**. The following box appears.




4. Click **Custom tuning**. The following box appears.




5. Select the tuning mode from the **Tuning mode** box and the mechanism from the **Mechanism selection** box, and then click **Next**. The following box appears.




- Enter the correct moment of inertia ratio and then click **Next**. The following window appears.




- Click **Anti-res Ctrl Adj**. The following window appears.



- Click **Manual Set** to set the frequency and click **Start adjustment**. The following window appears.




- Adjust the frequency by clicking the setting arrows.



Click **Reset** to reset the settings to their original values during adjustment.

- Adjust the damping gain by clicking the setting arrows.



Click **Reset** to reset the settings to their original values during adjustment.

- When tuning is completed, click the **Finish** Button. The settings that were changed will be saved in the SERVOPACK, and the main dialog box in step 6 will appear again.

12.3.2 Related Parameters

The following table lists parameters related to this function and their possibility of being changed while executing this function or of being changed automatically after executing this function.

- Parameters related to this function

These are parameters that are used or referenced when executing this function.

- Allowed changes during execution of this function

Yes : Parameters can be changed using SigmaWin+ while this function is being executed.

No : Parameters cannot be changed using SigmaWin+ while this function is being executed.

- Automatic changes after execution of this function

Yes : Parameter set values are automatically set or adjusted after execution of this function.

No : Parameter set values are not automatically set or adjusted after execution of this function.

Parameter	Name	Mid-execution Changes	Automatic Changes
Pn160	Anti-Resonance Control Related Switch	Yes	Yes
Pn161	Anti-Resonance Frequency	No	Yes
Pn162	Anti-Resonance Gain Compensation	Yes	No
Pn163	Anti-Resonance Damping Gain	No	Yes
Pn164	Anti-Resonance Filter Time Constant 1 Compensation	Yes	No
Pn165	Anti-Resonance Filter Time Constant 2 Compensation	Yes	No


Digital Operator

13.1 Overview	13-2
13.1.1 Part Names and Functions	13-3
13.1.2 Switching Mode	13-5
13.2 Parameter Mode	13-6
13.2.1 Parameter Setting	13-6
13.3 Monitor Mode (Un□□□)	13-9
13.3.1 Monitor Items	13-9
13.3.2 Monitor Mode Display	13-13
13.4 Utility Functions (Fn□□□)	13-14
13.4.1 Utility Functions List	13-14
13.4.2 Operations	13-16
13.4.3 Alarm History Display (Fn000)	13-17
13.4.4 JOG Operation (Fn002)	13-18
13.4.5 Origin Search (Fn003)	13-20
13.4.6 Program JOG Operation (Fn004)	13-22
13.4.7 Initializing Parameter Settings (Fn005)	13-26
13.4.8 Clearing Alarm History (Fn006)	13-27
13.4.9 Automatic Tuning of Analog Speed Reference Offset (Fn009)	13-28
13.4.10 Manual Servo-tuning of Speed Reference Offset (Fn00A)	13-29
13.4.11 Offset Adjustment of Analog Monitor Output (Fn00C)	13-30
13.4.12 Gain Adjustment of Analog Monitor Output (Fn00D)	13-31
13.4.13 Automatic Offset-Signal Adjustment of the Motor Current Detection Signal (Fn00E)	13-32
13.4.14 Manual Offset-Signal Adjustment of the Motor Current Detection Signal (Fn00F)	13-33
13.4.15 Write Prohibited Setting (Fn010)	13-35
13.4.16 Software Version Display (Fn012)	13-37
13.4.17 Display of SERVOPACK and Motor ID (Fn01E)	13-38
13.4.18 Turnup Function (Fn024)	13-39
13.4.19 Load Ratio Meter Output Gain Adjustment (Fn025)	13-40
13.4.20 Anti-Resonance Control Adjustment Function (Fn204)	13-42


13.1 Overview

The JUSP-OP05A-1-E digital operator is used to set and display the SERVOPACK parameters.

Note: Connect the digital operator to the CN3 connector of the power regeneration converter.



13.1.1 Part Names and Functions












(1) LED Display

The digital operator has an LCD display with a maximum of 17 characters for each of the 5 lines. It also has 5 LED indicators to show the status of the servo ON, positioning completion, and others. Details of the LED indicators are as follows.

Name	Function
SVON	Lit when the servo is ON. Unlit when the servo is OFF.
COIN VCMP	Lit when positioning is completed. Lit when the speed is coincident.
TGON	Lit while the motor is running.
REF	Lit when the speed reference input is greater than the setting value of Pn502.
CHARGE	Lit when the main circuit power supply is ON.


(2) Operation Keys


Operation Key	Main Function
	Resets the alarm. (The alarm cannot be reset unless the cause of the alarm is removed.)
	Switches the display mode of digital operator.
	<ul style="list-style-type: none"> Switches the cursor position between the parameter number and the setting when setting a parameter. Saves the parameter setting in the SERVOPACK. Opens the selected utility function display in the utility function mode.
	<ul style="list-style-type: none"> Moves the cursor up or down in parameter/monitor mode. Moves the cursor four lines up in the utility function mode.
	Switches between the servo ON and servo OFF signals while executing a utility function. Example: JOG operation
	Moves the cursor to left or right in parameter/monitor mode.
	<ul style="list-style-type: none"> Switches between parameters (Pn) and monitors (Un). Increases or decreases the parameter number, setting data, monitor number, and utility function number. Rotates the motor in a forward or reverse direction at a JOG operation.
	This operation key cannot be used for a Σ -V-SD series SERVOPACK for speed reference with analog voltage.
	Saves the status of the current display. The initial display will be recorded when the power supply is turned ON again.

Note: A cursor is a pointer that is flashing on the screen.


13.1.2 Switching Mode

Connect the digital operator to the power regeneration converter, and turn ON the power to the power regeneration converter. The initial display appears, and then the parameter/monitor mode display appears.

Press the  Key to change the mode.



An abbreviation of the name of the active mode is displayed in the upper right, and the SERVOPACK status is displayed in the upper left.



Note: Alarm Display for Communication Errors

If a communications error occurs between the Σ -V-SD Driver and digital operator, the following communications error codes are displayed. These errors may be caused by incorrect connector connection. Check the connection and correct it. Then, turn the power OFF and ON. If the communications error message still appears, replace the digital operator or the Σ -V-SD Driver.



13.2 Parameter Mode

This section describes how to display and set parameters in the parameter/monitor mode.

There are two types of notation used for parameters, one for parameter that requires a value setting (parameter for numeric settings) and one for parameter that requires the selection of a function (parameter for selecting functions).



























- Note 1. For details on the parameters, refer to 16.2 List of Parameters.
 2. To indicate a specific digit of a parameter that must be set or that has a specific meaning, the digit number is added to the parameter number. For example, Pn006.0 indicates the 1st digit of parameter Pn006.

13.2.1 Parameter Setting





(1) Operation Example 1: Setting the Parameters for Selecting Functions

There are some parameters which require the setting of each digit such as Pn01E (Application Function Select Switch 1E).

This example shows the operation procedure to set “1” (Mechanical winding selection) for Pn01E.1 (Winding Selection) of Pn01E (Application Function Select Switch 1E).

Step	Display after Operation	Keys	Operation
1	<pre>1:BB -PRM/MON- Un000= 00000 Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>		Press the  Key to select the parameter/monitor mode.
2	<pre>1:BB -PRM/MON- Un000= 00000 Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>	 	Press the  or  Key to move the cursor to “Un.”
3	<pre>1:BB -PRM/MON- Pn000= n.0000 Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>	 	Press the  or  Key to switch “Un” to “Pn.”
4	<pre>1:BB -PRM/MON- Pn000= n.0000 Un002= 00000 Un008= 00000puls e Un00D= 0000000000</pre>		Press the  Key once to move the cursor to the digit on the right side of “Pn.”
5	<pre>1:BB -PRM/MON- Pn01E= 00500 Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>	   	Use the following keys to display Pn01E. To move to another digit:  and  Keys To change the numeric value:  and  Keys
6	<pre>1:BB -PRM/MON- Pn01E= n.000<u>3</u> Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>		Press the  Key to move the cursor to the setting side (to the position of the first digit of Pn01E.1).
7	<pre>1:BB -PRM/MON- Pn01E= n.00<u>0</u>3 Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>	 	Click the  or  Key to move the cursor to the first digit.























(cont'd)

Step	Display after Operation	Keys	Operation
8	<pre>1:BB -PRM/MON- Pn01E=n.001<u>3</u> Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>		Press the  Key once to set “1” for the first digit of Pn01E.1.
9	<pre>1:A.941 -PRM/MON- Pn01E=n.0013 Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>		Press the  Key. The new setting of Pn01E is written to the SERVO-PACK. The cursor moves to the parameter number side and the warning A.941 is displayed.
10	To enable the change in the setting, turn the power OFF and ON again.*		







* If you change the setting of a parameter that requires the power supply to be restarted to apply the change, the warning A.941 (Parameter Needing Power Restart After Change) is displayed. Restart the power supply to enable the new setting. The warning will no longer be displayed.



(2) Operation Example 2: Setting the Parameters for Numeric Settings

This example shows the operation procedure to set “1000” (min⁻¹) for Pn304 (JOG speed).

Step	Display after Operation	Keys	Operation
1	<pre>1:BB -PRM/MON- Un00<u>0</u>= 00000 Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>		Press the  Key to select the parameter/monitor mode.
2	<pre>1:BB -PRM/MON- Un000= 00000 Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>	 	Press the  or  Key to move the cursor to “Un.”
3	<pre>1:BB -PRM/MON- Pn000=n.00000 Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>	 	Press the  or  Key to switch “Un” to “Pn.”
4	<pre>1:BB -PRM/MON- Pn<u>0</u>00=n.00000 Un002= 00000 Un008= 00000 pulse Un00D= 0000000000</pre>		Press the  Key once to move the cursor to the right side of “Pn.”
5	<pre>1:BB -PRM/MON- Pn<u>3</u>04=00500 Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>	   	Press the arrow keys to display “Pn304.” To move the cursor to different columns:  ,  Key To change the settings:  or  Key
6	<pre>1:BB -PRM/MON- Pn304=0050<u>0</u> Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>		Press the  Key. The cursor moves to the setting side (to the position of the first digit of Pn304).

(cont'd)

Step	Display after Operation	Keys	Operation
7	<pre> 1:BB -PRM/MON- Pn304=00<u>5</u>00 Un002= 00000 Un008= 0000000000 Un00D= 0000000000 </pre>		Press the  Key twice to move the cursor to the third digit of Pn304.
8	<pre> 1:BB -PRM/MON- Pn304=01<u>0</u>00 Un002= 00000 Un008= 0000000000 Un00D= 0000000000 </pre>		Press the  Key five times to change the setting to "1000."
9	<pre> 1:BB -PRM/MON- Pn304=01000 Un002= 00000 Un008= 0000000000 Un00D= 0000000000 </pre>		Press the  Key to write the settings. The cursor moves to the parameter number side.

Note: If the  Key has not been pressed but the  Key has been pressed to select another mode such as the utility function mode, any changes that have been made to the parameter will be saved in the SERVOPACK.

13.3 Monitor Mode (Un□□□)

This section describes available monitor modes and operation procedures in the parameter/monitor mode.


13.3.1 Monitor Items

Parameter No.	Content of Display	Unit	Reference
Un000	Motor rotating speed	min ⁻¹	–
Un001	Speed reference	min ⁻¹	–
Un002	Internal torque reference (in percentage to the maximum torque (120% of the rated torque))	%	–
Un003	Electric angle 1 (32-bit decimal notation)	Encoder pulse	–
Un005	Input signal monitor	–	13.3.1 (1) Input Signal Monitor (Un005) ON/OFF Status
Un006	Output signal monitor	–	13.3.1 (2) Output Signal Monitor (Un006) ON/OFF Status
Un007	Input reference pulse speed (Valid only for the orientation operation.)	min ⁻¹	–
Un008	Position error amount (Valid only for the orientation operation.)	Pulse	–
Un009	Accumulated load ratio (in percentage to the maximum torque (120% of the rated torque): effective torque in cycle of 10 seconds)	%	–
Un00C	Input reference pulse counter	Pulse	–
Un00D	Feedback pulse counter	Encoder pulse	–
Un00E	Load shaft feedback pulse counter	Encoder pulse	–
Un00F	Load shaft speed	min ⁻¹	–
Un012	Total run time	100 ms	–
Un013	Feedback pulse counter	Pulse	–
Un014	Effective gain monitor (gain settings 1 = 1, gain settings 2 = 2)	–	–
Un030	Motor temperature	0.1°C	–
Un032	Load meter	0.1%	–
Un033	Input signal monitor 2	–	13.3.1 (3) Input Signal Monitor 2 (Un033) ON/OFF Status
Un034	Output signal monitor 2	–	13.3.1 (4) Output Signal Monitor 2 (Un034) ON/OFF Status
Un035	Input signal monitor 2	–	13.3.1 (5) Input Signal Monitor 3 (Un035) ON/OFF Status
Un036	Status monitor	–	13.3.1 (6) Status Monitor (Un036) ON/OFF Status
Un03A	AD conversion value of magnetic sensor level (AD conversion value of magnetic sensor signal)	–	–


(cont'd)

Parameter No.	Content of Display	Unit	Reference
Un03B	Position monitor (Orientation control with a motor encoder: The actual position based on the set origin and displayed in divisions of the motor encoder resolution per rotation, Orientation control with an external encoder: The actual position based on the set origin and displayed in divisions of the external encoder resolution per rotation, Orientation control with a magnetic sensor: The actual position displayed in 4,096 divisions per rotation)	pulse	—
Un03C	Stop reference position (Orientation control with a motor encoder: The stop reference position based on the set origin and displayed in divisions of the motor encoder resolution per rotation, Orientation control with an external encoder: The stop reference position based on the set origin and displayed in divisions of the external encoder resolution per rotation, Orientation control with a magnetic sensor: The stop reference position displayed in 4,096 divisions per rotation)	pulse	—
Un03D	Position error (Pulse deviation between the stop reference position and the position monitor value)	pulse	—
Un03E	Positioning time (Time from orientation signal input to completion signal output)	ms	—
Un134	Winding selection internal signal monitor	—	—


(1) Input Signal Monitor (Un005) ON/OFF Status



The LED of digital operator shows signal status as follows.



(2) Output Signal Monitor (Un006) ON/OFF Status




The LED of digital operator shows signal status as follows. The undefined digits are displayed in the lower portion.

8	7	6	5	4	3	2	1	Digit number
FLT	/FLTL	/CHWE	/ORE	/SDET	CC*1	/AGR	/ZSPD	Function
Alarm	Alarm	Low-speed winding	Completed	ON*2	Low-speed winding	Speed agreed	Detected	Top row
Normal	Normal	High-speed winding	Not completed	OFF*3	High-speed winding	Speed not agreed	Not detected	Bottom row

- *1. CC: Output to winding selection device
- *2. ON: Indicates that the motor is rotating below the set value for the motor speed.
- *3. OFF: Indicates that the motor is rotating at or above the set value for the motor speed.


(3) Input Signal Monitor 2 (Un033) ON/OFF Status



The LED of digital operator shows signal status as follows. The undefined digits are displayed in the lower portion.

8	7	6	5	4	3	2	1	Digit number
		/DAS	/MGR	/LGR	/PPI	/TLL	/TLH	Function
		OFF	OFF	OFF	OFF	OFF	OFF	Top row
		ON	ON	ON	ON	ON	ON	Bottom row


(4) Output Signal Monitor 2 (Un034) ON/OFF Status



The LED of digital operator shows signal status as follows. The undefined digits are displayed in the lower portion.

8	7	6	5	4	3	2	1	Digit number
/FC3	/FC2	/FC1	/FC0	/TALM	/ORG	/TLE	/TDET	Function
1	1	1	1	Warning	ON	Performing	Detected	Top row
0	0	0	0	Normal	OFF	Not performed	Not detected	Bottom row

(5) Input Signal Monitor 3 (Un035) ON/OFF Status




The LED of digital operator shows signal status as follows. The undefined digits are displayed in the lower portion.

8	7	6	5	4	3	2	1	Digit number
					ESP	CA1, CA2*	HWBB	Function
					Emergency stop release	Low-speed winding	HWBB	Top row
					Emergency stop	High-speed winding	Normal	Bottom row

* CA1, CA2: Answer from winding selection device

(6) Status Monitor (Un036) ON/OFF Status



The LED of digital operator shows signal status as follows. The undefined digits are displayed in the lower portion.

8	7	6	5	4	3	2	1	Digit number
				INC	Change gear ratio (L)	Change gear ratio (M)	Change gear ratio (H)	Function
				OFF	Select	Select	Select	Top row
				ON	Not selected	Not selected	Not selected	Bottom row

13.3.2 Monitor Mode Display

• Operation Example

Select Un000 (Motor speed) on the first line, Un002 (Internal torque reference) on the second line, Un005 (Input signal monitor) on the third line, and Un006 (Output signal monitor) on the fourth line, and then save the display.

The following example shows when changing the displayed factory setting items.

<pre>1:BB -PRM/MON- Un000= 00000 Un002= 00000 Un005= ██████████ Un006= ██████████</pre>	<p>← Motor speed</p> <p>← Internal torque reference</p> <p>← Input signal monitor</p> <p>← Output signal monitor</p>
--	--

Step	Display after Operation	Keys	Operation
1	<pre>1:BB -PRM/MON- Un00<u>0</u>= 00000 Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>		Press the Key to select the parameter/monitor mode.
2	<pre>1:BB -PRM/MON- Un000= 00000 Un002= 00000 Un008= 0000000000 Un00<u>D</u>= 0000000000</pre>		Press the Key once to move the cursor to the fourth line.
3	<pre>1:BB -PRM/MON- Un000= 00000 Un002= 00000 Un008= 0000000000 Un00<u>6</u>= ██████████</pre>	 or 	Press the or Key to display Un006 (Output signal monitor).
4	<pre>1:BB -PRM/MON- Un000= 00000 Un002= 00000 Un00<u>8</u>= 0000000000 Un006= ██████████</pre>		Press the Key once to move the cursor to the line above.
5	<pre>1:BB -PRM/MON- Un000= 00000 Un002= 00000 Un00<u>5</u>= ██████████ Un006= ██████████</pre>	 or 	Press the or Key to display Un005 (Input signal monitor). The desired items are displayed.
6	<pre>1:BB -PRM/MON- Un000= 00000 Un002= 00000 Un00<u>5</u>= ██████████ Un006= ██████████</pre>		Press the Key. The LED on the key blinks and the display with selected items is saved. Note: Do not turn OFF the SERVOPACK's control power while saving.

13.4 Utility Functions (Fn□□□)

Utility functions are used to execute the functions related to spindle motor operation and adjustment. This section explains the settings and the operations of the utility functions.

13.4.1 Utility Functions List

The following table shows a list of utility functions.

Note: The utility function marked with a “✓” in Servo ON column is disabled when the /S-ON (Servo ON) input signal is ON. “NO-OP” is displayed when the Utility Function Mode main menu display is switched to each utility function display.

Function No.	Name	Function	Servo ON Status
Fn000	Alarm history display	Displays the history up to the last 10 alarms.	–
Fn002	JOG operation	Runs the motor using the operation keys on the digital operator.	✓
Fn003	Origin search	Runs the motor using the operation keys on the digital operator and stop the motor at the detected phase-C position.	✓
Fn004	Program JOG operation	Runs the motor in the pre-programmed motion pattern.	✓
Fn005	Initializing parameter settings	Initializes the settings of parameters to the factory setting.	✓
Fn006	Clearing alarm history	Clears the alarm history.	–
Fn008*	Initializing absolute encoder and resetting encoder alarm	–	–
Fn009	Automatic tuning of analog speed reference offset	Adjusts automatically the speed analog reference offset.	✓
Fn00A	Manual servo turning of speed reference offset	Adjusts manually the speed reference offset.	–
Fn00B*	Manual servo turning of torque reference offset	–	–
Fn00C	Offset adjustment of analog monitor output	Adjusts manually the analog monitor output offset.	–
Fn00D	Gain adjustment of analog monitor output	Adjusts manually the analog monitor output gain.	–
Fn00E	Automatic offset-signal adjustment of the motor current detection signal	Adjusts automatically the motor current detection offset.	✓
Fn00F	Manual offset-signal adjustment of the motor current detection signal	Adjusts manually the motor current detection offset.	–
Fn010	Write prohibited setting	Prohibits or permits overwriting the parameter.	–
Fn011*	Motor model display	–	–
Fn012	Software version display	Displays the software version number of the SERVOPACK.	–
Fn013*	Multiturn limit value setting change when a multiturn limit disagreement alarm (A.CC0) occurs	–	–
Fn014*	Resetting configuration error in option modules	–	–
Fn01B*	Vibration detection level initialization	–	–


(cont'd)




Function No.	Name	Function	Servo ON Status
Fn01E	Display of SERVOPACK and motor ID	Displays the SERVOPACK ID, motor ID, and encoder ID that are stored in the SERVOPACK.	–
Fn01F*	Display of motor ID in feedback option module	–	–
Fn020*	Origin setting	–	–
Fn024	Turnup	Adjusts load shaft encoder orientation and magnetic sensor orientation.	✓
Fn025	Load ratio meter output gain adjustment	Manually adjusts the gain of the load ratio meter output.	–
Fn030*	Software reset	–	–
Fn080*	Polarity detection	–	–
Fn200*	Tuning-less levels setting	–	–
Fn201*	Advanced autotuning	–	–
Fn202*	Advanced autotuning by reference	–	–
Fn204	Anti-resonance control adjustment function	Suppresses continuous vibration (trembling) of approximately 100 Hz to 1,000 Hz.	–
Fn205*	Vibration suppression function	–	–
Fn206*	EasyFFT	–	–
Fn207*	Online vibration monitor	–	–


* These functions are disabled in the Σ -V-SD SERVOPACK with expanded functions for analog voltage/speed references.

13.4.2 Operations

This section describes the operation method on the execution display selected from the main menu of the utility function.

Press the  Key in the parameter/monitor mode to display the main menu of utility function mode.



Press the  or  Key to select a utility function to be executed, and then press the  Key to display the execution display of selected utility function.

Press the  Key to scroll up or down four lines at a time.


1:BB	-FUNCTION-
Fn207:V-Monitor	
Fn000:Alm History	
Fn002:JOG	
Fn003:Z-Search	


← The selected utility function blinks.

Utility Function Mode Main Menu Display

If the utility function that cannot be executed is selected and the  or  Key is pressed, "NO-OP" is displayed for one second.

1:BB	-FUNCTION-
Fn000:Alm History	
Fn002:JOG	
Fn003:Z-Search	
Fn004:Program JOG	

 →

← 

After about one sec.

NO-OP	-FUNCTION-
Fn000:Alm History	
Fn002:JOG	
Fn003:Z-Search	
Fn004:Program JOG	

↖ Blink

<Example>

This status will occur if you attempt to perform a jog operation (Fn002) when the write prohibited setting (Fn010) parameter is set to prohibit writing.

Note: The following terms are used with the given meanings unless otherwise specified.

Servo OFF: Both the /FWD and /REV signals are OFF.

13.4.3 Alarm History Display (Fn000)

This function displays the last ten alarms that have occurred in the SERVOPACK.
The latest ten alarm numbers and time stamps* can be checked.

* Time Stamps

A function that measures the ON times of the control power supply and main circuit power supply in 100-ms units and displays the total operating time when an alarm occurs. The time stamp operates around the clock for approximately 13 years.

<Example of Time Stamps>

If 36000 is displayed,

$3600000 \text{ [ms]} = 3600 \text{ [s]} = 60 \text{ [min]} = 1 \text{ [h]}$

















Therefore, the total number of operating hours is 1 hour.

(1) Preparation

There are no tasks that must be performed before displaying the alarm history.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	<pre> 1: BB -FUNCTION- Fn207: V-Monitor Fn000: Alm History Fn002: JOG Fn003: Z-Search </pre>	  	Press the  Key to view the main menu for the utility function mode. Use the  or  Key to move through the list and select Fn000.
2	<pre> A.D00 -ALARM- 0: D00 00001207196 1: 720 00000032651 2: 511 00000009043 3: --- </pre>		Press the  Key. The display changes to the Fn000 execution display.
3	<pre> A.D00 -ALARM- 1: 720 00000032651 2: 511 00000009043 3: --- 4: --- </pre> <p>   </p> <p> Time stamp Alarm no. Alarm history no. 0: Latest 9: Oldest </p>	 	Press the  or  Key to scroll through the alarm history. The alarm history can be viewed.
4	<pre> 1: BB -FUNCTION- Fn207: V-Monitor Fn000: Alm History Fn002: JOG Fn003: Z-Search </pre>		Press the  Key. The display returns to the main menu of the utility function mode.

Note 1. If the same alarm occurs after more than one hour, the alarm will be saved.

If it occurs in less than one hour, it will not be saved.

- The display "□.---" means no alarm occurs.
- Delete the alarm history using the parameter Fn006. The alarm history is not cleared on alarm reset or when the SERVOPACK main circuit power is turned OFF.
- CPF00 and CPF01 alarms are related to the Digital Operator. They are not recorded in the alarm history.
- Warnings are not recorded in the alarm history.

13.4.4 JOG Operation (Fn002)

JOG operation is used to check the operation of the spindle motor under speed control without connecting the SERVOPACK to the host controller.

(1) Preparation























The following conditions must be met to perform a jog operation.

- The write prohibited setting (Fn010) must not be set to write-protect parameters.
- The main circuit power supply must be ON.
- All alarms must be cleared.
- The hardwire baseblock (HWBB) must be disabled.
- The servo must be OFF.
- The JOG speed must be set considering the operating range of the machine.
Set the jog speed in Pn304.











Pn304	Jog Speed				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 10000	1 min ⁻¹	500	Immediately	

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	1 : BB -FUNCTION- Fn000: Alm History Fn002: JOG Fn003: Z-Search Fn004: Program JOG	  	Press the  Key to view the main menu for the utility function mode. Use the  or  Key to move through the list and select Fn002.
2	1 : BB -JOG- Pn304=00500 Un000= 00000 Un002= 00000 Un00D= 0000000000		Press the  Key. The display changes to the Fn002 execution display.
3	1 : BB -JOG- Pn304=0050 <u>0</u> Un000= 00000 Un002= 00000 Un00D= 0000000000		Press the  Key. The cursor moves to the setting side (the right side) of Pn304 (JOG speed).
4	1 : BB -JOG- Pn304=01 <u>0</u> 00 Un000= 00000 Un002= 00000 Un00D= 0000000000	   	Press the  or  Key and the  or  Key to set the JOG speed to 1000 min ⁻¹ .
5	1 : BB -JOG- Pn304=0100 <u>0</u> Un000= 00000 Un002= 00000 Un00D= 0000000000		Press the  Key. The setting value is entered, and the cursor moves to the parameter number side (the left side).
6	1 : RUN -JOG- Pn304=01000 Un000= 00000 Un002= 00000 Un00D= 0000000000		Press the  Key. The status display changes from “BB” to “RUN”, and the motor power turns ON.

(cont'd)


Step	Display after Operation	Keys	Operation
7	<pre> 1 : RUN - JOG - Pn304=01000 Un000= 00000 Un002= 00000 Un00D= 000000000 </pre>	 	<p>The spindle motor will rotate at the present speed set in Pn304 while the  Key (for forward rotation) or  Key (for reverse rotation) is pressed.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Forward</p> </div> <div style="text-align: center;">  <p>Reverse</p> </div> </div>
8	<pre> 1 : BB - JOG - Pn304=01000 Un000= 00000 Un002= 00000 Un00D= 000000000 </pre>		<p>After having confirmed the correct motion of the spindle motor, press the  Key.</p> <p>The status display changes from “RUN” to “BB”, and the motor power turns OFF.</p>
9	<pre> 1 : BB - FUNCTION - Fn000: Alm History Fn002: JOG Fn003: Z-Search Fn004: Program JOG </pre>		<p>Press the  Key.</p> <p>The display returns to the main menu of the utility function mode.</p>
10	Turn OFF the power and then turn it ON again.		

13.4.5 Origin Search (Fn003)

The origin search is designed to position the zero pulse position of the incremental encoder (phase C) and to clamp the motor at that position.

Note: Perform origin searches without connecting the coupling.

This function is used when the spindle motor needs to be aligned to the zero point of the main shaft. The motor speed when the operation is executed is 60 min^{-1} .























(1) Preparation

The following conditions must be met to perform the origin search.

- The write prohibited setting (Fn010) must not be set to write-protect parameters.
- The main circuit power supply must be ON.
- All alarms must be cleared.
- The hardwire baseblock (HWBB) must be disabled.
- The servo must be OFF.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	<pre>1:BB —FUNCTION— Fn002:JOG Fn003:Z-Search Fn004:Program JOG Fn005:Prm Init</pre>	  	<p>Press the  Key to view the main menu for the utility function mode.</p> <p>Use the  or  Key to move through the list and select Fn003.</p>
2	<pre>1:BB —Z-Search— Un000= 00000 Un002= 00000 Un003= 0000000774 Un00D= 0000000000</pre>		<p>Press the  Key. The display changes to the Fn003 execution display.</p>
3	<pre>1:RUN —Z-Search— Un000= 00000 Un002= 00000 Un003= 0000000774 Un00D= 0000000000</pre>		<p>Press the  Key. The status display changes from “BB” to “RUN,” and the motor power turns ON.</p> <p>Note: If the motor is already at the zero position, “-Complete-” is displayed.</p>
4	<pre>1:RUN —Complete— Un000= 00000 Un002= 00000 Un003= 0000000000 Un00D= 0000001D58</pre>	 	<p>Pressing the  Key will rotate the motor in the forward direction. Pressing the  Key will rotate the spindle motor in the reverse direction.</p> <p>Press the  or  Key until the motor stops.</p> <p>If the origin search completed normally, “-Complete-” is displayed on the right top on the screen.</p>
5	<pre>1:BB —Z-Search— Un000= 00000 Un002= 00000 Un003= 0000000000 Un00D= 0000001D58</pre>		<p>When the origin search is completed, press the  Key.</p> <p>The status display changes from “RUN” to “BB,” and the spindle motor power turns OFF.</p> <p>The display “-Complete-” changes to “-Z-Search-.”</p>
6	<pre>1:BB —FUNCTION— Fn002:JOG Fn003:Z-Search Fn004:Program JOG Fn005:Prm Init</pre>		<p>Press the  Key.</p> <p>The display returns to the main menu of the utility function mode.</p>
7	Turn OFF the power and then turn it ON again.		

13.4.6 Program JOG Operation (Fn004)

This function allows continuous operation determined by the preset operation pattern, movement distance, movement speed, acceleration/deceleration time, waiting time, and number of times of movement.

In the same way as for the jog operation (Fn002), this function can be used during setup procedures to perform simple positioning operations without connecting the motor to the host controller for the machine.


(1) Preparation

The following conditions must be met to perform the program JOG operation.


- The write prohibited setting (Fn010) must not be set to write-protect parameters.
- The main circuit power supply must be ON.
- All alarms must be cleared.
- The hardwire baseblock (HWBB) must be disabled.
- The servo must be OFF.
- The speed must be set correctly considering the safety of the machine.
- The MGR and the LGR must be OFF.

(2) Program JOG Operation Patterns


The following describes an example of program JOG operation pattern. The following example is given when the rotating direction of the motor is set as Pn000.0 = 0 (Forward rotation by forward reference).




Note: When Pn536 (number of times of program JOG movement) is set to 0, infinite time operation is enabled. To stop infinite time operation, press the JOG/SVON Key of digital operator to turn the servo OFF.




Note: When Pn536 (Number of Times of Program JOG Movement) is set to 0, infinite time operation is enabled. To stop infinite time operation, press the JOG/SVON Key of digital operator to turn the servo OFF.




Note: When Pn530.0 is set to 2, infinite time operation is disabled.



Note: When Pn530.0 is set to 3, infinite time operation is disabled.



Note: When Pn536 (number of times of program JOG movement) is set to 0, infinite time operation is enabled. To stop infinite time operation, press the JOG/SVON Key of digital operator to turn the servo OFF.



Note: When Pn536 (number of times of program JOG movement) is set to 0, infinite time operation is enabled. To stop infinite time operation, press the JOG/SVON Key of digital operator to turn the servo OFF.






















(3) Related Parameters

The following parameters set the program JOG operation pattern. Do not change the settings while the program JOG operation is being executed.

Pn530	Program JOG Operation Related Switch <input type="checkbox"/> Speed <input type="checkbox"/> Position <input type="checkbox"/> Torque				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0000 to 0005	—	0000	Immediately	Setup
Pn531	Program JOG Movement Distance <input type="checkbox"/> Speed <input type="checkbox"/> Position <input type="checkbox"/> Torque				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	1 to 1073741824	1 pulse	32768	Immediately	Setup
Pn533	Program JOG Movement Speed <input type="checkbox"/> Speed <input type="checkbox"/> Position <input type="checkbox"/> Torque				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	1 to 10000	1 min ⁻¹	500	Immediately	Setup
Pn534	Program JOG Acceleration/Deceleration Time <input type="checkbox"/> Speed <input type="checkbox"/> Position <input type="checkbox"/> Torque				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	2 to 10000	1 ms	100	Immediately	Setup
Pn535	Program JOG Waiting Time <input type="checkbox"/> Speed <input type="checkbox"/> Position <input type="checkbox"/> Torque				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 10000	1 ms	100	Immediately	Setup
Pn536	Number of Times of Program JOG Movement <input type="checkbox"/> Speed <input type="checkbox"/> Position <input type="checkbox"/> Torque				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 1000	1 time	1	Immediately	Setup

(4) Operating Procedure

Use the following procedure to perform the program JOG operation after setting a program JOG operation pattern.

Step	Display after Operation	Keys	Operation
1	<pre>1: BB -FUNCTION- Fn003: Z-Search Fn004: Program JOG Fn005: Prm Init Fn006: AlmHist Clr</pre>	  	<p>Press the  Key to view the main menu for the utility function mode.</p> <p>Use the  or  Key to move through the list and select Fn004.</p>
2	<pre>1: BB -PRG JOG- Pn531=00032768 Pn533=00500 Pn534=00100 Pn536=00001</pre>		<p>Press the  Key. The display changes to the Fn004 execution display.</p>
3	<pre>1: BB -PRG JOG- Pn531=00032768 Pn533=00500 Pn534=00100 Pn536=00010</pre>	 	<p>Confirm that the parameters have been set.</p> <p>Press the  Key to view Pn530.</p> <p>Press the  Key to view the parameters in the following order: Pn530 → Pn531 → Pn533 → Pn534 → Pn535 → Pn536.</p>
4	<pre>1: RUN -PRG JOG- Pn531=00032768 Pn533=00500 Pn534=00100 Pn536=00010</pre>		<p>Press the  Key.</p> <p>The status display changes from “BB” to “RUN”, and the motor power turns ON.</p>
5	<pre>1: RUN -PRG JOG- Pn531=00032768 Pn533=00500 Pn534=00100 Pn536=00010</pre>	 	<p>Press the  (forward movement start) or  (reverse movement start) Key according to the first movement direction of the preset operation pattern. The motor starts moving after the preset waiting time in Pn535.</p> <p>Note: Pressing the  Key again changes the status to “BB” (baseblocked status) and stops movement even during operation.</p>
6	<pre>1: RUN -PRG JOG- Pn531=00032768 Pn533=00500 Pn534=00100 Pn536=000<u>1</u>0</pre>		<p>When the set program JOG operation movement is completed, “END” is displayed for one second, and then “RUN” is displayed.</p> <p>Press the  Key. The motor becomes baseblocked status. The display returns to the main menu of the utility function mode.</p>
7	After program JOG operation, turn OFF the power and then turn ON again.		

Note: When you check the settings of the parameters at step 3, you can also change the settings.

13.4.7 Initializing Parameter Settings (Fn005)

This function is used when returning to the factory settings after changing parameter settings.



IMPORTANT

- Be sure to initialize the parameter settings while the motor power is OFF.
- After initialization, turn OFF the power supply and then turn ON again to validate the settings.

Note: Any value adjusted with Fn00C, Fn00D, Fn00E, and Fn00F cannot be initialized by Fn005.













(1) Preparation

The following conditions must be met to initialize the parameter values.

- The write prohibited setting (Fn010) must not be set to write-protect parameters.
- The servo must be OFF.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	<pre>1:BB -FUNCTION- Fn004:Program JOG Fn005:Prm Init Fn006:AlmHist Clr Fn008:Mturn Clr</pre>	  	<p>Press the  Key to view the main menu for the utility function mode.</p> <p>Use the  or  Key to move through the list and select Fn005.</p>
2	<pre>1:BB Parameter Init Start : [DATA] Return : [SET]</pre>		<p>Press the  Key. The display changes to the Fn005 execution display.</p>
3	<pre>1:BB Parameter Init Start : [DATA] Return : [SET]</pre>	 	<p>Press the  Key to initialize parameters.</p> <p>During initialization, "Parameter Init" is flashing in the display.</p> <p>After the initialization is completed, "Parameter Init" stops flashing and the status display changes as follows: "BB" to "DONE" to "BB."</p> <p>Note: Press the  Key not to initialize parameters. The display returns to the main menu of the utility function mode.</p>
4	Turn OFF the power and then turn it ON again to validate the new setting.		

13.4.8 Clearing Alarm History (Fn006)

This function deletes all of the alarm history recorded in the SERVOPACK.

Note: The alarm history is not deleted when the alarm reset is executed or the main circuit power supply of the SERVOPACK is turned OFF.













(1) Preparation

The follow conditions must be met to clear the alarm history.

- The write prohibited setting (Fn010) must not be set to write-protect parameters.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	<pre> 1:BB -FUNCTION- Fn005:Prm Init Fn006:AlmHist Clr Fn008:Mturn Clr Fn009:Ref Adj </pre>	  	<p>Press the  Key to view the main menu for the utility function mode.</p> <p>Use the  or  Key to move through the list and select Fn006.</p>
2	<pre> 1:BB Alarm History Data Clear Start : [DATA] Return: [SET] </pre>		<p>Press the  Key. The display changes to the Fn006 execution display.</p>
3	<pre> 1:BB Alarm History Data Clear Start : [DATA] Return: [SET] </pre>	 	<p>Press the  Key to clear the alarm history.</p> <p>While clearing the data, “DONE” is displayed in the status display. After the data has been successfully cleared, “BB” is displayed.</p> <p>Note: Press the  Key not to clear the alarm history. The display returns to the main menu of the utility function mode.</p>

13.4.9 Automatic Tuning of Analog Speed Reference Offset (Fn009)

This function measures the amount of offsets and adjusts the reference voltage automatically. The amount of offsets measured is saved in the SERVOPACK.



IMPORTANT

Always turn OFF the servo before you automatically adjust the reference offset.

- Note 1. You cannot use this function if you implement a position loop in the host controller. Use the manual servo tuning of speed reference offset (Fn00A) for the adjustment.
 2. The offset value will not be initialized when parameter settings are initialized by using Fn005.













(1) Preparation

The following conditions must be met to adjust the offsets of speed or torque analog reference automatically.

- The write prohibited setting (Fn010) must not be set to write-protect parameters.
- The servo must be OFF.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	<pre>1:BB -PRM/MON- Un000= 00000 Un002= 00000 Un008= 0000000000 Un00D= 0000000000</pre>	—	Turn OFF the servo and input a reference voltage of 0 V from the host controller or from an external circuit.
2	<pre>1:BB -FUNCTION- Fn008:Mturn Clr Fn009:Ref Adj Fn00A:Vel Adj Fn00B:Trq Adj</pre>	  	Press the  Key to view the main menu of the utility function mode. Use the  or  Key to move through the list and select Fn009.
3	<pre>1:BB Ref Adjust Start : [DATA] Return: [SET]</pre>		Press the  Key. The display changes to the Fn009 execution display.
4	<pre>1:BB Ref Adjust Start : [DATA] Return: [SET]</pre>	 OR 	<p>Press the  Key to execute the automatic adjustment of analog voltage reference (speed) offset. “DONE” will flash for approximately 1 second after the write is completed normally, and then the “BB” display will return.</p> <p>Press the  Key not to execute the automatic adjustment. The display returns to the main menu of the utility function mode.</p>

13.4.10 Manual Servo-tuning of Speed Reference Offset (Fn00A)

This function allows you to directly input the reference offset. Use this function in the following cases.

- To deliberately set the offset amount to some value.
- To check the offset amount calculated in the automatic adjustment mode.

<Supplementary Note>

The offset value will not be initialized when parameter settings are initialized by using Fn005.

















(1) Preparation

The following conditions must be met to adjust the offsets of speed reference manually.

- The write prohibited setting (Fn010) must not be set to write-protect parameters.
- The main circuit power supply must be ON.
- All alarms must be cleared.
- The hard wire base block (HWBB) must be disabled.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	–	–	Input a reference voltage of 0 V from the host controller or from an external circuit.
2	1:BB –FUNCTION– Fn009:Ref Adj Fn00A:Vel Adj Fn00B:Trq Adj Fn00C:MonZero Adj	  	Press the  Key to view the main menu of the utility function mode. Use the  or  Key to move through the list and select Fn00A.
3	1:BB Velocity Adjust ZADJV= 00000 Vref = 00000		Press the  Key. The display changes to the Fn00A execution display.
4	1:RUN Velocity Adjust ZADJV= 00000 Vref = 00000	–	Turn ON the /FWD or /REV signal. The servo will turn ON.
5	1:RUN Velocity Adjust ZADJV=+0001 <u>2</u> Vref = 00000	 or 	Press the  or  Key to adjust the reference speed offset value. Note: Adjust the value until the speed of the spindle motor goes to zero.
6	1:RUN Velocity Adjust ZADJV=+0001 <u>5</u> Vref = 00000		Press the  Key to write the speed reference offset value into the SERVOPACK. When the writing is completed, the status display shows “DONE” for one second.
7	1:RUN –FUNCTION– Fn009:Ref Adj Fn00A:Vel Adj Fn00B:Trq Adj Fn00C:MonZero Adj		Press the  Key. The display returns to the main menu of the utility function mode. The status display then returns to show “RUN” again.

13.4.11 Offset Adjustment of Analog Monitor Output (Fn00C)

This function is used to manually adjust the offsets for the analog monitor outputs (torque reference monitor and motor speed monitor). The offsets are adjusted at the factory. You normally do not need to use this function.

<Supplementary Note>

- The offset value will not be initialized when parameter settings are initialized by using Fn005.
- If you adjust the offsets, connect the measuring instrument that you will actually use with the analog monitor output adjusted to zero. The following are setting examples for a zero output.
 - Turn OFF the servo and set the monitor signal to a torque reference.
 - Set the monitor signal to position error when using speed control.























(1) Preparation

The following condition must be met to adjust the offsets of the analog monitor output.

- The write prohibited setting (Fn010) must not be set to write-protect parameters.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	<pre>1:BB -FUNCTION- Fn00B:Trq Adj Fn00C:MonZero Adj Fn00D:MonGain Adj Fn00E:Cur AutoAdj</pre>	  	Press the  Key to view the main menu for the utility function mode. Use the  or  Key to move through the list and select Fn00C.
2	<pre>1:BB -Zero ADJ- CH1=-0000<u>2</u> CH2= 00001 Un002= 00000 Un000= 00000</pre>		Press the  Key. The display changes to the Fn00C execution display.
3	<pre>1:BB -Zero ADJ- CH1=-0000<u>5</u> CH2= 00001 Un002= 00000 Un000= 00000</pre>	 	Press the  or  Key to adjust the offset of CH1 (torque reference monitor). Adjust the offset so that the measurement instrument reading is as close to 0 V as possible.
4	<pre>1:BB -Zero ADJ- CH1=-00005 CH2= 0000<u>1</u> Un002= 00000 Un000= 00000</pre>		After the offset adjustment of CH1 has completed, adjust the offset of CH2 (motor speed monitor). Press the  Key. The cursor moves to CH2 side.
5	<pre>1:BB -Zero ADJ- CH1=-00005 CH2= 0000<u>6</u> Un002= 00000 Un000= 00000</pre>	 	Adjust the offset of CH2 in the same way as for CH1. Press the  or  Key to adjust the offset of CH2. Adjust the offset so that the measurement instrument reading is as close to 0 V as possible.
6	<pre>1:BB -Zero ADJ- CH1=-00005 CH2= 0000<u>6</u> Un002= 00000 Un000= 00000</pre>		After having completed the offset adjustment both for CH1 and CH2, press the  Key. The adjustment results are saved in the SERVOPACK, and the status display shows "DONE" for one second. The status display then returns to show "BB" again.
7	<pre>1:BB -FUNCTION- Fn00B:Trq Adj Fn00C:MonZero Adj Fn00D:MonGain Adj Fn00E:Cur AutoAdj</pre>		Press the  Key. The display returns to the main menu of the utility function mode.

13.4.12 Gain Adjustment of Analog Monitor Output (Fn00D)

This function is used to manually adjust the gains for the analog monitor outputs (torque reference monitor output and motor speed monitor output). The gain values are factory-set before shipping. Therefore, the user need not usually use this function.

The setting range of the gain adjustment width for analog monitor output is -128 to +127 (× 0.4%).

The setting of gain adjustment width is made on the base of 100%. For example, the setting “-125” makes $100\% - (125 \times 0.4\%) = 50\%$, which means that the monitor output voltage is 1/2. The setting “125” makes $100\% + (125 \times 0.4\%) = 150\%$, which means that the monitor output voltage is 1.5 times.

Note: The adjustment value will not be initialized when parameter settings are initialized using Fn005.























(1) Preparation

The following condition must be met to adjust the gain of the analog monitor output.

- The write prohibited setting (Fn010) must not be set to write-protect parameters.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	1:BB -FUNCTION- Fn00C:MonZero Adj Fn00D:MonGain Adj Fn00E:Cur AutoAdj Fn00F:Cur ManuAdj	  	Press the  Key to view the main menu for the utility function mode. Use the  or  Key to move through the list and select Fn00D.
2	1:BB -Gain ADJ- CH1=-0000 <u>1</u> CH2=-00001 Un002= 00000 Un000= 00000		Press the  Key. The display changes to the Fn00D execution display.
3	1:BB -Gain ADJ- CH1= 0012 <u>5</u> CH2=-00001 Un002= 00000 Un000= 00000	 	Press the  or  Key to adjust the gain adjustment width of CH1 (torque reference monitor).
4	1:BB -Gain ADJ- CH1= 00125 CH2=-0000 <u>1</u> Un002= 00000 Un000= 00000		After the gain adjustment of CH1 has completed, adjust the gain adjustment width of CH2 (motor speed monitor). Press the  Key. The cursor moves to CH2 side.
5	1:BB -Gain ADJ- CH1= 00125 CH2=-0012 <u>5</u> Un002= 00000 Un000= 00000	 	Adjust the gain of CH2 in the same way as for CH1. Press the  or  Key to adjust the gain adjustment width of CH2 (motor speed monitor).
6	1:BB -Gain ADJ- CH1= 00125 CH2=-0012 <u>5</u> Un002= 00000 Un000= 00000		After having completed the adjustment both for CH1 and CH2, press the  Key. The adjustment results are saved in the SERVOPACK, and the status display shows “DONE” for one second. The status display then returns to show “BB” again.
7	1:BB -FUNCTION- Fn00C:MonZero Adj Fn00D:MonGain Adj Fn00E:Cur AutoAdj Fn00F:Cur ManuAdj		Press the  Key. The display returns to the main menu of the utility function mode.

13.4.13 Automatic Offset-Signal Adjustment of the Motor Current Detection Signal (Fn00E)

Perform this adjustment only if highly accurate adjustment is required for reducing torque ripple caused by current offset. The user need not usually use this function.



IMPORTANT

- Be sure to perform this function while the servo is OFF.
- Execute the automatic offset adjustment if the torque ripple is too big when compared with those of other SERVOPACKs.

Note: Fn005 cannot initialize any value adjusted with Fn00E.













(1) Preparation

The following conditions must be met to automatically adjust the offset of the motor current detection signal.

- The write prohibited setting (Fn010) must not be set to write-protect parameters.
- The main circuit power supply must be ON.
- All alarms must be cleared.
- The hard wire base block (HWBB) must be disabled.
- The servo must be OFF.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	<pre>1:BB -FUNCTION- Fn00D: MonGain Adj Fn00E: Cur AutoAdj Fn00F: Cur ManuAdj Fn010: Prm Protect</pre>	  	<p>Press the  Key to view the main menu for the utility function mode.</p> <p>Use the  or  Key to move through the list and select Fn00E.</p>
2	<pre>1:BB Auto Offset-ADJ of Motor Current Start : [DATA] Return: [SET]</pre>		<p>Press the  Key. The display changes to the Fn00E execution display.</p>
3	<pre>1:BB Auto Offset-ADJ of Motor Current Start : [DATA] Return: [SET]</pre>	 	<p>Press the  Key to start the automatic offset-signal adjustment of motor current detection.</p> <p>When the adjustment is completed, the status display shows "DONE" for one second. The status display then returns to show "BB" again.</p> <p>Note: Press the  Key to cancel the automatic adjustment. The display returns to the main menu of the utility function mode.</p>

13.4.14 Manual Offset-Signal Adjustment of the Motor Current Detection Signal (Fn00F)

Use this function only if the torque ripple is still high after the automatic offset-signal adjustment of the motor current detection signal (Fn00E).



If this function is executed carelessly, it may worsen the characteristics.

Observe the following precautions when performing manual servo tuning.

- Run the spindle motor at a speed of approximately 100 min⁻¹.
- Adjust the offset while monitoring the torque reference with the analog monitor until the ripple of torque reference monitor's waveform is minimized.
- Adjust the phase-U and phase-V offset amounts alternately several times until these offsets are well balanced.

Note: Fn005 cannot initialize any value adjusted with Fn00F.



















(1) Preparation

The following condition must be met to manually adjust the offset of the motor current detection signal.





- The write prohibited setting (Fn010) must not be set to write-protect parameters.
- The main circuit power supply must be ON.
- All alarms must be cleared.
- The hardwire baseblock (HWBB) must be disabled.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	1:BB -FUNCTION- Fn00F:Cur ManuAdj Fn010:Prm Protect Fn011:Motor Info Fn012:Soft Ver	  	Press the  Key to view the main menu for the utility function mode. Use the  or  Key to move through the list and select Fn00F.
2	1:BB Manual Offset-ADJ of Motor Current ZADJIU= 0000 <u>9</u> ZADJIV= 0000 <u>6</u>		Press the  Key. The display changes to the Fn00F execution display.
3	1:RUN Manual Offset-ADJ of Motor Current ZADJIU= 0000 <u>9</u> ZADJIV= 0000 <u>6</u>	—	Input the /FWD or /REV signal from the host controller.
4	1:RUN Manual Offset-ADJ of Motor Current ZADJIU= 0001 <u>9</u> ZADJIV= 0000 <u>6</u>	 	Adjust the phase-U offset. Press the  or  Key to adjust the offset amount. Adjust the offset amount by 10 in the direction that the torque ripple is reduced. Adjustment range: -512 to +511 (ZADJIU: Offset value of phase-U current)
5	1:RUN Manual Offset-ADJ of Motor Current ZADJIU= 0001 <u>9</u> ZADJIV= 0000 <u>6</u>		Adjust the phase-V offset. Press the  Key. The cursor moves to the phase-V side.
6	1:RUN Manual Offset-ADJ of Motor Current ZADJIU= 0001 <u>9</u> ZADJIV= 0001 <u>6</u>	 	Press the  or  Key to adjust the offset amount. Adjust the offset amount by 10 in the direction that the torque ripple is reduced. (ZADJIV: Offset value of phase-V current)

(cont'd)

Step	Display after Operation	Keys	Operation
7	<pre> 1: RUN Manual Offset-ADJ of Motor Current ZADJIU= 00019 ZADJIV= 0001<u>6</u> </pre>		<p>Press the  Key to save the result of adjustment in the SERVOPACK.</p> <p>When the saving is completed, the status display shows "DONE" for one second. The status display then returns to show "RUN" again.</p>
8	<pre> 1: RUN -FUNCTION- Fn00F: Cur ManuAdj Fn010: Prm Protect Fn011: Motor Info Fn012: Soft Ver </pre>		<p>Press the  Key.</p> <p>The display returns to the main menu of the utility function mode.</p>

Note: Repeat the operations of steps 4 to 6 (phase-U and-V alternately) until adjusting the offset amounts both for phase-U and -V in both directions cannot reduce the torque ripple any more. Then, perform the same operation by adjusting by smaller amount.

13.4.15 Write Prohibited Setting (Fn010)

This function prevents changing parameters by mistake and sets restrictions on the execution of the utility function.

Parameter changes and execution of the utility function become restricted in the following manner when the write prohibited setting is set.

- Parameters: Cannot be changed. If you attempt to change it, “NO-OP” will flash on the display and the screen will return to the main menu.
- Utility Function: Some functions cannot be executed. (Refer to the following table.) If you attempt to execute these utility functions, “NO-OP” will flash on the display and the screen will return to the main menu.

Parameter No.	Function	Write Prohibited Setting
Fn000	Alarm history display	Executable
Fn002	JOG operation	Cannot be executed
Fn003	Origin search	Cannot be executed
Fn004	Program JOG operation	Cannot be executed
Fn005	Initializing parameter settings	Cannot be executed
Fn006	Clearing alarm history	Cannot be executed
Fn009	Automatic tuning of analog speed reference offset	Cannot be executed
Fn00A	Manual servo turning of speed reference offset	Cannot be executed
Fn00C	Offset adjustment of analog monitor output	Cannot be executed
Fn00D	Gain adjustment of analog monitor output	Cannot be executed
Fn00E	Automatic offset-signal adjustment of the motor current detection signal	Cannot be executed
Fn00F	Manual offset-signal adjustment of the motor current detection signal	Cannot be executed
Fn010	Write prohibited setting	–
Fn012	Software version display	Executable
Fn01E	Display of SERVOPACK and motor ID	Executable
Fn204	Anti-resonance control adjustment function	Cannot be executed

(1) Preparation















There are no tasks that must be performed before the execution.

(2) Operating Procedure

A setting example for prohibiting and permitting changes is given below.

The following set values are used:

- P.0000: Changes permitted (prohibit canceled) (default)
- P.0001: Changed prohibited (Changes are prohibited from the next time the power supply is restarted.)

Step	Display after Operation	Keys	Operation
1	<pre>1:BB -FUNCTION- Fn00F:Cur ManuAdj Fn010:Prm Protect Fn011:Motor Info Fn012:Soft Ver</pre>	  	<p>Press the  Key to view the main menu for the utility function mode.</p> <p>Use the  or  Key to move through the list and select Fn010.</p>
2	<pre>1:BB Parameter Write Protect P. 0000_</pre>		<p>Press the  Key. The display changes to the Fn010 execution display.</p>
3	<pre>1:BB Parameter Write Protect P. 0001_</pre>	 	<p>Press the  or  Key to select one of the following settings.</p> <p>P.0000: Write permitted [Factory setting] P.0001: Write prohibited</p>
4	<pre>1:BB Parameter Write Protect P. 0001_</pre>		<p>Press the  Key. The setting value is written into the SERVOPACK, and the status display changes as follows: "DONE" to "BB."</p> <p>Note: Saved settings will be enabled after the SERVOPACK is restarted.</p>
5	Turn OFF the power and then turn it ON again to validate the new setting.		

Note: To make the setting available, change the setting to P.0000 as shown in step 3.

13.4.16 Software Version Display (Fn012)











This function displays the software version of the SERVOPACK.

(1) Preparation

There are no tasks that must be performed before the execution.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	<pre>1:BB -FUNCTION- Fn011:Motor Info Fn012:Soft Ver Fn013:MturnLmSet Fn014:Opt Init</pre>	  	<p>Press the  Key to view the main menu for the utility function mode.</p> <p>Use the  or  Key to move through the list and select Fn012.</p>
2	<pre>1:BB -Soft Ver- DRIVER Ver.=0001 ENCODER Ver.=0000</pre>		<p>Press the  Key. The display changes to the Fn012 execution display.</p> <p>The software versions of the SERVOPACK will appear.</p> <p>Note: The software version of the encoder is always displayed as 0000.</p>
3	<pre>1:BB -FUNCTION- Fn011:Motor Info Fn012:Soft Ver Fn013:MturnLmSet Fn014:Opt Init</pre>		<p>Press the  Key. The display returns to the main menu of the utility function mode.</p>

13.4.17 Display of SERVOPACK and Motor ID (Fn01E)

This function displays information that was written to the SERVOPACK for the SERVOPACK ID, motor ID, and encoder ID. The following items can be displayed.



























ID	Items to be Displayed
SERVOPACK ID	<ul style="list-style-type: none"> • SERVOPACK model • SERVOPACK serial number • SERVOPACK manufacturing date • SERVOPACK input voltage (V) • Maximum applicable motor capacity (W) • Maximum applicable motor rated current (Arms)
Motor ID	<ul style="list-style-type: none"> • Motor model • Motor input voltage (V) • Motor capacity (W) • Motor rated current (Arms)
Encoder ID	<ul style="list-style-type: none"> • Encoder model • Encoder type/resolution

(1) Preparation

There are no tasks that must be performed before the execution.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	<pre>1: RUN - FUNCTION - Fn01B: Viblv Init Fn01E: SvMotOp ID Fn01F: FBOpMot ID Fn020: S-Orig Set</pre>	  	Press the  Key to view the main menu for the utility function mode. Use the  or  Key to move through the list and select Fn01E.
2	<pre>1: BB - SvMotOp ID - Driver CACR-JU065ADA ← D00241234590001 ← 11.04 200V,15000W</pre> <p>Serial number SERVOPACK model Manufacturing date Input voltage Capacity</p>	  	Press the  Key. The display changes to the Fn01E execution display. The SERVOPACK ID information is displayed. Use the  or  Key to scroll left and right and to view other information.
3	<pre>1: BB - SvMotOp ID - Motor UAKAJ-15CZC100 ← 200V,15000W</pre> <p>Motor model Input voltage Capacity</p>	  	Press the  Key. The motor ID information is displayed. Use the  or  Key to scroll left and right and to view other information.
4	<pre>1: BB - SvMotOp ID - Encoder UTMSI-10AAGAZA ← 12bit-INC</pre> <p>Encoder model Encoder resolution Encoder type</p>	  	Press the  Key. The encoder ID information is displayed. Use the  or  Key to scroll left and right and to view other information.
5	<pre>1: RUN - FUNCTION - Fn01B: Viblv Init Fn01E: SvMotOp ID Fn01F: FBOpMot ID Fn020: S-Orig Set</pre>		Press the  Key. The display returns to the main menu of the utility function mode.

13.4.18 Turnup Function (Fn024)

You can use the tuneup function to compensate the phase-C width and adjust the origin position for orientation control with a load shaft encoder.

For orientation control with a magnetic sensor, the magnetic sensor settings are automatically adjusted.



IMPORTANT

Always execute the tuneup function before you use orientation control.

If you do not execute the tuneup function, orientation control may malfunction.

Set the gear ratio accurately. If a gear ratio is not correct, the tuneup will not end normally.

(1) Preparation

The following condition must be met to perform turnup.

- The write prohibited setting (Fn010) must not be set to write-protect parameters.
- The main circuit power supply must be ON.
- All alarms must be cleared.
- The hardwire baseblock (HWBB) must be disabled.
- /ORT signal is OFF.
- Either orientation with a load shaft encoder or orientation with a magnetic sensor must be set.
- The motor must be stopped.

(2) Related Parameters












Pn80A	Load Shaft Positioning Origin (Using an Encoder) <input type="checkbox"/> Speed <input type="checkbox"/> Position <input type="checkbox"/> Torque				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 1073741824	1 pulse	0	Immediately	Setup
Pn80C	Load Shaft Positioning Origin (Using a Magnetic Sensor) <input type="checkbox"/> Speed <input type="checkbox"/> Position <input type="checkbox"/> Torque				Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	-200 to 200	0.01 deg	0	Immediately	Setup

(3) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	<pre> 1:BB -FUNCTION- Fn020:S-Orig Set Fn024:ORT TunUp Fn025:LM Tuning Fn030:Soft Reset </pre>	 	Press the Key to view the main menu for the utility function mode. Use the or Key to move through the list and select Fn024.
2	<pre> 1:BB -ORT TUN- Pn80A=0000000000 Un000=00000 Un00F=00000 Un005=■■■■■■■■■■ </pre>		Press the Key. The display changes to the Fn024 execution display.
3	<pre> 1:RUN -TUNRDY- Pn80A=0000000000 Un000=00000 Un00F=00000 Un005=■■■■■■■■■■ </pre>	-	Turn ON the ORT signal. The servo will turn ON.
4	<pre> 1:RUN -TUNRDY- Pn80A=0000000000 Un000=00000 Un00F=00000 Un005=■■■■■■■■■■ </pre>		Press the and Keys at the same time to start turnup. Turnup starts.

(cont'd)

Step	Display after Operation	Keys	Operation
5	<pre>1:RUN -TUNRUN- Pn80A=000000000 Un000=00060 Un00F=00060 Un005=■■■■■</pre>		<p>During turnup, the display changes from “TUNRDY” to “TUNRUN”.</p> <p>To hold the operation, press the  Key.</p>
6	<pre>1:RUN -Complete- Pn80A=000000000 Un000=00000 Un00F=00000 Un005=■■■■■</pre>	-	<p>When the turnup is completed, the display “- Complete -” blinks.</p> <p>Go to step 7 to adjust the offset.</p> <p>Go to step 8 to skip adjusting the offset.</p>
7	<pre>1:RUN -Complete- Pn80A=000000000 Un000=00000 Un00F=00000 Un005=■■■■■</pre>	  	<p>Use the  or  Key to select Pn80A or Pn80C and press the  Key to enable parameter editing.</p> <p>Press the  Key again to select the parameter number.</p>
8	<pre>1:BB -FUNCTION- Fn020:S-Orig Set Fn024:ORT TunUp Fn025:LM Tuning Fn030:Soft Reset</pre>		<p>After turning OFF the /ORT signal, press the  Key.</p> <p>The display returns to the main menu of the utility function mode.</p>

- Note 1. If the tuneup operation does not end, check the gear ratio setting and check to see if the feedback speed is stable.
2. The tuneup operation is not necessary for orientation with a motor encoder. Set Pn81C.3 to 1 to complete the tuneup operation.
3. The motor will operate if you change the setting of Pn80A or Pn80C in step 7. Secure system safety.

13.4.19 Load Ratio Meter Output Gain Adjustment (Fn025)

This function is used to adjust the gain of the load ratio meter output.

The gain is adjusted at the factory. You normally do not need to use this function.

The setting range of the gain adjustment width for the load ratio meter output is -128 to +127 (× 0.4%).

The middle value of the gain adjustment width setting is 100%. For example, if you set -125, $100\% - (125 \times 0.4\%)$ is 50%, so the load ratio meter output voltage is reduced to 1/2. If you set 125, $100\% + (125 \times 0.4\%)$ is 150%, so the load ratio meter output voltage is increased by a factor of 1.5.









(1) Preparation

The following conditions must be met to adjust the load ratio meter output gain.

























- The write prohibited setting (Fn010) must not be set to write-protect parameters.
- All alarms must be cleared.
- The servo must be OFF.

(2) Operating Procedure

Use the following procedure.

Step	Display after Operation	Keys	Operation
1	<pre>1:BB -FUNCTION- Fn024:ORT TunUp Fn025:LM Tuning Fn030:Soft Reset Fn080:Pole Detect</pre>	  	<p>Press the  Key to view the main menu for the utility function mode.</p> <p>Use the  or  Key to move through the list and select Fn025.</p>
2	<pre>1:BB -LM Tuning- Setting Tuning Mode = 0 Type = H</pre>		<p>Press the  Key.</p> <p>The display changes to the Fn025 execution display.</p>

(cont'd)

Step	Display after Operation	Keys	Operation
3	<pre>1:BB -LM Tuning- Setting Tuning Mode= 0 Type = H</pre>	 	Press the  or  Key to select one of the following settings for tuning mode. Tuning Mode = 0: 100% of 10-sec rated output Tuning Mode = 1: 100% of continuous rated output
4	<pre>1:BB -LM Tuning- Setting Tuning Mode= 0 Type = H</pre>		Press the  Key to move the cursor to the type side.
5	<pre>1:BB -LM Tuning- Setting Tuning Mode= 0 Type = H</pre>	 	Press the  or  Key to select one of the following settings for tuning type. Type = Hi: High-speed winding Type = Low: Low-speed winding
6	<pre>1:BB -LM Tuning- Setting Tuning Mode= 0 Type = H</pre>		Press the  Key. The display changes to the Fn025 execution display.
7	<pre>1:BB -LM Tuning- Pn84D= 001.00</pre>	   	Press the  ,  or  ,  Key to set the load ratio meter gain adjustment value (Pn84D).
8	<pre>1:BB -LM Tuning- Pn84D= 001.00</pre>		Press the  Key to write the value into the SERVO-PACK. When the writing is completed, the status display shows "DONE" for two seconds. The status display then returns to show "BB" again.
9	<pre>1:BB -FUNCTION- Fn024:ORT TunUp Fn025:LM Tuning Fn030:Soft Reset Fn080:Pole Detect</pre>		Press the  Key. The display returns to the main menu of the utility function mode.

13.4.20 Anti-Resonance Control Adjustment Function (Fn204)

This function increases the effectiveness of the vibration suppression after adjusting servo gains.

Note: Anti-resonance control adjustment function can be executed from the SigmaWin+ or from a Digital Operator. This section provides the adjustment procedure for a Digital Operator. Refer to 12.3 *Anti-Resonance Control Adjustment Function* for details on anti-resonance control adjustment function and the procedure to execute anti-resonance control adjustment with the Digital Operator.

WARNING

- When this function is executed, the related parameters will be set automatically. This may cause the response characteristics to vary greatly before and after execution of this function. To ensure safety, make sure that an emergency stop can be applied at any time.
Failure to observe this warning may result in injury or damage to the product.
- Before you execute anti-resonance adjustment function, make sure that the moment of inertia ratio (Pn103) is set correctly.
If the setting of the moment of inertia is not correct, normal control may not be possible and vibration may occur.



IMPORTANT

- This function detects vibration between 100 and 1,000 Hz. Vibration will not be detected for frequencies outside of this range, and instead, "F----" will be displayed. If that occurs, set a notch filter manually.
- Vibration can be reduced more effectively by increasing the anti-resonance damping gain (Pn163). The amplitude of vibration may become larger if the damping gain is excessively high. Increase the damping gain from about 0% to 200% in 10% increments while checking the effect of vibration reduction. If the effect of vibration reduction is still insufficient at a gain of 200%, cancel the setting, and lower the servo gain.

(1) Preparation

The following conditions must be met to perform the anti-resonance control adjustment function. The message "NO-OP" indicating that the settings are not appropriate will be displayed, if all of the following conditions are not met.



























- The write prohibited setting (Fn010) must not be set to write-protect parameters.
- The main circuit power supply must be ON.
- All alarms must be cleared.
- The hardwire baseblock (HWBB) must be disabled.

(2) Operating Procedure















With this function, an operation reference is sent, and the function is executed while vibration is occurring.

- Using Anti-Resonance Control for the first time
 - With undetermined vibration frequency
 - With determined vibration frequency
- For fine-tuning after adjusting the Anti-Resonance Control
























■ Using Anti-Resonance Control for the First Time
 • With Undetermined Vibration Frequency

Step	Display after Operation	Keys	Operation
1	<pre>1: RUN —FUNCTION— Fn203: OnePrmTun Fn204: A-Vib Sup Fn205: Vib Sup Fn206: Easy FFT</pre>	  	<p>Press the  Key to view the main menu for the utility function mode.</p> <p>Use the  or  Key to move through the list, select Fn204.</p>
2	<p>Status Display</p> <pre>1: RUN — Vib Sup— Tuning Mode = 0</pre>		<p>Press the  Key to display the initial setting screen for tuning mode.</p>
3	<pre>1: RUN — Vib Sup— Tuning Mode = 0</pre>	 	<p>Press the  or  Key and set the tuning mode “0.”</p>
4	<pre>1: RUN — Vib Sup— freq = ---- Hz damp = 0000</pre>		<p>Press the  Key while “Tuning Mode = 0” is displayed. The screen shown on the left will appear. The detection of vibration frequencies will start and “freq” will flash. Return to step 3 if vibration is not detected.</p>
5	<pre>1: RUN — Vib Sup— freq = 0400 Hz damp = 0000</pre>	—	<p>The vibration frequency will be displayed in “freq” if vibration is detected.</p>  <p>Example of measured waveform</p>
6	<pre>1: RUN — Vib Sup— freq = 0400 Hz damp = 0000</pre>		<p>Press the  Key. The cursor will move to “damp,” and the flashing of “freq” will stop.</p>
7	<pre>1: RUN — Vib Sup— freq = 0400 Hz damp = 0120</pre>	   	<p>Select the digit with the  or  Key, and press the  or  Key to set the damping gain.</p>  <p>Example of measured waveform</p> <p>Note: Increase the damping gain from about 0% to 200% in 10% increments while checking the effect of vibration reduction. If vibration reduction is still insufficient at a gain of 200%, cancel the setting, and lower the servo gain.</p>


























(cont'd)

Step	Display after Operation	Keys	Operation
8	<pre>1:RUN - Vib Sup- freq = 0400 Hz damp = 0120</pre>		If fine tuning of the frequency is necessary, press the  Key. The cursor will move from “damp” to “freq.” If fine-tuning is not necessary, skip step 9 and go to step 10.
9	<pre>1:RUN - Vib Sup- freq = 0420 Hz damp = 0120</pre>	   	Select the digit with the  or  Key, and press the  or  Key to fine-tune the frequency.
10	<pre>1:RUN - Vib Sup- freq = 0420 Hz damp = 0120</pre>		Press the  Key to save the settings. “DONE” will flash for approximately two seconds and “RUN” will be displayed.
11	<pre>1:RUN -FUNCTION- Fn203:OnePrmTun Fn204:A-Vib Sup Fn205:Vib Sup Fn206:Easy FFT</pre>		Press the  Key to complete the anti-resonance control adjustment function. The display returns to the main menu of the utility function mode.

































- With Determined Vibration Frequency

Step	Display after Operation	Keys	Operation
1	<pre>1:RUN -FUNCTION- Fn203:OnePrmTun Fn204:A-Vib Sup Fn205:Vib Sup Fn206:Easy FFT</pre>	  	Press the  Key to view the main menu for the utility function mode. Use the  or  Key to move through the list, select Fn204.
2	<pre>1:RUN - Vib Sup- Tuning Mode = 0</pre>		Press the  Key to display the initial setting screen for tuning mode.
3	<pre>1:RUN -FUNCTION- Tuning Mode = 1</pre>	 	Press the  or  Key and set the tuning mode “1.”
4	<pre>1:RUN - Vib Sup- freq = 0100 Hz damp = 0000</pre>		Press the  Key while “Tuning Mode = 1” is displayed. The screen shown on the left will appear and “freq” will flash.  Example of measured waveform
5	<pre>1:RUN - Vib Sup- freq = 0100 Hz damp = 0000</pre>	   	Select the digit with the  or  Key, and press the  or  Key to adjust the frequency.

(cont'd)

Step	Display after Operation	Keys	Operation
6	<pre>1: RUN - Vib Sup- freq = 0400 Hz damp = 000<u>0</u></pre>		Press the  Key. The cursor will move to “damp.”
7	<pre>1: RUN - Vib Sup- freq = 0400 Hz damp = 002<u>0</u></pre>	   	<p>Select the digit with the  or  Key, and press the  or  Key to adjust the damping gain.</p>  <p>Example of measured waveform</p> <p>Note: Increase the damping gain from about 0% to 200% in 10% increments while checking the effect of vibration reduction. If vibration reduction is still insufficient at a gain of 200%, cancel the setting, and lower the servo gain.</p>
8	<pre>1: RUN - Vib Sup- freq = 0400 Hz damp = 012<u>0</u></pre>		If fine tuning of the frequency is necessary, press the  Key. The cursor will move from “damp” to “freq.” If fine-tuning is not necessary, skip step 9 and go to step 10.
9	<pre>1: RUN - Vib Sup- freq = 0400 Hz damp = 012<u>0</u></pre>	   	Select the digit with the  or  Key, and press the  or  Key to fine-tune the frequency.
10	<pre>1: RUN - Vib Sup- freq = 0400 Hz damp = 012<u>0</u></pre>		Press the  Key to save the settings. “DONE” will flash for approximately two seconds and “RUN” will be displayed.
11	<pre>1: RUN -FUNCTION- Fn203: OnePrmTun Fn204: A-Vib Sup Fn205: Vib Sup Fn206: Easy FFT</pre>		Press the  Key to complete the anti-resonance control adjustment function. The display returns to the main menu of the utility function mode.

■ For Fine-tuning After Adjusting the Anti-Resonance Control

Step	Display after Operation	Keys	Operation
1	<pre>1:RUN —FUNCTION— Fn203:OnePrmTun Fn204:A-Vib Sup Fn205:Vib Sup Fn206:Easy FFT</pre>	  	<p>Press the  Key to view the main menu for the utility function mode.</p> <p>Use the  or  Key to move through the list, select Fn204.</p>
2	<pre>1:RUN —FUNCTION— Tuning Mode = 1</pre>		<p>Press the  Key to display the “Tuning Mode = 1” as shown on the left.</p>
3	<pre>1:RUN —Vib Sup— freq = 0400 Hz damp = 0120</pre>		<p>Press the  Key while “Tuning Mode = 1” is displayed. The screen shown on the left will appear and “damp” will flash.</p>
4	<pre>1:RUN —Vib Sup— freq = 0400 Hz damp = 01<u>5</u>0</pre>	   	<p>Select the digit with the  or  Key, and press the  or  Key to set the damping gain.</p> <p>Note: Increase the damping gain from about 0% to 200% in 10% increments while checking the effect of vibration reduction. If vibration reduction is still insufficient at a gain of 200%, cancel the setting, and lower the servo gain.</p>
5	<pre>1:RUN —Vib Sup— freq = 0400 Hz damp = 01<u>50</u></pre>		<p>If fine tuning of the frequency is necessary, press the  Key. The cursor will move from “damp” to “freq.” If fine-tuning is not necessary, skip step 6 and go to step 7.</p>
6	<pre>1:RUN —Vib Sup— freq = 0420 Hz damp = 01<u>50</u></pre>	   	<p>Select the digit with the  or  Key, and press the  or  Key to fine-tune the frequency.</p>
7	<pre>1:RUN —Vib Sup— freq = 0420 Hz damp = 01<u>50</u></pre>		<p>Press the  Key to save the settings. “DONE” will flash for approximately two seconds and “RUN” will be displayed.</p>
8	<pre>1:RUN —FUNCTION— Fn203:OnePrmTun Fn204:A-Vib Sup Fn205:Vib Sup Fn206:Easy FFT</pre>		<p>Press the  Key to complete the anti-resonance control adjustment function. The display returns to the main menu of the utility function mode.</p>

Standards Compliance

14.1	Harmonized Standards	14-2
14.2	Models That Are Compliant with International Standards	14-3
14.3	Precautions for Complying with European Standards	14-4
14.3.1	EMC Installation Conditions	14-4
14.3.2	Precautions	14-6
14.3.3	Compliance with Low Voltage Directive	14-7
14.4	Precautions for Complying with UL Standards	14-8

14.1 Harmonized Standards

(1) North American Safety Standards (UL)



Products and Models	UL Standards (UL File No.)
Power regeneration converter (CACP-JU□□□3B), SERVOPACK (CACR-JU□□□□E□)	UL508C (E147823)

(2) European Directives



Products and Models	European Directives	Harmonized Standards
Power regeneration converter (CACP-JU□□□3□), SERVOPACK (CACR-JU□□□□E□)	EMC Directive 2004/108/EC	EN 61000-6-4 EN 55011 EN 61000-6-2 EN 61800-3
	Low Voltage Directive 2006/95/EC	EN 61800-5-1

14.2 Models That Are Compliant with International Standards

The models that are compliant with international standards are listed in the following table.

Name	Model	European Standards (CE Marking)	UL Standards
Power Regeneration Converter	CACP-JU15A3A	Compliant	Unsupported
	CACP-JU19A3A		
	CACP-JU22A3A		
	CACP-JU30A3A		
	CACP-JU15D3A		
	CACP-JU19D3A		
	CACP-JU22D3A	Compliant	Compliant
	CACP-JU15A3B		
	CACP-JU19A3B		
	CACP-JU22A3B	Scheduled	Scheduled
	CACP-JU30A3B		
	CACP-JU37A3B		
	CACP-JU45A3B		
	CACP-JU15D3B		
	CACP-JU19D3B	Compliant	Compliant
CACP-JU22D3B			
CACR-JU028AEA			
CACR-JU036AEA			
CACR-JU065AEA			
CACR-JU084AEA			
CACR-JU102AEA	Compliant	Scheduled	
CACR-JU125AEA			
CACR-JU196AEA			
CACR-JU014DEA			
CACR-JU018DEA			
CACR-JU033DEA			
CACR-JU042DEA			
CACR-JU051DEA			

14.3 Precautions for Complying with European Standards


14.3.1 EMC Installation Conditions

This section describes the recommended installation conditions that satisfy EMC guidelines for the Σ -V-SD driver.

This section describes the EMC installation conditions satisfied in test conditions prepared by Yaskawa. The actual EMC level may differ depending on the actual system's configuration, wiring, and other conditions. However, because this product is built-in, check that the following conditions are still met after being installed in the user's product.

The harmonized standards are EN61800-3, EN61000-2 and EN61000-6-4.


(1) Example: With 200-V SERVOPACK with Orientation Control with an External Encoder



Symbol	Cable Name	Specification
①	Main circuit cable	Shield cable
②	Control power cable	Shield cable
③	I/O signal cable (for converter)	Shield cable
④	Spindle motor fan cable	Shield cable
⑤	Local bus communication cable	Shield cable
⑥	Spindle motor main circuit cable	Shield cable
⑦	Spindle motor encoder cable	Shield cable
⑧	External encoder cable	Shield cable
⑨	24-VDC control power supply cable	Unshielded cable
⑩⑪⑫⑬	I/O signal cable (for SERVOPACK)	Shield cable

- *1. Recommended surge absorber model: LT-C32G801WS (Soshin Electric Co., Ltd.)
- *2. For more information on this noise filter, refer to 3.3.3 *Noise Filter*.
- *3. For more information on this AC reactor, refer to 3.3.1 *AC Reactor*.
- *4. Use an LT-C12G801WS Surge Absorber (from Soshin Electric Co., Ltd.) in the input section for the 24-VDC power supply.
- *5. Use an HF2005A-UP Noise Filter (from Soshin Electric Co., Ltd.) in the input section for the 24-VDC power supply.
- *6. Use a 24-VDC control power supply with double insulation against primary or reinforced insulation.

(2) Example: With 200-V SERVOPACK with Orientation Control with a Magnetic Sensor




Symbol	Cable Name	Specification
①	Main circuit cable	Shield cable
②	Control power cable	Shield cable
③	I/O signal cable (for converter)	Shield cable
④	Spindle motor fan cable	Shield cable
⑤	Local bus communication cable	Shield cable
⑥	Spindle motor main circuit cable	Shield cable
⑦	Spindle motor encoder cable	Shield cable
⑧	24-VDC control power supply cable	Unshielded cable
⑨⑩⑪	I/O signal cable (for SERVOPACK)	Shield cable
⑫	Magnetic sensor cable	Unshielded cable

- *1. Recommended surge absorber model: LT-C32G801WS (Soshin Electric Co., Ltd.)
- *2. For more information on this noise filter, refer to 3.3.3 *Noise Filter*.
- *3. For more information on this AC reactor, refer to 3.3.1 *AC Reactor*.
- *4. Use an LT-C12G801WS Surge Absorber (from Soshin Electric Co., Ltd.) in the input section for the 24-VDC power supply.
- *5. Use an HF2005A-UP Noise Filter (from Soshin Electric Co., Ltd.) in the input section for the 24-VDC power supply.
- *6. Use a 24-VDC control power supply with double insulation against primary or reinforced insulation.
- *7. Use the shield cable for magnetic sensor cable, when a FS-1378C magnetic sensor is used.

14.3.2 Precautions

(1) Attachment Methods of Ferrite Cores




(2) Recommended Ferrite Core

Ferrite Core Model	Manufacturer
SFT72SN	TAKEUCHI INDUSTRY Co., Ltd.

(3) Fixing the Cable

Fix and ground the cable shield using a piece of conductive metal.

- Example of Cable Clamp



(4) Shield Box

A shield box, which is a closed metallic enclosure, is effective as reinforced shielding against electromagnetic interference (EMI) from SERVOPACKs. The structure of the box should allow the main body, door, and cooling unit to be attached to the ground. The box opening should be as small as possible.

Note: Do not connect the analog monitor cable to the SERVOPACK during operations.
Connect them only when the machinery is stopped during maintenance.

14.3.3 Compliance with Low Voltage Directive

This drive has been tested according to European standard IEC61800-5-1, and it fully complies with the Low Voltage Directive.

To comply with the Low Voltage Directive, be sure to meet the following conditions when combining this drive with other devices.

(1) Installation Location

Install the servo drive in a location with an overvoltage category of 3 and a pollution degree of 2 or lower according to IEC 664 specifications. Install at an altitude of 1000 m max.

(2) Protection against Foreign Matter

The degree of protection of the servo drives is IP10.

(3) Grounding

Ground the neutral point of the 400-V power supply. The leakage current may exceed 3.5 mA. Therefore, use a 10-mm² or thicker copper grounding wire.

(4) 24-VDC Control Power Supply

Use a 24-VDC control power supply with double insulation or reinforced insulation against primary.

14.4 Precautions for Complying with UL Standards

This drive has been tested according to UL standard UL508C, and it fully complies with the UL requirements.

To comply with the UL standard, be sure to meet the following conditions when combining this drive with other devices.

(1) Installation Location

Install the servo drive in a location with a pollution degree of 2 or lower according to UL specifications. Install at an altitude of 1000 m max.

(2) Wiring the Main Circuit Terminals

Wire the main circuit terminals with the maximum tightening torque that is given in 5.2.1 (1) *Wire Sizes and Tightening Torques*.

(3) Short-circuit Rating

This servo drive has undergone UL short-circuit testing using a power supply with a current of 31,000 A maximum and a voltage of 480 V maximum.

(4) 24-VDC Control Power Supply

Use a 24-VDC control power supply with double insulation or reinforced insulation.

(5) AC Reactor

Use an AC reactor for UL compliance according to 3.3.1 (1) *Specifications*.

(6) Magnetic Contactor for Winding Selection

Use a magnetic contactor for winding selection for UL compliance according to 3.3.2 (1) *Specifications*.

(7) Heat Sink Cooling

To cool the heat sink, provide an air flow of 2.5 m/s in the ventilation duct or use the Base Mounting Unit from Yaskawa.

Refer to 2.3.6 *Base Mounting Units* and 3.3.4 *Base Mounting Units* for information on the Base Mounting Units.

(8) Grounding

Ground the neutral point of a 400-V power supply.

The leakage current may exceed 3.5 mA. Therefore, use a 10-mm² or thicker copper grounding wire.

Inspection, Maintenance, and Troubleshooting

15.1 Inspection and Maintenance	15-2
15.1.1 Spindle Motor	15-2
15.1.2 Σ -V-SD Driver	15-3
15.2 Troubleshooting	15-4
15.2.1 List of Alarms	15-4
15.2.2 Troubleshooting of Alarms	15-10
15.3 Warning Displays	15-29
15.3.1 List of Warnings	15-29
15.3.2 Troubleshooting of Warnings	15-30
15.4 Troubleshooting Malfunction Based on Operation and Conditions of the Spindle Motor	15-33

15.1 Inspection and Maintenance

15.1.1 Spindle Motor

(1) Inspection

The following table provides explanations about the inspections required for the spindle motor. The inspection and maintenance frequencies in the table are only guidelines. Increase or decrease the frequency to suit the operating conditions and environment.

Item	Frequency	Procedure	Comments
Vibration and Noise	Daily	Touch and listen. There is no problem as long as vibration and the sound level do not increase over normal levels.	–
Exterior	According to degree of contamination	Clean with cloth or compressed air.	–
Insulation Resistance Measurement	At least once a year	Disconnect the SERVOPACK and test the insulation resistance with a 500-V resistance meter between each of the phases U, V, and W in the motor's main circuit cable and FG. Must exceed 10 MΩ	Contact your Yaskawa representative if the insulation resistance is below 10 MΩ .
Overhaul	At least once every 12,000 hours or 2 years.	Contact your Yaskawa representative.	–



IMPORTANT

During inspection and maintenance, do not disassemble the motor.

(2) Replacement Schedule

The parts of the spindle motor have a limited service life due to mechanical wear. Perform periodic inspections for preventive maintenance. The part replacement period varies with the usage condition and usage environment. A part must be replaced if there is any problem, even if it is not yet time to replace it. Contact your Yaskawa representative if a part needs to be replaced or if the standard replacement period has elapsed.

Part	Standard Replacement Period	Remarks
Cooling fan	12,000 hours or 2 years	A part must be replaced if there is any problem, even if the standard replacement period has not yet elapsed.
Bearing		

15.1.2 Σ -V-SD Driver

(1) Inspection


For inspections and maintenance of the Σ -V-SD Driver, follow the inspection procedures in the table below at least once every year.

Item	Frequency	Procedure	Remedy
Exterior	At least once a year	Check for dust, dirt, and oil on surfaces.	Clean with compressed air or cloth.
Loose screws		Check for loose terminal block and connector screws.	Tighten any loose screws.

(2) Replacement Schedule

The following electric or electronic parts are subject to mechanical wear or deterioration over time. To avoid failure, replace these parts at the frequency indicated.

Refer to the standard replacement period in the following table, contact your Yaskawa representative. After an examination of the part in question, we will determine whether the parts should be replaced or not.

 IMPORTANT	<p>The parameters of any SERVOPACKs overhauled by Yaskawa are reset to the factory settings before shipping. The motor constants are also reset to the factory settings at the same time. Before you start operation again, make sure that you reset the parameters that are required for operation.</p>
---	--

Part	Standard Replacement Period	Operating Conditions
Cooling Fan	4 to 5 years	<ul style="list-style-type: none"> • Surrounding Air Temperature: Annual average of 30°C • Load Factor: 80% max. • Operation Rate: 20 hours/day max.
Smoothing Capacitor	7 to 8 years	
Relays	–	
Fuses	10 years	
Aluminum Electrolytic Capacitor on Circuit Board	5 years	

Note: If the above operating conditions are not used, replacement may be required sooner than the standard replacement period. To extend the life of the parts, reduce the surrounding air temperature. Contact your Yaskawa representative if you require more-detailed information.

15.2 Troubleshooting

The following sections describe troubleshooting in response to alarm displays.

The alarm name, alarm meaning, alarm stopping method and alarm reset capability are listed in order of the alarm numbers in *15.2.1 List of Alarms*.

The causes of alarms and troubleshooting methods are provided in *15.2.2 Troubleshooting of Alarms*.

15.2.1 List of Alarms

If an alarm occurs, the motor can be stopped by doing either of the following operations.

Gr.1: The motor coasts to a stop.

Gr.2: The motor is stopped according to the setting in Pn00B.1 if an alarm occurs. Pn00B.1 is factory-set to stop the motor by setting the speed reference to "0." By setting Pn00B.1 to 1, the motor stops using the same method as Gr.1.

Available: Removing the cause of alarm and then executing the alarm reset can clear the alarm.
N/A: Executing the alarm reset cannot clear the alarm.

Alarm Display	Alarm Name	Meaning	Motor Stop Method	Alarm Reset	Alarm Code Output			
					FC3	FC2	FC1	FC0
A.020	Parameter Checksum Error	The data of the parameter in the SERVO-PACK is incorrect.	Gr.1	N/A				
A.021	Parameter Format Error	The data format of the parameter in the SERVOPACK is incorrect.	Gr.1	N/A				
A.022	System Checksum Error	The data of the parameter in the SERVO-PACK is incorrect.	Gr.1	N/A				
A.029	Motor Parameter Checksum Error	The motor parameter data in the SERVO-PACK is corrupted.	Gr.1	N/A				
A.02C	Converter Parameter Checksum Error	The data of the parameter in the power regeneration converter is incorrect.	Gr.1	N/A				
A.02D	Converter Parameter Format Error	The format of the parameter in the power regeneration converter is incorrect.	Gr.1	N/A				
A.02E	Converter System Checksum Error	The data of the parameter in the power regeneration converter is incorrect.	Gr.1	N/A				
A.030	Main Circuit Detector Error	Detection data for main circuit is incorrect.	Gr.1	Available				
A.040	Parameter Setting Error	The parameter setting in the SERVOPACK is outside the allowable setting range.	Gr.1	N/A	L	L	L	L
A.042	Parameter Combination Error	Combination of some parameters exceeds the setting range.	Gr.1	N/A				
A.04B	Converter Parameter Setting Error	The parameter setting in the power regeneration converter is outside the allowable setting range.	Gr.1	N/A				
A.050	Combination Error	The SERVOPACK and the motor capacities do not match each other.	Gr.1	Available				
A.051	Unsupported Device Alarm	The device unit unsupported was connected.	Gr.1	N/A				
A.052	Motor Type Setting Mismatch	The motor type/Application selection setting (Pn01E.0) does not match the motor constant written inside the SERVOPACK.	Gr.1	N/A				
A.053	Winding Selection Setting Mismatch	The Winding Change Setting (Pn01E.1) does not match the motor constant written inside the SERVOPACK.	Gr.1	N/A				
A.054	Unsupported Winding Selection Alarm	The combination of the SERVOPACK and spindle motor does not support winding selection.	Gr.1	N/A				

(cont'd)

Alarm Display	Alarm Name	Meaning	Motor Stop Method	Alarm Reset	Alarm Code Output			
					FC3	FC2	FC1	FC0
A.055	Motor Encoder/Load Shaft Encoder Setting Error	The settings for the Encoder Type (Pn01F.0) and the Load Shaft Encoder Type (Pn01A.0) conflict with each other.	Gr.1	N/A				
A.05A	Induction Motor Combination Error	The capacity of the spindle motor is outside of the range that can be combined.	Gr.1	N/A	L	L	L	L
A.05B	Converter Combination Error	The converter and SERVOPACK are not combined correctly.	Gr.1	N/A				
A.0B0	Cancelled Servo ON Command Alarm	/FWD or /REV signal was input from the host controller after the Servo ON function was used with the utility function.	Gr.1	Available				
A.100	Overcurrent	An overcurrent flowed through the IGBT. Heat sink of the SERVOPACK was overheated.	Gr.1	N/A				
A.10A	Converter Overcurrent	An overcurrent flowed through the power transistor inside the power regeneration converter.	Gr.1	N/A	L	L	L	H
A.11A	Converter Ground Fault	A ground fault occurred inside the power regeneration converter.	Gr.1	N/A				
A.22A	Converter Fuse Blowout	The fuse of the main power supply inside the power regeneration converter is blown out.	Gr.1	N/A	L	L	H	L
A.400	Overvoltage	The main circuit DC voltage inside the SERVOPACK is excessively high.	Gr.1	Available				
A.40A	Converter Overvoltage	The main circuit DC voltage inside the power regeneration converter is abnormally high.	Gr.1	Available				
A.40B	Converter AC Overvoltage	The AC power supply voltage inside the power regeneration converter is abnormally high.	Gr.1	Available				
A.40C	Abnormal Voltage in Converter Main Circuit	An error occurred in the main circuit of the power regeneration converter.	Gr.1	Available				
A.410	Undervoltage	Main circuit DC voltage is excessively low.	Gr.2	Available	L	H	L	L
A.41A	Converter DC Undervoltage	The main circuit DC voltage inside the power regeneration converter is abnormally low.	Gr.2	Available				
A.41B	Converter AC Undervoltage	The AC voltage inside the power regeneration converter is abnormally low.	Gr.1	Available				
A.41C	Power Failure While Motor Running	The AC power supply was cut off while the motor was running.	Gr.1	Available				
A.42C	Converter Initial Charging Error	The charging of the main circuit capacitor did not finish within the specified period of time.	Gr.1	Available				
A.450	Main Circuit Capacitor Overvoltage	The capacitor of the main circuit has deteriorated or is faulty.	Gr.1	N/A				
A.510	Overspeed	The motor speed is excessively high.	Gr.1	Available				
A.531	Excessive Speed Deviation	The deviation between the speed reference and the actual motor speed is abnormal.	Gr.1	Available	L	H	L	H
A.540	Overspeed (During Low-speed Winding)	The low-speed winding maximum rotation speed was exceeded during low-speed winding.	Gr.1	Available				
A.682	Tuneup Not Completed Error	An orientation command was detected when the tuneup operation had not been performed.	Gr.1	Available				
A.683	Phase-C Signal Detection Error	The phase-C signal was not detected during the tuneup operation.	Gr.1	Available	L	H	H	L

(cont'd)

Alarm Display	Alarm Name	Meaning	Motor Stop Method	Alarm Reset	Alarm Code Output			
					FC3	FC2	FC1	FC0
A.684	Pulses Per Revolution Error	There was an error in the number of pulses per spindle shaft revolution during the tuneup operation.	Gr.1	Available	L	H	H	L
A.685	Phase-C Signal Width Error	The width of the phase-C signal was 100 pulses or greater at tuneup.	Gr.1	Available				
A.686	Magnetic Sensor Signal Detection Error	The voltage level of the magnetic sensor signal was not a suitable value at tuneup.	Gr.1	Available				
A.687	Magnetic Sensor Signal Disconnection Error	<ul style="list-style-type: none"> The magnetic sensor signal is disconnected or wired incorrectly. The magnetic sensor did not read the magnetic signal correctly during orientation. 	Gr.1	Available				
A.690	Winding Selection Operation Fault	<ul style="list-style-type: none"> During the winding selection operation check that is performed when the power is turned ON, the electromagnetic contactor for winding selection did not change according to the internal command. Winding selection was not completed within two seconds of receiving the winding selection command. Chattering occurred in the electromagnetic contactor for winding selection when the winding selection command was not received. 	Gr.1	N/A				
A.710	Overload: High Load	The motor was operating for several seconds to several tens of seconds under a torque largely exceeding ratings.	Gr.2	Available				
A.720	Overload: Low Load	The motor was operating continuously under a torque largely exceeding ratings.	Gr.1	Available				
A.72A	Converter Electric Operation Overload	Continuous electrical operation was performed that exceeded the rated output of the power supply regenerative converter.	Gr.2	Available				
A.72B	Converter Power Supply Regenerative Overload	Continuous regenerative operation was performed that exceeded the ratings of the power regenerative converter.	Gr.1	Available				
A.74A	Converter Inrush Resistance Overload	The main circuit power supply turned ON and OFF frequently.	Gr.1	Available				
A.790	Motor Overheated	The motor temperature exceeded the upper limit.	Gr.1	Available	L	H	H	H
A.791	Motor Temperature Detection Error	The motor thermistor is either disconnected or is damaged.	Gr.1	N/A				
A.7A0	Heat Sink in SERVOPACK Overheated	The temperature of the heat sink in the SERVOPACK exceeded 100°C, or the thermistor in the SERVOPACK was disconnected or damaged.	Gr.2	Available				
A.7AB	Built-in Fan in SERVOPACK Stopped*	The fan inside the SERVOPACK stopped.	Gr.1	Available				
A.7AC	Built-in Fan in Converter Stopped*	The fan inside the power regeneration converter stopped.	Gr.1	Available				
A.7BA	Converter Heat Sink Overheated	The heat sink inside the power regeneration converter exceeded 100°C, or the thermistor in the converter was disconnected or damaged.	Gr.2	Available				

* If the fan stops, an alarm or a warning will issued in accordance with the setting of SERVOPACK parameter Pn00D.2.

(cont'd)

Alarm Display	Alarm Name	Meaning	Motor Stop Method	Alarm Reset	Alarm Code Output			
					FC3	FC2	FC1	FC0
A.98A	INC Signal Error	There was an error in the input timing of the INC signal.	Gr.1	Available	H	L	L	H
A.B11	Speed Reference A/D Data Error	A malfunction occurred in the speed reference A/D data detection section.	Gr.2	Available	H	L	H	H
A.B31	Current Detection Error1 (Phase-U)	The current detection circuit for phase-U is faulty.	Gr.1	N/A				
A.B32	Current Detection Error 2 (Phase-V)	The current detection circuit for phase-V is faulty.	Gr.1	N/A				
A.B33	Current Detection Error 3 (Current detector)	The detection circuit for the current is faulty.	Gr.1	N/A				
A.B4A	Converter Gate Drive Output Error	An error occurred in the gate drive signal of power transistor of the power regeneration converter.	Gr.1	N/A				
A.BDA	Converter CPU: AD Conversion Circuit Error	An error occurred in the A/D conversion circuit inside the power regeneration converter.	Gr.1	Available				
A.BDB	Converter Reference Voltage Error 1	An error occurred in the reference voltage output inside the power regeneration converter.	Gr.1	Available				
A.BDC	Converter Reference Voltage Error 2	An error occurred in the reference voltage output inside the power regeneration converter.	Gr.1	Available				
A.BDD	Converter System Error 0	Internal program error 0 occurred inside the power regeneration converter.	Gr.1	N/A				
A.BEA	Converter System Error 1	Internal program error 1 occurred inside the power regeneration converter.	Gr.1	N/A				
A.BEB	Converter System Error 2	Internal program error 2 occurred inside the power regeneration converter.	Gr.1	N/A				
A.BF0	System Alarm 0	Internal program error 0 occurred in the SERVOPACK.	Gr.1	N/A				
A.BF1	System Alarm 1	Internal program error 1 occurred in the SERVOPACK.	Gr.1	N/A				
A.BF2	System Alarm 2	Internal program error 2 occurred in the SERVOPACK.	Gr.1	N/A				
A.BF3	System Alarm 3	Internal program error 3 occurred in the SERVOPACK.	Gr.1	N/A				
A.BF4	System Alarm 4	Internal program error 4 occurred in the SERVOPACK.	Gr.1	N/A				

15.2.1 List of Alarms

(cont'd)

Alarm Display	Alarm Name	Meaning	Motor Stop Method	Alarm Reset	Alarm Code Output			
					FC3	FC2	FC1	FC0
A.C10	Servo Overrun Detected	The motor ran out of control.	Gr.1	Available				
A.C2A	Pulse Encoder Phase C Error/Pulse Error	The number of pulses per revolution exceeded the setting range.	Gr.1	N/A				
A.C3A	Pulse Encoder Phase A Disconnection	The signal line for phase A of the pulse encoder is disconnected.	Gr.1	N/A				
A.C3B	Pulse Encoder Phase B Disconnection	The signal line for phase B of the pulse encoder is disconnected.	Gr.1	N/A				
A.C3C	Pulse Encoder Phase C Disconnection	The signal line for phase C of the pulse encoder is disconnected.	Gr.1	N/A	H	H	L	L
A.C3D	External Encoder Phase A Disconnection	The signal line for phase A of the load pulse encoder is disconnected.	Gr.1	N/A				
A.C3E	External Encoder Phase B Disconnection	The signal line for phase B of the load pulse encoder is disconnected.	Gr.1	N/A				
A.C3F	External Encoder Phase C Disconnection	The signal line for phase C of the load pulse encoder is disconnected.	Gr.1	N/A				
A.C50	Phase C Not Detected	Phase C was not detected during the first two rotations after the power supply was turned ON.	Gr.1	N/A				
A.D00	Position Error Pulse Overflow	Position error pulses exceeded parameter (Pn520).	Gr.1	Available				
A.D01	Position Error Pulse Overflow Alarm at Servo ON	Position error pulses accumulated too much.	Gr.1	Available				
A.D02	Position Error Pulse Overflow Alarm by Speed Limit at Servo ON	After a position error pulse has been input, Pn529 limits the speed if the SV_ON command is received. If Pn529 limits the speed in such a state, this alarm occurs when the position references are input and the number of position error pulses exceeds the value set for parameter Pn520 (Excessive Position Error Alarm Level).	Gr.2	Available	H	H	L	H
A.E02	System Alarm 6	Internal program error 6 occurred in the SERVOPACK.	Gr.1	Available				
A.EA0	SERVOPACK Failure (DRV alarm 0)	SERVOPACK alarm 0 occurred.	Gr.1	N/A				
A.EA1	SERVOPACK Initial Access Error	The SERVOPACK initial access alarm occurred.	Gr.1	N/A				
A.EA2	DRV Alarm 2 (SERVOPACK WDC error)	A SERVOPACK DRV alarm 0 occurs.	Gr.2	Available				
A.EB1	HWBB Function Signal Input Timing Error	The HWBB function signal input timing is faulty.	Gr.1	N/A				
A.ED2	DAS Signal Setting Conflict	The DAS signal conflicts with the 12-bit digital reference signal selection.	Gr.1	Available	H	H	H	L
A.EEA	Converter Local Bus WD Error	A power regeneration converter local bus WD alarm occurred.	Gr.1	N/A				
A.EEB	Converter Local Bus Communications Error	A communications error occurred during the power regeneration converter local bus communications.	Gr.1	Available				
A.EF0	Local Bus Connection Error	The local bus is not connected.	Gr.1	Available				
A.EF2	Local Bus Drive WD Error	A local bus watchdog alarm occurred in the SERVOPACK.	Gr.2	N/A				
A.EF4	Local Bus Communications Error	An error occurred during local bus communications.	Gr.2	Available				

(cont'd)

Alarm Display	Alarm Name	Meaning	Motor Stop Method	Alarm Reset	Alarm Code Output			
					FC3	FC2	FC1	FC0
A.F1A	Converter AC Power Supply Open Phase	The voltage was low for one second in phase L1, L2, or L3 when the main power supply was turned ON.	Gr.1	Available	H	H	H	H
A.F2A	Converter AC Power Supply Frequency Error	The power supply frequency is faulty.	Gr.1	Available				
A.F2B	Converter AC Power Supply Frequency Detection Time Exceeded	The detection of the AC power supply input frequency was not completed within the set time.	Gr.1	Available				
A.F3B	Converter AC Power Supply Phase Sequence Error	An error occurred in the AC power supply phase sequence.	Gr.1	N/A				

15.2.2 Troubleshooting of Alarms

When an error occurs in the servo drives, LEDs on the panel operator will light up. Refer to the following table to identify the cause of an alarm and the action to be taken.

Contact your Yaskawa representative if the problem cannot be solved by the described corrective action.

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.020: Parameter Checksum Error (The parameter data in the SERVOPACK is incorrect.)	The power supply voltage suddenly dropped.	Measure the power supply voltage.	Set the power supply voltage within the specified range, and set Fn005 to initialize the parameter.
	The power supply went OFF while changing a parameter setting.	Note the circumstances when the power supply went OFF.	Set Fn005 to initialize the parameter and then set the parameter again.
	The number of times that parameters were written exceeded the limit.	Check to see if the parameters were frequently changed through the host controller.	The SERVOPACK may be faulty. Replace the SERVOPACK. Reconsider the method of writing parameters.
	Malfunction caused by noise from the AC power supply or grounding line, static electricity noise, etc.	Turn the power supply ON and OFF several times. If the alarm still occurs, there may be noise interference.	Take countermeasures against noise.
	Gas, water drops, or cutting oil entered the SERVOPACK and caused failure of the internal components.	Check the installation conditions.	The SERVOPACK may be faulty. Replace the SERVOPACK.
	SERVOPACK failure	Turn the power supply ON and OFF several times. If the alarm still occurs, the SERVOPACK is faulty.	The SERVOPACK may be faulty. Replace the SERVOPACK.
A.021: Parameter Format Error (The data format of the parameter in the SER- VOPACK is incorrect.)	The software version of SERVOPACK that caused the alarm is older than that of the written parameter.	Check SigmaWin+ to see if the set software version agrees with that of the SERVOPACK. If not, an alarm may occur.	Write the parameter of another SERVOPACK of the same model with the same software version. Then turn the power OFF and then ON again.
	SERVOPACK failure	–	The SERVOPACK may be faulty. Replace the SERVOPACK.
A.022: System Checksum Error (The parameter data in the SERVOPACK is incorrect.)	The power supply voltage suddenly dropped.	Measure the power supply voltage.	The SERVOPACK may be faulty. Replace the SERVOPACK.
	The power supply went OFF while setting an utility function.	Note the circumstances when the power supply went OFF.	The SERVOPACK may be faulty. Replace the SERVOPACK.
	SERVOPACK failure	Turn the power supply ON and OFF several times. If the alarm still occurs, the SERVOPACK is faulty.	The SERVOPACK may be faulty. Replace the SERVOPACK.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.029: Motor Parameter Checksum Error (The motor parameter data in the SERVO- PACK is corrupted.)	Writing the motor parameters failed.	Check to see if write processing ended before the write was completed.	Write the motor parameters again.
	Motor Parameter Error	Check to see if suitable motor parameters were written.	Write suitable motor parameters.
	The power supply voltage suddenly dropped.	Measure the power supply voltage.	Set the power supply voltage within the specified range.
	The power supply went OFF while changing a motor parameter setting.	Note the circumstances when the power supply went OFF.	Write the motor parameters again.
	The number of times that motor parameters were written exceeded the limit.	Check to see if the parameters were frequently changed.	The SERVOPACK may be faulty. Repair or replace the SERVOPACK.
	Malfunction caused by noise from the AC power supply or grounding line, static electricity noise, etc.	Turn the power supply ON and OFF several times. If the alarm still occurs, there may be noise interference.	Take countermeasures against noise.
	Gas, water drops, or cutting oil entered the SERVOPACK and caused failure of the internal components.	Check the installation conditions.	The SERVOPACK may be faulty. Replace the SERVOPACK.
SERVOPACK failure	Turn the power supply ON and OFF several times. If the alarm still occurs, the SERVOPACK is faulty.	The SERVOPACK may be faulty. Replace the SERVOPACK.	
A.02C: Converter Parameter Checksum Error (The parameter data in the power regeneration converter is incorrect.)	Power regeneration converter failure	—	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.02D: Converter Parameter Format Error (The parameter format in the power regeneration converter is incorrect.)	Power regeneration converter failure	—	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.02E: Converter System Checksum Error (The parameter data in the power regeneration converter is incorrect.)	Power regeneration converter failure	—	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.030: Main Circuit Detector Error	SERVOPACK failure	—	The SERVOPACK may be faulty. Replace the SERVOPACK.
A.040: Parameter Setting Error (The parameter setting was out of the allowable setting range.)	The SERVOPACK and motor capacities do not match each other.	Check the combination of SERVOPACK and motor capacities.	Select the proper combination of SERVOPACK and spindle motor capacities.
	SERVOPACK failure	—	The SERVOPACK may be faulty. Replace the SERVOPACK.
	The parameter setting is out of the specified range.	Check the setting ranges of the parameters that have been changed.	Set the parameter to a value within the specified range.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.042: Parameter Combination Error	The speed of program JOG operation is lower than the setting range after having changed the setting of Pn533 "Program JOG Movement Speed."	Check that the detection conditions* is satisfied.	Increase the setting for Pn533 "Program JOG Movement Speed."
A.04B: Converter Parameter Setting Error (The parameter data in the power regeneration converter is incorrect.)	Power regeneration converter failure	—	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.050: Combination Error (The SERVOPACK and motor capacities do not correspond.)	The SERVOPACK and motor capacities do not match each other.	Check the capacities to see if they satisfy the following condition: $1/4 \leq \frac{\text{Motor capacity}}{\text{SERVOPACK capacity}} \leq 4$	Select the proper combination of SERVOPACK and spindle motor capacities.
	Encoder failure	Replace the motor and see if the alarm occurs again.	Replace the spindle motor (encoder).
	SERVOPACK failure	—	The SERVOPACK may be faulty. Replace the SERVOPACK.
A.051: Unsupported Device Alarm	An unsupported pulse encoder is connected to the SERVOPACK.	Check the product specifications, and select the correct model.	Select the correct combination of units.
A.052: Motor Type Setting Mismatch (The Motor Type/Application Selection Setting (Pn01E.0) does not match the motor constant written inside the SERVOPACK.)	The Motor Type Setting (Pn01E.0) is wrong.	Check the parameter setting (Pn01E.0) and the motor that is used in combination with the SERVOPACK.	Correct the Motor Type Setting (Pn01E.0) according to the combined spindle motor.
	A mistake occurred in writing the motor constant file.	Check the model of the combined motor from the product information monitor in SigmaWin+.	Write the motor constant file in the SERVOPACK according to the combined spindle motor.
A.053: Winding Selection Setting Mismatch (The Winding Change Setting (Pn01E.1) does not match the motor constant written inside the SERVOPACK.)	The Motor Type Setting (Pn01E.0) is wrong.	Check the parameter setting (Pn01E.0) and the motor that is used in combination with the SERVOPACK.	Correct the Motor Type Setting (Pn01E.0) according to the combined spindle motor.
	The Winding Change Setting (Pn01E.1) is wrong.	Check the parameter setting (Pn01E.1) and the motor that is used in combination with the SERVOPACK.	Correct the Winding Change Setting (Pn01E.1) according to the combined motor.
	A mistake occurred in writing the motor constant file.	Check the model of the combined motor from the product information monitor in SigmaWin+.	Write the motor constant file in the SERVOPACK according to the combined spindle motor.
A.054: Unsupported Winding Selection Alarm (The combination of the SERVOPACK and motor does not support winding selection)	The combination of the SERVOPACK and motor does not allow winding selection.	—	Change the combination of the SERVOPACK and spindle motor.

* Detection Condition Formulas

An alarm is detected if either of the following two conditions is met.

- $\text{Pn533} [\text{min}^{-1}] \times \frac{\text{Encoder resolution}}{6 \times 10^5} \leq 1$
- $\text{Motor max. speed} [\text{min}^{-1}] \times \frac{\text{Encoder resolution}}{\text{Approx } 3.66 \times 10^{12}} \geq 1$

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.055 Motor Encoder/Load Shaft Encoder Setting Error	The settings of the Encoder Type (Pn01F.0) and the Load Shaft Encoder Type (Pn01A.0) conflict with each other.	Check the settings of the Encoder Type (Pn01F.0) and the Load Shaft Encoder Type (Pn01A.0).	Set the Encoder Type (Pn01F.0) and the Load Shaft Encoder Type (Pn01A.0) correctly.
A.05A: Induction Motor Combination Error (The capacity of the spindle motor is outside of the range that can be combined.)	The SERVOPACK capacity and spindle motor capacity are not compatible.	Check the combination of the SERVOPACK capacity and servomotor capacity.	Align the SERVOPACK capacity and spindle motor capacity.
A.05B: Converter Combination Error (The converter and SER- VOPACK are not com- bined correctly.)	A converter that does not support an emergency stop was used with Pn01B.0 set to 1.	–	Replace the converter.
A.0B0: Cancelled Servo ON Command Alarm	After executing the utility function to turn ON the power to the motor, /FWD or /REV signal was input from the host controller.	–	Turn the SERVOPACK power supply OFF and then ON again.
A.100: Overcurrent (An overcurrent flowed through the IGBT or heat sink of SERVO- PACK overheated.)	Incorrect wiring or contact fault of main circuit cable or motor main circuit cable.	Check the wiring.	Correct the wiring.
	Short-circuit or ground fault of main circuit cable or motor main circuit cable.	Check for short-circuits across the cable phase-U, -V, and -W, or between the grounding and terminal U, V, or W.	Some cables may be damaged. Replace damaged cables.
	Short-circuit or ground fault inside the motor.	Check for short-circuits across the motor terminal phase-U, -V, and -W, or between the grounding and motor terminal U, V, or W.	The motor may be faulty. Replace the spindle motor.
	Short-circuit or ground fault inside the SERVOPACK.	Check for short-circuits across the motor connection terminals U, V, and W on the SERVOPACK, or between the grounding and terminal U, V, or W.	The SERVOPACK may be faulty. Replace the SERVOPACK.
	A heavy load was applied while the motor was stopped or running at a low-speed.	Check to see if the operating conditions are outside servo drive specifications.	Reduce the load applied to the spindle motor or increase the operation speed.
	Malfunction caused by noise interference.	Improve the wiring or installation environment, such as by reducing noise, and check to see if the alarm recurs.	Take countermeasures for noise, such as correct wiring of the FG. Use an FG wire size equivalent to the SERVOPACK main circuit wire size.
	SERVOPACK failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.10A: Converter Overcurrent (An overcurrent flowed through the power transistor inside the power regeneration converter.)	A mistake occurred when selecting the power regeneration converter capacity.	Check the power regeneration converter capacity and the total output capacity of the SERVOPACK.	Change the power regeneration converter capacity.
	An unmatched AC reactor is used.	–	Use the specified AC reactor.
	The main circuit cable is either incorrectly wired or has a contact fault.	Make sure the wiring is correct.	Correct the wiring.
	A short-circuit or ground fault occurred in the main circuit cable.	Check for short-circuits across phase R, S, and T of the cable, or between the ground and phase R, S, or T.	The cable may have short-circuited. Replace the cable.
	A short-circuit or ground fault occurred in the power regeneration converter.	Check for short-circuits across phase R, S, and T of the main circuit power supply connection terminal of the power regeneration converter, or between the ground and phase R, S, or T.	The power regeneration converter may be faulty. Replace the power regeneration converter.
	Malfunction caused by noise.	Improve the noise environment, including the wiring and installation, and check to see if the alarm occurs again.	Take measures against noise, such as wiring the FG correctly. Match the FG wire size with the SERVOPACK main circuit wire size.
	A short-circuit or ground fault occurred in the AC reactor.	–	The AC reactor may be faulty. Replace the AC reactor.
A.11A: Converter Ground Fault (A ground fault occurred.)	Power regeneration converter failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
	Ground fault of motor cable	Check for short-circuits between the cable phase-U, -V, and -W and the grounding.	The cable may be faulty. Replace the cable.
	Ground fault inside the motor	Check for short-circuits between the motor terminals U, V, and W and the grounding.	The motor may be faulty. Replace the spindle motor.
	Ground fault of main circuit in the SERVOPACK	Check for short-circuits between the motor connection terminals U, V, and W on the SERVOPACK and the grounding, or between terminals P and N and the grounding.	The SERVOPACK may be faulty. Replace the SERVOPACK.
	Ground fault of main circuit in the power regeneration converter	Check for short-circuits between the power connection terminals L1, L2, and L3 on the power regeneration converter and the grounding, or between terminals P and N and the grounding.	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.22A: Converter Fuse Blowout (The fuse of the main power supply inside the power regeneration converter is blown out.)	Power regeneration converter failure	Turn the control power ON and check if an alarm occurs.	If an alarm occurs after turning the control power ON, the power regeneration converter may be faulty. Replace the power regeneration converter.
	The fuse of the main power supply inside the power regeneration converter is blown out.	–	Replace the power regeneration converter.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.400: Overvoltage (The main circuit DC voltage inside the SERVOPACK is abnormally high.)	<ul style="list-style-type: none"> For 200 VAC SERVOPACKs with DC power supply input: The power supply voltage exceeded 410 V. For 400 VAC SERVOPACKs with DC power supply input: The power supply voltage exceeded 820 V. 	Measure the power supply voltage.	Set AC/DC power supply voltage within the specified range.
	The power supply is unstable, or was influenced by a lightning surge.	Measure the power supply voltage.	Improve the power supply conditions, and turn the power supply ON again after installing a surge absorber. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
	Acceleration/deceleration was executed under the following conditions. <ul style="list-style-type: none"> The AC power supply voltage of 200 VAC SERVOPACK was in the range between 230 V and 270 V. The AC power supply voltage of 400 VAC SERVOPACK was in the range between 480 V and 560 V. 	Check the power supply voltage and the speed and torque during operation.	Set AC power supply voltage within the specified range.
	The moment of inertia exceeded the allowable value.	Confirm that the moment of inertia ratio is within the allowable range.	Increase the deceleration time, or reduce the load.
	SERVOPACK failure	—	Turn the control power OFF and then ON again while the main circuit power supply is OFF. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.40A: Converter Overvoltage (The main circuit DC voltage inside the converter is abnormally high.)	<ul style="list-style-type: none"> For 200 V power regeneration converter with DC power supply input: The power voltage exceeded 410 V. For 400 V power regeneration converter with DC power supply input: The power voltage exceeded 820 V. 	Measure the power supply voltage.	Set the AC/DC power supply voltage within the specified range.
	The power supply is unstable, or was influenced by a lightening surge.	Measure the power supply voltage.	Improve the power supply conditions, and turn ON the power supply again after installing a surge absorber. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
	Acceleration/deceleration was executed under the following conditions. <ul style="list-style-type: none"> The AC power supply voltage of 200 VAC SERVOPACK was in the range between 230 V and 270 V. The AC power supply voltage of 400 VAC SERVOPACK was in the range is between 480 V and 560 V. 	Check the power supply voltage and the speed and torque during operation.	Set the AC power supply voltage within the specified range.
	The moment of inertia exceeded the allowable value in the SERVOPACK connected to the power regeneration converter.	Make sure the moment of inertia ratio is within the allowable range.	Increase the deceleration time, or reduce the load.
	A mistake occurred when selecting the power regeneration converter capacity.	Check the power regeneration converter capacity and the total output capacity of the SERVOPACK.	Change the power regeneration converter capacity.
	Power regeneration converter failure	—	Turn OFF the control power and then turn it ON again while the main circuit power supply is OFF. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
A.40B: Converter AC Overvoltage (The AC power supply voltage inside the converter is abnormally high.)	The main circuit cable is either incorrectly wired or has a contact fault.	Make sure the wiring is correct.	Correct the wiring.
	The main circuit power supply voltage is higher than the specified range.	Measure the AC power supply voltage.	Set the voltage to an appropriate value.
	An error occurred in the AC voltage detection circuit inside the power regeneration converter.	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.40C: Abnormal Voltage in Converter Main Circuit (An error occurred in the main circuit of the power regeneration converter.)	The AC voltage is unstable.	Measure the AC power supply voltage.	Improve the power supply conditions.
	The DC bus voltage is unstable, or an error occurred in the main circuit in the SERVOPACK.	Measure the DC bus power supply voltage.	The SERVOPACK may be faulty. Replace the SERVOPACK.
	The DC bus voltage is unstable, or an error occurred in the main circuit in the power regeneration converter.	Measure the DC bus power supply voltage.	The power regeneration converter may be faulty. Replace the power regeneration converter.
	An error occurred in the AC/DC voltage detection circuit in the power regeneration converter.	–	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.410: Undervoltage (The DC voltage inside the SERVOPACK is low.)	<ul style="list-style-type: none"> For 200 VAC SERVOPACKs: The power supply voltage was in the range between 125 V and 170 V. For 400 VAC SERVOPACKs: The power supply voltage was in the range between 250 V and 323 V. 	Measure the power supply voltage.	Set the power supply voltage within the specified range.
	The power supply voltage dropped during operation.	Measure the power supply voltage.	Increase the power supply capacity.
	Occurrence of instantaneous power interruption.	Measure the power supply voltage.	Improve the power supply conditions.
	SERVOPACK failure	–	The SERVOPACK may be faulty. Replace the SERVOPACK.
A.41A: Converter DC Undervoltage (The DC voltage inside the power regeneration converter is low.)	<ul style="list-style-type: none"> For 200 VAC power regeneration converter: The power supply voltage was in the range between 125 V and 170 V. For 400 VAC power regeneration converter: The power supply voltage was in the range between 250 V and 323 V. 	Measure the power supply voltage.	Set the power supply voltage within the specified range.
	The wiring of the main circuit DC bus is incorrect.	Check the wiring.	Correct the wiring of the main circuit DC bus.
	An error occurred in the main circuit of the SERVOPACK connected to the converter.	Separate the main circuit DC bus of the SERVOPACK.	Separate the SERVOPACK and then turn ON the power supply again. If an alarm does not occur, the SERVOPACK may be faulty. Replace the SERVOPACK.
	Power regeneration converter failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.41B: Converter AC Undervoltage (The AC voltage inside the power regeneration converter is low.)	<ul style="list-style-type: none"> For 200 VAC power regeneration converter: The power supply was in the range between 50 V to 125 V. For 400 VAC power regeneration converter: The power supply was in the range between 100 V to 250 V. 	Measure the power supply voltage.	Set AC power supply voltage within the specified range.
	Power regeneration converter failure	—	If an alarm occurs after turning the correct power ON, the power regeneration converter may be faulty. Replace the power regeneration converter.
A.41C: Power Failure While Motor Running (The AC power supply was cut off while the motor was running.)	A power failure occurred.	—	Turn the power supply OFF and then ON again.
	The AC power supply was disconnected by the main circuit contactor.	Check the main circuit contactor and NFB.	Turn OFF the AC power supply and then turn it ON again.
	The AC voltage is unstable during the operation. <ul style="list-style-type: none"> For 200 VAC power regeneration converter: The power supply was 50 V or less. For 400 VAC power regeneration converter: The power supply was 100 V or less. 	Measure the power supply voltage.	Set AC power supply voltage within the specified range.
	Power regeneration converter failure	—	If an alarm occurs after turning the correct power ON, the power regeneration converter may be faulty. Replace the power regeneration converter.
A.42C: Converter Initial Charging Error (Charging of the main circuit capacitor did not finish within the speci- fied period of time.)	The main circuit cable is either incorrectly wired or has a contact fault.	Make sure the wiring is correct.	Correct the wiring.
	The wiring of the main circuit DC bus is incorrect.	Check the wiring.	Correct the wiring of the main circuit DC bus.
	An error occurred in the main circuit of the SERVOPACK connected to the converter.	Separate the main circuit DC bus of the SERVOPACK.	Separate the SERVOPACK and then turn ON the power supply again. If an alarm does not occur, the SERVOPACK may be faulty. Replace the SERVOPACK.
	Converter rapid discharge circuit failure	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
	The AC-DC conversion circuit inside the power regeneration converter has failed.	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
A.450: Main Circuit Capacitor Overvoltage (The capacitor of the main circuit has deterio- rated or is faulty.)	Main circuit capacitor failure	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
	An error occurred in the main circuit detection circuit.		

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.510: Overspeed (The motor speed exceeds the maximum.)	The order of phases U, V, and W in the motor wiring is incorrect.	Check the motor wiring.	Confirm that the spindle motor is correctly wired.
	A reference value exceeding the overspeed detection level was input.	Check the input value.	Reduce the reference value or adjust the gain.
	The motor speed exceeded the maximum.	Check the motor speed waveform.	Adjust the servo gain, or reconsider the operation conditions.
	SERVOPACK failure	–	The SERVOPACK may be faulty. Replace the SERVOPACK.
A.531: Excessive Speed Deviation (The deviation between the speed reference and actual motor speed is abnormal.)	The motor main circuit cable is either incorrectly wired or has a contact fault.	Make sure the wiring is correct.	Correct the wiring.
	A short-circuit or ground fault occurred in the motor main circuit cable.	Check for short-circuits across phase U, V, and W of the cable, or between the ground and phase U, V, or W.	The cable may have short-circuited. Replace the cable.
	The load is heavy (for example, the cutting resistance may be high).	Check to see if the load friction is high and the moment of inertia of the load is too high.	Remove the load.
A.540: Overspeed (During Low-speed Winding) (The low-speed winding maximum speed was exceeded during low-speed winding.)	The sequence of phase U, V, and W motor lines is incorrect.	Check the wiring of the motor and of the electromagnetic contactor for winding selection.	Correct the spindle motor wiring.
	The reference input value exceeds the maximum speed of the low-speed winding.	Check the input reference.	Reduce the reference value, or adjust the gain.
	The low-speed winding maximum rotation speed was exceeded during low-speed winding.	Check the motor speed from the motor speed monitor in SigmaWin+.	Adjust the gain, or revise the operating conditions.
	SERVOPACK failure	–	The SERVOPACK may be faulty. Replace the SERVOPACK.
A.682: Tuneup Not Completed Error	An orientation operation was performed when the tuneup operation had not been completed.	Check the setting of Pn81C.	Set Pn81C.3 to 1 after completion of the tuneup operation.
	The tuneup operation was performed when the tuneup operation had already been completed.	Check the setting of Pn81C.	Set Pn81C.3 to 0 before you perform the tuneup operation.
A.683: Phase-C Signal Detection Error	Malfunction caused by noise.	Improve the noise environment, including the wiring and installation, and check to see if the alarm occurs again.	Check the ground on the spindle motor and servo amplifier. Make sure that the encoder cable is separated from the main circuit cable.
	Incorrect wiring or disconnected wiring	Check the wiring of the encoder.	Check the encoder wiring for any problems.
	Encoder failure	–	Replace the external encoder or the spindle motor.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.684: Pulse Per Revolution Error	The error in the pulses per revolution exceeded ± 1 pulse during the tuneup operation for orientation control with an external encoder.	Check the gear ratio settings.	Check the gear ratio settings (Pn83C, Pn83D, and Pn83E).
	The error in the pulses per revolution of the main shaft exceeded $\pm 6\%$ during the tuneup operation for magnetic orientation.	Check the gear ratio settings.	Check the gear ratio settings (Pn83C, Pn83D, and Pn83E).
	Incorrect wiring	Check the wiring.	Correct the wiring.
	Malfunction caused by noise.	Improve the noise environment, including the wiring and installation, and check to see if the alarm occurs again.	Correct the ground. Make sure that the encoder cable is separated from the main circuit cable.
	Failure	—	Replace the magnetic sensor or magnet. Or, replace the encoder.
A.685: Phase-C Signal Width Error	Incorrect wiring	Check the wiring of the encoder cable.	Correct the wiring of the encoder cable.
	Malfunction caused by noise.	Improve the noise environment, including the wiring and installation, and check to see if the alarm occurs again.	Check the ground on the servo amplifier. Make sure that the encoder cable is separated from the main circuit cable.
	Encoder failure	—	Replace the external encoder or the spindle motor.
A.686: Magnetic Sensor Signal Detection Error	The magnetic sensor and magnet are not mounted in the correct positions.	Check the positions of the magnetic sensor and magnet.	Correctly mount the magnetic sensor and magnet.
	The magnetic sensor signal standardization angle (Pn80F) is not set correctly.	Check the setting of the magnetic sensor signal standardization angle (Pn80F).	Set a suitable value for the magnetic sensor signal standardization angle (Pn80F).
	The magnetic sensor or magnet has failed.	—	Replace the magnetic sensor or magnet.
	Incorrect wiring or disconnected wiring	Check the wiring.	Correct the wiring of the magnetic sensor signal.
A.687: Magnetic Sensor Signal Disconnection Error	Incorrect wiring or disconnected wiring	Check the wiring.	Correct the wiring of the magnetic sensor signal.
	A gear ratio setting was changed.	Check the gear ratio settings.	Set a correct gear ratio.
	The magnetic sensor or magnet has failed.	—	Replace the magnetic sensor or magnet and perform the tuneup operation again.
	The orientation speed is too slow.	Check the setting of Pn812.	Set the correct target speed.
	The tuneup was insufficient.	—	Set the magnetic sensor signal standardization angle (Pn80F) and gear ratios (Pn83C, Pn83D, and Pn83E) correctly, and then perform the tuneup.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.690: Winding Selection Operation Fault	During the winding selection check that is performed when the power is turned ON, the electromagnetic contactor for winding selection did not change according to the internal command.	Check the wiring of the SERVOPACK and of the electromagnetic contactor for winding selection.	Correct the wiring of the winding selection signal.
	Winding selection was not completed within two seconds of receiving the winding selection command.	Check the wiring of the electromagnetic contactor for winding selection.	Correct the wiring of the electromagnetic contactor for winding selection.
	Chattering occurred in the electromagnetic contactor for winding selection when the winding selection command was not received.	Check the wiring of the electromagnetic contactor for winding selection.	Correct the wiring of the electromagnetic contactor for winding selection, or replace the electromagnetic contactor for winding selection.
A.710: A.720: Overload A.710: High Load A.720: Low Load	Incorrect wiring or contact fault of motor and encoder.	Check the wiring.	Confirm that the motor and encoder are correctly wired.
	Operation beyond the overload protection characteristics.	Check the motor overload characteristics and command.	Reconsider the load conditions and operation conditions. Or, increase the spindle motor capacity.
	Excessive load was applied during operation because the motor was not driven due to mechanical problems.	Check the command and motor speed.	Remove the mechanical problems.
	SERVOPACK failure	–	The SERVOPACK may be faulty. Replace the SERVOPACK.
A.72A: Converter Electric Operation Overload (A continuous operation drew power at a rate that exceeded the rated output of the power regeneration converter.)	The sequence of phase U, V, and W motor lines is incorrect.	Check the wiring of the motor's main circuit cable.	Correct the motor wiring.
	The motor main circuit cable is either incorrectly wired or has a contact fault.	Make sure the wiring is correct.	Correct the wiring.
	A mistake occurred when selecting the power regeneration converter capacity.	Check the power regeneration converter capacity and the total output capacity of the SERVOPACK.	Change the power regeneration converter capacity.
	Converter current detection circuit failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
	The AC power supply voltage is low.	Measure the power supply voltage.	Set AC power supply voltage within the specified range.
A.72B: Converter Power Supply Regenerative Overload (Continuous power regeneration exceeded the ratings of the power regeneration converter.)	A mistake occurred when selecting the power regeneration converter capacity.	Check the power regeneration converter capacity and the total output capacity of the SERVOPACK.	Change the power regeneration converter capacity.
	The AC power supply voltage is low.	Measure the power supply voltage.	Set AC power supply voltage within the specified range.
	Power regeneration converter failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.74A: Converter Inrush Resistance Overload (The main circuit power supply turned ON and OFF frequently.)	The main circuit power supply turned ON and OFF frequently.	Check the ON/OFF sequence of the main circuit power supply.	Change the sequence and operation pattern such that the main circuit power supply does not turn ON and OFF frequently.
	Inrush limit circuit failure	—	Turn the power supply OFF and then ON again after cooling the power regeneration converter to the surrounding air temperature. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
A.790: Motor Overheated (The motor temperature has exceeded the upper limit.)	The surrounding air temperature around the motor is high.	Check the surrounding air temperature around the motor.	Make sure the surrounding air temperature around the motor does not increase.
	Acceleration and deceleration were repeated frequently.	—	Make the acceleration/deceleration of the motor smoother, or change the operation pattern.
A.791: Motor Temperature Detection Error (The motor thermistor is either disconnected or is damaged.)	The cable between the SERVOPACK and spindle motor is either disconnected or has a contact fault.	Make sure the wiring is not disconnected and no contact fault exists.	Correct the wiring.
	The thermistor wiring in the spindle motor is disconnected.	—	The spindle motor may be faulty. Replace the spindle motor.
	The thermistor has failed.	—	The spindle motor may be faulty. Replace the spindle motor.
A.7A0: Heat Sink in SERVOPACK Overheated (The temperature of the heat sink in the SERVOPACK exceeded 100°C, or the thermistor in the SERVOPACK was disconnected or damaged.)	The surrounding air temperature is too high.	Check the surrounding air temperature using a thermometer.	Improve the installation conditions of the SERVOPACK and reduce the surrounding air temperature.
	The overload alarm has been reset by turning OFF the power too many times.	Check the alarm history to see if the overload alarm of the SERVOPACK was reported.	Change the method for resetting the alarm.
	The installation orientation of the SERVOPACK is incorrect or the distance from other equipment is insufficient.	Check the installation conditions of the SERVOPACK.	Install the SERVOPACK correctly as specified.
	SERVOPACK failure	—	The SERVOPACK may be faulty. Replace the SERVOPACK.
A.7AB: Built-in Fan in SERVOPACK Stopped	The fan inside the SERVOPACK stopped.	Check for foreign matter or debris inside the SERVOPACK.	Remove foreign matter. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.7AC: Built-in Fan in Converter Stopped (The fan inside the power regeneration converter stopped.)	The fan inside the power regeneration converter stopped.	Check for foreign matter or debris inside the power regeneration converter.	Remove the foreign matter. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.7BA: Converter Heat Sink Overheated (The temperature of the heat sink inside the power regeneration converter exceeded 100°C, or the thermistor in the converter was disconnected or damaged.)	The surrounding air temperature is high.	Check the surrounding air temperature using a thermometer.	Improve the installation conditions of the power regeneration converter and reduce the surrounding air temperature.
	The overload alarm has been reset by turning OFF the power too many times.	—	Remove the cause of the overload alarm.
	Either the load is in excess or operation is performed beyond the power regeneration processing capacity.	—	Review the load and operation conditions.
	The installation orientation of the power regeneration converter is incorrect or the distance from other equipment is insufficient.	Check the installation conditions of the power regeneration converter.	Install the power regeneration converter correctly as specified.
	Power regeneration converter failure	—	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.98A: INC Signal Error	The INC signal was input at the wrong time.	Check the INC signal.	Perform incremental orientation after you have completed absolute orientation.
A.B11: Speed Reference A/D Data Error (A malfunction occurred in the speed reference A/D data detection section.)	A malfunction occurred in the speed reference input section.	—	Reset the alarm and restart operation.
	SERVOPACK failure	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.B31: Current Detection Error 1 (Phase-U)	The current detection circuit for phase U is faulty.	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.B32: Current Detection Error 2 (Phase-V)	The current detection circuit for phase V is faulty.	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.B33: Current Detection Error 3 (Current detector)	The detection circuit for the current is faulty.	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
	The motor main circuit cable is disconnected.	Check for disconnection of the motor main circuit cable.	Correct the motor wiring.
A.B4A: Converter Gate Drive Output Error	The gate drive signal output circuit of power transistor of the power regeneration converter has failed.	—	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.BDA: Converter CPU: AD Conversion Circuit Error (An error occurred in the A/D conversion circuit inside the power regeneration converter.)	Power regeneration converter failure	—	The power regeneration converter may be faulty. Replace the power regeneration converter.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.BDB: Converter Reference Voltage Error 1 (An error occurred in the reference voltage output in the power regeneration converter.)	Power regeneration converter failure	–	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.BDC: Converter Reference Voltage Error 2 (An error occurred in the reference voltage output inside the power regeneration converter.)	Power regeneration converter failure	–	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.BDD: Converter System Error 0	Power regeneration converter failure	–	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.BEA: Converter System Error 1	Power regeneration converter failure	–	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.BEB: Converter System Error 2	Power regeneration converter failure	–	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.BF0: System Alarm 0	SERVOPACK failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.BF1: System Alarm 1	SERVOPACK failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.BF2: System Alarm 2	SERVOPACK failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.BF3: System Alarm 3	SERVOPACK failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.BF4: System Alarm 4	SERVOPACK failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.C10: Servo Overrun Detected (Detected when the motor power is ON.)	The order of phases U, V, and W in the motor wiring is incorrect.	Check the motor wiring.	Confirm that the spindle motor is correctly wired.
	Encoder failure	–	If the alarm still occurs after turning the power OFF and then ON again, even though the spindle motor is correctly wired, the spindle motor may be faulty. Replace the spindle motor.
	SERVOPACK failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.C2A: Pulse Encoder Phase C Error/Pulse Error	An error occurred in the feedback pulse count of the pulse encoder.	Check the signal wiring of the pulse encoder.	Correct the wiring of the pulse encoder.
	Malfunction caused by noise.	Improve the noise environment, including the wiring and installation, and check to see if the alarm occurs again.	Install the pulse encoder cable away from the peripheral equipment, or add a ferrite core.
A.C3A: Pulse Encoder Phase A Disconnection	The signal line for phase A of the pulse encoder is disconnected.	Check the signal wiring of the pulse encoder.	Correct the wiring of the pulse encoder.
A.C3B: Pulse Encoder Phase B Disconnection	The signal line for phase B of the pulse encoder is disconnected.	Check the signal wiring of the pulse encoder.	Correct the wiring of the pulse encoder.
A.C3C: Pulse Encoder Phase C Disconnection	The signal line for phase C of the pulse encoder is disconnected.	Check the signal wiring of the pulse encoder.	Correct the wiring of the pulse encoder.
A.C3D: External Encoder Phase A Disconnection	The signal line for phase A of the load pulse encoder is disconnected.	Check the signal wiring of the load pulse encoder.	Correct the wiring of the load pulse encoder.
A.C3E: External Encoder Phase B Disconnection	The signal line for phase B of the load pulse encoder is disconnected.	Check the signal wiring of the load pulse encoder.	Correct the wiring of the load pulse encoder.
A.C3E: External Encoder Phase C Disconnection	The signal line for phase C of the load pulse encoder is disconnected.	Check the signal wiring of the load pulse encoder.	Correct the wiring of the load pulse encoder.
A.C50: Phase C Not Detected	The phase C signal of the pulse encoder is not wired correctly.	Check the signal wiring of the pulse encoder.	Correct the wiring of the pulse encoder.
	Pulse encoder error	Check the phase C signal of the pulse encoder.	The pulse encoder may have failed. Replace the motor.
A.D00: Position Error Pulse Overflow (Position error exceeded the value set in the excessive position error alarm level (Pn520))	The contact in the motor U, V, and W wirings is faulty.	Check the motor main circuit cable connection.	Confirm that there is no contact fault in the motor wiring of encoder wiring.
	The set value of the Orientation Acceleration Constant (Pn813) or the Orientation Deceleration Constant (Pn815) is too large.	—	Set suitable values for the Pn813 and Pn815 parameters.
	Setting of the Pn520 (Excessive Position Error Alarm Level) is low against the operating condition.	Check the alarm level (Pn520) to see if it is set to an appropriate value.	Set the Pn520 to proper value.
	SERVOPACK failure	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.D01: Position Error Pulse Overflow Alarm at Servo ON	The SV_ON command is received when the number of position error pulses is greater than the set value of Pn526 while the motor power is OFF.	Check the error counter monitor in SigmaWin+ while the motor power is OFF.	Correct the excessive position error alarm level at servo ON (Pn526).

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.D02: Position Error Pulse Overflow Alarm by Speed Limit at Servo ON	After a position error pulse has been input, Pn529 limits the speed if the SV_ON command is received. If Pn529 limits the speed in such a state, this alarm occurs when the position references are input and the number of position error pulses exceeds the value set for parameter Pn520 (Excessive Position Error Alarm Level).	–	Correct the excessive position error alarm level (Pn520). Or, adjust the speed limit level at servo turns ON (Pn529).
A.E02: System Alarm 6	SERVOPACK failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.EA0: SERVOPACK Failure (DRV alarm 0) (SERVOPACK alarm 0 occurred.)	SERVOPACK failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.EA1: SERVOPACK Initial Access Error (The SERVOPACK initial access alarm occurred.)	SERVOPACK failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.EA2: DRV Alarm 2 (SERVOPACK WDC error)	SERVOPACK failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.EB1: HWBB Function Signal Input Timing Error	The lag between activations of the input signals /HWBB1 and /HWBB2 for the HWBB function is 10 second or more.	Measure the time lag between the /HWBB1 and /HWBB2 signals.	The output signal circuits or devices for /HWBB1 and /HWBB2 or the SERVOPACK input signal circuits may be faulty. Alternatively, the input signal cables may be disconnected. Repair or replace them.
A.ED2: DAS Signal Setting Conflict	The DAS signal conflicts with the 12-bit digital reference signal selection.	Check the DAS signal status and the setting of Pn850.0.	Consider the DAS signal status and the setting of Pn850.0 and set them so that the digital speed reference and the inputs for the orientation stop position reference do not overlap.
A.EEA: Converter Local Bus WD Error (A power regeneration converter local bus WD alarm occurred.)	The local bus cable of the power regeneration converter is either disconnected or a has a contact fault.	Check the local bus cable.	Either re-install the local bus cable or replace it.
	Malfunction caused by noise	Improve the noise environment, including the wiring and installation, and check to see if the alarm occurs again.	Install the local bus cable away from the peripheral equipment, or replace it with a cable that has a ferrite core.
	The local bus circuit inside the power regeneration converter has failed.	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.EEB: Converter Local Bus Communications Error (A communications error occurred in the power regeneration converter local bus.)	The local bus cable of the power regeneration converter is either disconnected or has a contact fault.	Check the local bus cable.	Either re-install the local bus cable or replace it.
	Malfunction caused by noise	Improve the noise environment, including the wiring and installation, and check to see if the alarm occurs again.	Install the local bus cable away from the peripheral equipment, or replace it with a cable that has a ferrite core.
	The terminator circuit inside the power regeneration converter has failed.	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
A.EF0: Local Bus Connection Error (An error occurred in the local bus connection.)	The local bus cable is either disconnected or has a contact fault.	Check the local bus cable.	Either re-install the local bus cable or replace it.
	Malfunction caused by noise	Improve the noise environment, including the wiring and installation, and check to see if the alarm occurs again.	Install the local bus cable away from the peripheral equipment, or replace it with a cable that has a ferrite core.
	Local bus circuit failure	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
A.EF2: Local Bus Drive WD Error (A local bus watchdog alarm occurred in the SERVOPACK.)	Malfunction caused by noise	Improve the noise environment, including the wiring and installation, and check to see if the alarm occurs again.	Install the local bus cable away from the peripheral equipment, or replace it with a cable that has a ferrite core.
	Local bus circuit failure	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
A.EF4: Local Bus Communications Error (An error occurred during the local bus communications.)	An error occurred during local bus communications.	Check the insertion of connector of the local bus cable and the cable wiring.	The local bus cable may be faulty. Replace the local bus cable.
			The SERVOPACK may be faulty. Replace the SERVOPACK.
A.F1A: Converter AC Power Supply Open Phase (The voltage was low for one second on phase L1, L2, or L3 when the main power supply was turned ON.)	The three-phase power supply wiring is faulty.	Check the power supply wiring.	Make sure the power supply wiring is correct.
	The three-phase power supply is unbalanced.	Measure the voltage for each phase of the three-phase power supply.	Balance the power supply by changing phases.
	Power regeneration converter failure	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.

(cont'd)

Alarm: Alarm Name	Cause	Investigative Actions	Corrective Actions
A.F2A: Converter AC Power Supply Frequency Error (The deviation in the power supply frequency is large.)	The three-phase power supply wiring is faulty.	Check the power supply wiring.	Make sure the power supply wiring is correct.
	The three-phase power supply is unbalanced.	Measure the voltage for each phase of the three-phase power supply.	Balance the power supply by chang- ing phases.
	An error occurred in the fre- quency of the three-phase power supply.	Measure the frequency of the three- phase power supply.	Make sure the power supply wiring is correct.
	Power regeneration converter failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration con- verter may be faulty. Replace the power regeneration converter.
A.F2B: Converter AC Power Supply Frequency Detection Time Exceeded (The detection of the AC power supply input fre- quency was not com- pleted within the set time.)	The three-phase power supply wiring is faulty.	Check the power supply wiring.	Make sure the power supply wiring is correct.
	The three-phase power supply is unbalanced.	Measure the voltage for each phase of the three-phase power supply.	Balance the power supply by chang- ing phases.
	An error occurred in the fre- quency of the three-phase power supply.	Measure the frequency of the three- phase power supply.	Make sure the power supply wiring is correct.
	Power regeneration converter failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration con- verter may be faulty. Replace the power regeneration converter.
A.F3B: Converter AC Power Supply Phase Sequence Error (An error occurred in the AC power supply phase sequence.)	The three-phase power supply wiring is faulty.	Check the power supply wiring.	Make sure the power supply wiring is correct.
	The phases of the three-phase power supply was different before and after an instantaneous power interruption.	–	Modify the power supply so that the phases remain fixed.
	Power regeneration converter failure	–	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration con- verter may be faulty. Replace the power regeneration converter.

15.3 Warning Displays

The following sections describe troubleshooting in response to warning displays.

The warning names, warning meanings, and reset possibilities are listed in order of the warning numbers in *15.3.1 List of Warnings*.

Remove the cause of the warning before you reset the warning.

The causes of warnings and troubleshooting methods are provided in *15.3.2 Troubleshooting of Warnings*.

15.3.1 List of Warnings

This section provides list of warnings.

Warning Number	Warning Name	Meaning	Reset	Alarm Code Output			
				FC3	FC2	FC1	FC0
A.900	Position Error Overflow	Position error exceeded the parameter setting (Pn520×Pn51E/100).	Available				
A.901	Position Error Overflow Alarm at Servo ON	When the motor power turns ON, the position error exceeded the parameter setting (Pn526×Pn528/100).	Available				
A.910	Overload	This warning occurs before the overload alarms (A.710 or A.720) occur. If the warning is ignored and operation continues, an overload alarm may occur.	Available				
A.91A	Converter Electric Operation Overload	This warning occurs before the converter electric operation overload alarm (A.72A) occurs. If the warning is ignored and operation continues, a converter electric operation overload alarm may occur.	Available				
A.91B	Converter Power Supply Regenerative Overload	This warning occurs before the converter power supply regenerative overload alarm (A.72B) occurs. If the warning is ignored and operation continues, a converter power supply regenerative overload alarm may occur.	Available				
A.923*	Built-in Fan in SERVOPACK Stopped	The fan inside the SERVOPACK stopped.	N/A	H	L	L	H
A.92B	Built-in Fan in Converter Stopped	The fan inside the power regeneration converter stopped.	N/A				
A.941	Parameter Needing Power Restart After Change	A parameter that requires restarting the power of the SERVOPACK to update was changed.	N/A				
A.971	Undervoltage	This warning occurs before undervoltage alarm (A.410) occurs. If the warning is ignored and operation continues, an undervoltage alarm may occur.	Available				
A.97D	Converter Heat Sink Overheated	This warning occurs before the converter heat sink overheated alarm (A.7BA) occurs. If the warning is ignored and operation continues, a converter heat sink overheated alarm may occur.	Available				
A.980	Motor Overheated	This warning occurs before the motor overheated alarm (A.790) occurs. If the warning is ignored and operation continues, a motor overheated alarm may occur.	Available				

* This warning will occur only when PN00D.2 is set to 1 in the SERVOPACK.

Note: If Pn008.2 = 1 (does not detect warning) is selected, any warnings from the SERVOPACK will be ignored.

15.3.2 Troubleshooting of Warnings

Refer to the following table to identify the cause of a warning and the action to be taken. Contact your Yaskawa representative if the problem cannot be solved by the described corrective action.

Warning No.: Warning Name (Warning Description)	Cause	Investigative Actions	Corrective Actions
A.900: Position Error Overflow	The motor U, V, and W wirings is faulty.	Check the motor main circuit cable connection.	Confirm that there is no contact fault in the motor wiring or encoder wiring.
	The SERVOPACK gain is too low.	Check the SERVOPACK gain.	Increase the servo gain.
	The position reference acceleration is too fast.	Reduce the reference acceleration, and operate the SERVOPACK.	Reduce the reference acceleration.
	Setting of the excessive position error alarm level (Pn520) is low against the operating condition.	Check the alarm level (Pn520) to see if it is set to an appropriate value.	Set the Pn520 to proper value.
	SERVOPACK failure	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.901: Position Error Overflow Alarm at Servo ON	When the spindle motor power turns ON, the position error exceeded the parameter setting (Pn526 × Pn528/100).	—	Correct the excessive position error warning level at servo ON (Pn528).
A.910: Overload (Warning before alarm A.710 or A.720 occurs)	Incorrect wiring or contact fault of spindle motor and encoder.	Check the wiring.	Confirm that the spindle motor and encoder are correctly wired.
	Operation beyond the overload protection characteristics.	Check the spindle motor overload characteristics and executed run command.	Reconsider the load conditions and operating conditions. Or, increase the motor capacity.
	Excessive load was applied during operation because the spindle motor was not driven due to mechanical problems.	Check the executed operation reference and motor speed.	Remove the mechanical problems.
	SERVOPACK failure	—	The SERVOPACK may be faulty. Replace the SERVOPACK.

(cont'd)

Warning No.: Warning Name (Warning Description)	Cause	Investigative Actions	Corrective Actions
A.91A: Converter Electric Operation Overload	The sequence of phase U, V, and W motor lines is incorrect.	Check the wiring of the motor's main circuit cable.	Correct the motor wiring.
	The motor main circuit cable is either incorrectly wired or has a contact fault.	Make sure the wiring is correct.	Correct the wiring.
	A mistake occurred when selecting the power regeneration converter capacity.	Check the power regeneration converter capacity and the total output capacity of the SERVOPACK.	Change the power regeneration converter capacity.
	Converter current detection circuit failure	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
	The AC power supply voltage is low.	Measure the power supply voltage.	Set AC power supply voltage within the specified range.
A.91B: Converter Power Supply Regenerative Overload	A mistake occurred when selecting the power regeneration converter capacity.	Check the power regeneration converter capacity and the total output capacity of the SERVOPACK.	Change the power regeneration converter capacity.
	The AC power supply voltage is low.	Measure the power supply voltage.	Set AC power supply voltage within the specified range.
	Power regeneration converter failure	—	Turn the power supply OFF and then ON again. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
A.923: Built-in Fan in SERVOPACK Stopped	The fan inside the SERVOPACK stopped.	Check for foreign matter or debris inside the SERVOPACK.	Remove foreign matter. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.
A.92B: Built-in Fan in Converter Stopped	The fan inside the power regeneration converter stopped.	Check for foreign matter or debris inside the power regeneration converter.	Remove the foreign matter. If the alarm still occurs, the power regeneration converter may be faulty. Replace the power regeneration converter.
A.941: Parameter Needing Power Restart After Change	A parameter that requires restarting the power of the SERVOPACK to update was changed.	—	Restart the power supply.

(cont'd)

Warning No.: Warning Name (Warning Description)	Cause	Investigative Actions	Corrective Actions
A.971: Undervoltage	<ul style="list-style-type: none"> For 200-VAC SERVOPACKs: The AC power supply voltage was in the range between 125 V and 170 V. For 400-VAC SERVOPACKs: The AC power supply voltage was in the range between 250 V and 323 V. 	Measure the power supply voltage.	Set the power supply voltage within the specified range.
	The power supply voltage dropped during operation.	Measure the power supply voltage.	Increase the power supply capacity.
	Occurrence of instantaneous power interruption.	Measure the power supply voltage.	Improve the power supply conditions.
	SERVOPACK failure	—	The SERVOPACK may be faulty. Replace the SERVOPACK.
A.97D: Converter Heat Sink Overheated	The surrounding air temperature is high.	Check the surrounding air temperature using a thermometer.	Improve the installation conditions of the power regeneration converter and reduce the surrounding air temperature.
	The overload alarm has been reset by turning OFF the power too many times.	—	Remove the cause of the overload alarm.
	Either the load is in excess or operation is performed beyond the power regeneration processing capacity.	—	Review the load and operation conditions.
	The installation orientation of the power regeneration converter is incorrect or the distance from other equipment is insufficient.	Check the installation conditions of the power regeneration converter.	Install the power regeneration converter correctly as specified.
	Power regeneration converter failure	—	The power regeneration converter may be faulty. Replace the power regeneration converter.
A.980: Motor Overheated	The surrounding air temperature around the motor is high.	Check the surrounding air temperature around the motor.	Make sure the surrounding air temperature around the motor does not increase.
	Acceleration and deceleration were repeated frequently.	—	Make the acceleration/deceleration of the motor smoother, or change the operation pattern.

15.4 Troubleshooting Malfunction Based on Operation and Conditions of the Spindle Motor

Troubleshooting for the malfunctions based on the operation and conditions of the spindle motor is provided in this section.

Be sure to turn OFF the servo system before troubleshooting items shown in bold lines in the table.

Problem	Probable Cause	Investigative Actions	Corrective Actions
Motor Does Not Start	The control power supply is not ON.	Check voltage between control power terminals.	Correct the wiring.
	The main circuit power supply is not ON.	Check the voltage between main circuit power terminals.	Correct the wiring.
	Wiring of I/O signal connector CN1 faulty or disconnected.	Check if the connector CN1 is properly inserted and connected.	Correct the connector CN1 connection.
	Motor or encoder wiring disconnected.	Check the wiring.	Correct the wiring.
	Overloaded	Run under no load and check the load status.	Reduce load or replace with larger capacity motor.
	Motor type differs from parameter setting (Pn01E.0).	Check the settings for parameter Pn01E.0.	Set parameter Pn01E.0 to the motor type being used.
	The safety input signal (/HWBB1 or /HWBB2) remains OFF.	Check the /HWBB1 and /HWBB2 input signal.	Set the /HWBB1 and /HWBB2 input signal to ON.
	SERVOPACK failure	–	Replace the SERVOPACK.
Motor Moves Instantaneously, and then Stops	Motor wiring is incorrect.	Check the motor wiring.	Correct the wiring.
	Encoder wiring is incorrect.	Check the encoder wiring.	Correct the wiring.
Motor Speed Unstable	Wiring connection to motor is defective.	Check connections of power line (phases U, V, and W) and encoder connectors.	Tighten any loose terminals or connectors and correct the wiring.
Motor Rotates Without Reference Input	SERVOPACK failure	–	Replace the SERVOPACK.

(cont'd)

Problem	Probable Cause	Investigative Actions	Corrective Actions
Abnormal Noise from Motor	Mounting is not secured.	Check if there are any loose mounting screws.	Tighten the mounting screws.
		Check if there is misalignment of couplings.	Align the couplings.
		Check if there are unbalanced couplings.	Balance the couplings.
	Bearings are defective.	Check for noise and vibration around the bearings.	Replace the motor.
	Vibration source at the driven machine	Check for any foreign matter, damage, or deformations on the machinery's movable parts.	Contact the machine manufacturer.
	Noise interference due to incorrect I/O signal cable specifications	The I/O signal cable must be tinned annealed copper shielded twisted-pair or screened unshielded twisted-pair cable with a core of 0.12 mm ² minimum.	Use the specified I/O signal cable.
	Noise interference due to length of I/O signal cable	Check the length of the I/O signal cable.	The I/O signal cable length must be no more than 3 m.
	Noise interference due to incorrect encoder cable specifications	The encoder cable must be tinned annealed copper shielded twisted-pair or screened unshielded twisted-pair cable with a core of 0.12 mm ² minimum.	Use the specified encoder cable.
	Noise interference due to length of encoder cable	Check the length of the encoder cable.	The length of the encoder cable must be no more than 20 m.
	Noise interference due to damaged encoder cable	Check if the encoder cable is bent and the sheath is damaged.	Replace the encoder cable and modify the encoder cable layout.
	Excessive noise to the encoder cable	Check if the encoder cable is bundled with a high-current line or near a high-current line.	Correct the encoder cable layout so that no surge is applied.
	The FG potential varies because of influence from machines on the motor side, such as the welder.	Check if the machines are correctly grounded.	Properly ground the machines to separate from the encoder FG.
	SERVOPACK pulse counting error due to noise interference	Check if there is noise interference on the I/O signal line from the encoder.	Take measures against noise in the encoder wiring.
	Excessive vibration and shock to the encoder	Check if vibration from the machine occurred or motor installation is incorrect (mounting surface accuracy, fixing, alignment, etc.).	Reduce vibration from the machine, or secure the motor installation.
Encoder failure	–	Replace the motor.	
Motor Vibrates at Frequency of Approx. 200 to 400 Hz.	Unbalanced servo gains	Check to see if the servo gains have been correctly adjusted.	Adjust servo gains.
	Speed loop gain value (Pn100) too high	Check the speed loop gain (Pn100). Factory setting: Kv = 40.0 Hz	Reduce the speed loop gain (Pn100).
	Incorrect speed loop integral time constant (Pn101)	Check the speed loop integral time constant (Pn101). Factory setting: Ti = 20.0 ms	Correct the speed loop integral time constant (Pn101).
	Incorrect moment of inertia ratio (Pn103)	Check the moment of inertia ratio (Pn103).	Correct the moment of inertia ratio (Pn103).

(cont'd)

Problem	Probable Cause	Investigative Actions	Corrective Actions
Position Error (Without Alarm)	Noise interference due to incorrect encoder cable specifications	The encoder cable must be tinned annealed copper shielded twisted-pair or screened unshielded twisted-pair cable with a core of 0.12 mm ² minimum.	Use the specified encoder cable.
	Noise interference due to length of encoder cable	Check the length of the encoder cable.	The encoder cable must be no more than 20 m.
	Noise influence due to damaged encoder cable	Check if the encoder cable is bent and its sheath is damaged.	Replace the encoder cable and modify the encoder cable layout.
	Excessive noise to encoder cable	Check if the encoder cable is bundled with a high-current line or near a high-current line.	Change the encoder cable layout so that no surge is applied.
	The FG potential varies because of influence from machines on the motor side such as the welder.	Check if the machines are correctly grounded.	Properly ground the machines encoder FG.
	SERVOPACK pulse count error due to noise	Check if the I/O signal line from the encoder is influenced by noise.	Take measures against noise in the encoder wiring.
	Excessive vibration and shock to the encoder	Check if vibration from the machine occurred or motor installation is incorrect (mounting surface accuracy, fixing, alignment, etc.).	Reduce the machine vibration or mount the motor securely.
	Unsecured coupling between machine and motor	Check if a position error occurs at the coupling between machine and motor.	Secure the coupling between the machine and motor.
	Noise interference due to improper I/O signal cable specifications	The I/O signal cable must be tinned annealed copper shielded twisted-pair or screened unshielded twisted-pair cable with a core of 0.12 mm ² minimum.	Use input signal cable with the specified specifications.
	Noise interference due to length of I/O signal cable	Check the I/O signal cable length.	The I/O signal cable length must be no more than 3 m.
	Encoder failure (The pulse count does not change.)	–	Replace the motor.
	SERVOPACK failure	–	Replace the SERVOPACK.
Motor Overheated	Surrounding air operating temperature too high	Measure the motor surrounding air temperature.	Reduce the surrounding air operating temperature to 40°C or less.
	Motor surface dirty	Visually check the surface.	Clean dust and oil from the surface.
	Motor overloaded	Check the load status with monitor.	If overloaded, reduce load or replace with larger capacity SERVOPACK and motor.

16

Appendix

16.1 Operation Modes and Applicable Parameters	16-2
16.2 List of Parameters	16-3
16.3 Parameter Recording Table	16-18
16.4 Determining Drive Capacity	16-23
16.4.1 Load Drive Capacity	16-23
16.4.2 Acceleration/deceleration Capacity	16-27
16.4.3 Calculating Start and Stop Times	16-29
16.4.4 Intermittent Load Operating Capacity	16-30

16.1 Operation Modes and Applicable Parameters

The gain parameters are changed for each operation mode.

The signals that are used to select operations and the parameters that are applied are given in the following table.

Winding Selection Motor (Winding Selection Signal (CHW))	Operation Mode	Orientation Signal (/ORT)	Servo Mode Signal (/SV)	M Gear Selection Signal (/MGR)	L Gear Selection Signal (/LGR)	Applied Parameters					Transmission Gear Ratio
						Speed Loop Gain	Speed Loop Integral Time Constant	Position Loop Gain	Torque Reference Filter Time Constant	Base Speed Ratio	
High-speed winding selected. ^{*1} (/CHW signal: OFF)	Standard Mode	OFF	OFF	OFF	OFF	Pn100	Pn101	Pn102	Pn401	*4	Pn83C
				ON	–	Pn104	Pn105	Pn106	Pn412		Pn83D
				–	ON						Pn83E
	Servo Mode	OFF	ON	OFF	OFF	Pn12B	Pn12C	Pn12D	Pn413	Pn434	Pn83C
				ON	–	Pn12E	Pn12F	Pn130	Pn414		Pn83D
				–	ON					Pn434	Pn83E
	Orientation Mode	ON	*2	OFF	OFF	Pn830	Pn831	Pn832	Pn833	Pn434	Pn83C
				ON	–	Pn834	Pn835	Pn836	Pn837		Pn83D
				OFF	ON	Pn838	Pn839	Pn83A	Pn83B		Pn83E
Low-speed winding selected. (/CHW signal: ON)	Standard Mode	OFF	OFF	*3	*3	Pn104	Pn105	Pn106	Pn412	*5	Pn83E
	Servo Mode	OFF	ON			Pn12E	Pn12F	Pn130	Pn414	Pn436	Pn83E
	Orientation Mode	ON	*2			Pn834	Pn835	Pn836	Pn837		Pn83E

*1. For a motor with only one winding, the parameters are the same as when the high-speed winding is selected on a winding selection motor. However, the gain parameters are not changed even if the /CHW signal changes.

*2. When orientation is executed, servo mode is used regardless of the setting of the /SV signal.

*3. When the low-speed winding is selected, the L gear is used regardless of the setting of the /MGR signal and the /LGR signal.

*4. The base speed of the motor is applied. (There is no parameter to set.)

*5. The base speed of the low-speed winding of the motor is applied. (There is no parameter to set.)

16.2 List of Parameters

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section		
Pn002	2	Application Function Select Switch 2	0000 to 4114	–	0014	After restart	Setup	–		
	4th digit 3rd digit 2nd digit 1st digit n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		Reserved (Do not change.)							
			Reserved (Do not change.)							
			Reserved (Do not change.)							
			Direction of Load Shaft Encoder							
			0	Uses in forward rotation with forward reference.						
			1	Uses in forward rotation with forward reference.						
			2	Reserved (Do not change.)						
			3	Uses in reverse rotation with forward reference.						
			4	Reserved (Do not change.)						
Pn006	2	Application Function Select Switch 6	0000 to 005F	–	0002	Immediately	Setup	–		
	4th digit 3rd digit 2nd digit 1st digit n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		Analog Monitor 1 Signal Selection							
			00	Motor speed (1 V / 1000 min ⁻¹)						
			01	Speed reference (1 V / 1000 min ⁻¹)						
			02	Torque reference (1 V / (Max. torque/1.2))						
			03	Position error (0.05 V/1 pulse)						
			05	Position reference speed (1 V / 1000 min ⁻¹)						
			06	Reserved (Do not change.)						
			08	Positioning completion (positioning completed: 5 V, positioning not completed: 0 V)						
			0B	Reserved (Do not change.)						
		0C	Completion of position reference (completed: 5 V, not completed: 0 V)							
		46	Load meter (6 V/100%)							
		Reserved (Do not change.)								
		Reserved (Do not change.)								

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section		
Pn007	2	Application Function Select Switch 7	0000 to 005F	–	0000	Immediately	Setup	–		
	<div style="display: flex; justify-content: space-around;"> 4th digit 3rd digit 2nd digit 1st digit </div>									
	<div style="display: flex; justify-content: space-around;"> n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div>									
			Analog Monitor 2 Signal Selection							
			00	Motor speed (1 V / 1000 min ⁻¹)						
			01	Speed reference (1 V / 1000 min ⁻¹)						
			02	Torque reference (1 V / (Max. torque/1.2))						
			03	Position error (0.05 V/1 pulse)						
			05	Position reference speed (1 V / 1000 min ⁻¹)						
			06	Reserved (Do not change.)						
			08	Positioning completion (positioning completed: 5 V, positioning not completed: 0 V)						
			0B	Reserved (Do not change.)						
			0C	Completion of position reference (completed: 5 V not completed: 0 V)						
			46	Load meter (6 V/100%)						
			Reserved (Do not change.)							
		Reserved (Do not change.)								
Pn008	2	Application Function Select Switch 8	0000 to 7121	–	0000	After restart	Setup	–		
	<div style="display: flex; justify-content: space-around;"> 4th digit 3rd digit 2nd digit 1st digit </div>									
	<div style="display: flex; justify-content: space-around;"> n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div>									
			Reserved (Do not change.)							
			Function Selection for UnderVoltage							
			0	Does not detect warning for undervoltage.						
			1	Detects warning for undervoltage.						
			2	Reserved (Do not change.)						
			Warning Detection Selection							
			0	Detects warning.						
			1	Does not detect warning.						
			Reserved (Do not change.)							
	Pn00B	2	Application Function Select Switch B	0000 to 0111	–	0001	After restart	Setup	–	
		<div style="display: flex; justify-content: space-around;"> 4th digit 3rd digit 2nd digit 1st digit </div>								
		<div style="display: flex; justify-content: space-around;"> n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div>								
		Reserved (Do not change.)								
		Alarm Gr.2 Stop Method Selection								
		0	Stops the motor by setting the speed reference to "0".							
		1	Stops the motor by applying DB or by coasting.							
		Reserved (Do not change.)								
		Reserved (Do not change.)								

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section									
Pn00D	2	Application Function Select Switch D	0000 to 1101	–	0000	After restart	Setup	–									
	<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>4th digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>3rd digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>2nd digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>1st digit</p><input type="checkbox"/></div> </div>		<div style="margin-left: 20px;"> <p>n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/></p> </div>														
			Reserved (Do not change.)														
			Reserved (Do not change.)														
			Fan Stop Error Detection Selection														
			<table border="1" style="width: 100%;"> <tr> <td style="width: 50px;">0</td> <td>Issues an alarm after the fan stops.</td> </tr> <tr> <td>1</td> <td>Issues a warning for a specified time and then an alarm after the fan stops.</td> </tr> </table>							0	Issues an alarm after the fan stops.	1	Issues a warning for a specified time and then an alarm after the fan stops.				
	0	Issues an alarm after the fan stops.															
	1	Issues a warning for a specified time and then an alarm after the fan stops.															
			Reserved (Do not change.)														
			Reserved (Do not change.)														
		Reserved (Do not change.)															
		Reserved (Do not change.)															
Pn01A	2	Application Function Select Switch 1A	0000 to 0013	–	0000	After restart	Setup	–									
	<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>4th digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>3rd digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>2nd digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>1st digit</p><input type="checkbox"/></div> </div>		<div style="margin-left: 20px;"> <p>n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/></p> </div>														
			Load Shaft Encoder Type														
			<table border="1" style="width: 100%;"> <tr> <td style="width: 50px;">0</td> <td>Does not use a load shaft encoder.</td> </tr> <tr> <td>1</td> <td>Pulse encoder</td> </tr> <tr> <td>2</td> <td>Magnetic sensor</td> </tr> <tr> <td>3</td> <td>Reserved (Do not change.)</td> </tr> </table>							0	Does not use a load shaft encoder.	1	Pulse encoder	2	Magnetic sensor	3	Reserved (Do not change.)
	0	Does not use a load shaft encoder.															
	1	Pulse encoder															
	2	Magnetic sensor															
	3	Reserved (Do not change.)															
			Speed Control Type when Stopped with Orientation Control with a Magnetic Sensor														
			<table border="1" style="width: 100%;"> <tr> <td style="width: 50px;">0</td> <td>Motor encoder type</td> </tr> <tr> <td>1</td> <td>Magnetic sensor type</td> </tr> </table>							0	Motor encoder type	1	Magnetic sensor type				
0	Motor encoder type																
1	Magnetic sensor type																
		Reserved (Do not change.)															
		Reserved (Do not change.)															
		Reserved (Do not change.)															
		Reserved (Do not change.)															
Pn01B	2	Application Function Select Switch 1B	0000 to 0011	–	0000	After restart	Setup	–									
	<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>4th digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>3rd digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>2nd digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>1st digit</p><input type="checkbox"/></div> </div>		<div style="margin-left: 20px;"> <p>n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/></p> </div>														
			Emergency Stop Signal Selection														
			<table border="1" style="width: 100%;"> <tr> <td style="width: 50px;">0</td> <td>Disables the emergency stop signal.</td> </tr> <tr> <td>1</td> <td>Enables the emergency stop signal.</td> </tr> </table>							0	Disables the emergency stop signal.	1	Enables the emergency stop signal.				
	0	Disables the emergency stop signal.															
	1	Enables the emergency stop signal.															
			Reserved (Do not change.)														
			Reserved (Do not change.)														
			Reserved (Do not change.)														
			Reserved (Do not change.)														
		Reserved (Do not change.)															
		Reserved (Do not change.)															
		Reserved (Do not change.)															

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section																	
Pn01C	2	Application Function Select Switch 1C	0000 to 1003	–	0000	After restart	Setup	–																	
	<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>4th digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>3rd digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>2nd digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>1st digit</p><input type="checkbox"/></div> </div> <div style="margin-left: 20px;"> <p>n. <input type="checkbox"/></p> </div>		<table border="1" style="width: 100%;"> <tr> <th colspan="2">Load Ratio Output Level Selection</th> </tr> <tr> <td>0</td> <td>A load ratio of 120% is output for the maximum spindle motor output.</td> </tr> <tr> <td>1</td> <td>A load ratio of 100% is output for the maximum spindle motor output.</td> </tr> <tr> <td>2</td> <td>A load ratio of 100% is output for the instantaneous rated output.</td> </tr> <tr> <td>3</td> <td>A load ratio of 100% is output for the continuous rated output.</td> </tr> <tr> <td colspan="2">Reserved (Do not change.)</td> </tr> <tr> <td colspan="2">Reserved (Do not change.)</td> </tr> <tr> <td colspan="2">Reserved (Do not change.)</td> </tr> </table>							Load Ratio Output Level Selection		0	A load ratio of 120% is output for the maximum spindle motor output.	1	A load ratio of 100% is output for the maximum spindle motor output.	2	A load ratio of 100% is output for the instantaneous rated output.	3	A load ratio of 100% is output for the continuous rated output.	Reserved (Do not change.)		Reserved (Do not change.)		Reserved (Do not change.)	
	Load Ratio Output Level Selection																								
	0	A load ratio of 120% is output for the maximum spindle motor output.																							
	1	A load ratio of 100% is output for the maximum spindle motor output.																							
2	A load ratio of 100% is output for the instantaneous rated output.																								
3	A load ratio of 100% is output for the continuous rated output.																								
Reserved (Do not change.)																									
Reserved (Do not change.)																									
Reserved (Do not change.)																									
		Reserved (Do not change.)																							
		Reserved (Do not change.)																							
		Reserved (Do not change.)																							
Pn01E	2	Application Function Select Switch 1E	0000 to 0036	–	0003	After restart	Setup	–																	
	<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>4th digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>3rd digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>2nd digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>1st digit</p><input type="checkbox"/></div> </div> <div style="margin-left: 20px;"> <p>n. <input type="checkbox"/></p> </div>		<table border="1" style="width: 100%;"> <tr> <td colspan="2">Reserved (Do not change.)</td> </tr> <tr> <th colspan="2">Winding Selection</th> </tr> <tr> <td>0</td> <td>None</td> </tr> <tr> <td>1</td> <td>Mechanical winding selection</td> </tr> <tr> <td>2, 3</td> <td>Reserved (Do not change.)</td> </tr> <tr> <td colspan="2">Reserved (Do not change.)</td> </tr> <tr> <td colspan="2">Reserved (Do not change.)</td> </tr> </table>							Reserved (Do not change.)		Winding Selection		0	None	1	Mechanical winding selection	2, 3	Reserved (Do not change.)	Reserved (Do not change.)		Reserved (Do not change.)			
	Reserved (Do not change.)																								
	Winding Selection																								
	0	None																							
1	Mechanical winding selection																								
2, 3	Reserved (Do not change.)																								
Reserved (Do not change.)																									
Reserved (Do not change.)																									
		Reserved (Do not change.)																							
		Reserved (Do not change.)																							
		Reserved (Do not change.)																							
Pn01F	2	Application Function Select Switch 1F	0000 to 0002	–	0001	After restart	Setup	–																	
	<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>4th digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>3rd digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>2nd digit</p><input type="checkbox"/></div> <div style="text-align: center;"> <p>1st digit</p><input type="checkbox"/></div> </div> <div style="margin-left: 20px;"> <p>n. <input type="checkbox"/></p> </div>		<table border="1" style="width: 100%;"> <tr> <th colspan="2">Encoder Type</th> </tr> <tr> <td>0</td> <td>Reserved (Do not change.)</td> </tr> <tr> <td>1</td> <td>Pulse encoder (spindle motor)</td> </tr> <tr> <td>2</td> <td>Reserved (Do not change.)</td> </tr> <tr> <td colspan="2">Reserved (Do not change.)</td> </tr> <tr> <td colspan="2">Reserved (Do not change.)</td> </tr> <tr> <td colspan="2">Reserved (Do not change.)</td> </tr> </table>							Encoder Type		0	Reserved (Do not change.)	1	Pulse encoder (spindle motor)	2	Reserved (Do not change.)	Reserved (Do not change.)		Reserved (Do not change.)		Reserved (Do not change.)			
	Encoder Type																								
	0	Reserved (Do not change.)																							
	1	Pulse encoder (spindle motor)																							
2	Reserved (Do not change.)																								
Reserved (Do not change.)																									
Reserved (Do not change.)																									
Reserved (Do not change.)																									
		Reserved (Do not change.)																							
		Reserved (Do not change.)																							
		Reserved (Do not change.)																							
Pn030	2	Reserved (Do not change.)	–	–	0000	–	Setup	–																	

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section	
Pn031	2	Application Function Select Switch 31	0000 to 0111	–	0001	After Restart	Setup	–	
		Analog Speed Reference Input Selection							
		0	Uses Speed Reference Input Gain 1 (Pn300).						
		1	Uses Speed Reference Input Gain 2 (Pn30A).						
		Speed Limit Selection							
		0	The upper limit is 105% of the rated speed.						
		1	The upper limit is 110% of the rated speed.						
		Speed Reference Gain Selection at Servo Mode							
		0	Does not switch speed reference gain.						
	1	Switches speed reference gain.							
	Reserved (Do not change.)								
Pn100	2	Speed Loop Gain	10 to 20000	0.1 Hz	100	Immediately	Tuning	–	
Pn101	2	Speed Loop Integral Time Constant	15 to 51200	0.01 ms	3000	Immediately	Tuning	–	
Pn102	2	Position Loop Gain	10 to 20000	0.1/s	100	Immediately	Tuning	–	
Pn103	2	Moment of Inertia Ratio	0 to 20000	1%	100	Immediately	Tuning	–	
Pn104	2	2nd Speed Loop Gain	10 to 20000	0.1 Hz	100	Immediately	Tuning	–	
Pn105	2	2nd Speed Loop Integral Time Constant	15 to 51200	0.01 ms	3000	Immediately	Tuning	–	
Pn106	2	2nd Position Loop Gain	10 to 20000	0.1/s	100	Immediately	Tuning	–	
Pn12B	2	3rd Speed Loop Gain	10 to 20000	0.1 Hz	100	Immediately	Tuning	–	
Pn12C	2	3rd Speed Loop Integral Time Constant	15 to 51200	0.01 ms	3000	Immediately	Tuning	–	
Pn12D	2	3rd Position Loop Gain	10 to 20000	0.1/s	100	Immediately	Tuning	–	
Pn12E	2	4th Speed Loop Gain	10 to 20000	0.1 Hz	100	Immediately	Tuning	–	
Pn12F	2	4th Speed Loop Integral Time Constant	15 to 51200	0.01 ms	3000	Immediately	Tuning	–	
Pn130	2	4th Position Loop Gain	10 to 20000	0.1/s	100	Immediately	Tuning	–	

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section																										
Pn160	2	Anti-Resonance Control Related Switch	0000 to 0011	–	0010	Immediately	Tuning	–																										
	n. <table style="display: inline-table; vertical-align: middle;"> <tr> <td style="text-align: center;">4th digit</td> <td style="text-align: center;">3rd digit</td> <td style="text-align: center;">2nd digit</td> <td style="text-align: center;">1st digit</td> </tr> <tr> <td style="text-align: center;">□</td> <td style="text-align: center;">□</td> <td style="text-align: center;">□</td> <td style="text-align: center;">□</td> </tr> </table>		4th digit	3rd digit	2nd digit	1st digit	□	□	□	□	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="text-align: right;">Anti-Resonance Control Selection</td> <td style="text-align: right;">(refer to 12.3 and 13.4.20)</td> </tr> <tr> <td style="text-align: center;">0</td> <td colspan="2">Does not use anti-resonance control.</td> </tr> <tr> <td style="text-align: center;">1</td> <td colspan="2">Uses anti-resonance control.</td> </tr> <tr> <td colspan="3" style="text-align: center;">Reserved (Do not change.)</td> </tr> <tr> <td colspan="3" style="text-align: center;">Reserved (Do not change.)</td> </tr> <tr> <td colspan="3" style="text-align: center;">Reserved (Do not change.)</td> </tr> </table>						Anti-Resonance Control Selection		(refer to 12.3 and 13.4.20)	0	Does not use anti-resonance control.		1	Uses anti-resonance control.		Reserved (Do not change.)			Reserved (Do not change.)			Reserved (Do not change.)		
	4th digit	3rd digit	2nd digit	1st digit																														
	□	□	□	□																														
	Anti-Resonance Control Selection		(refer to 12.3 and 13.4.20)																															
	0	Does not use anti-resonance control.																																
1	Uses anti-resonance control.																																	
Reserved (Do not change.)																																		
Reserved (Do not change.)																																		
Reserved (Do not change.)																																		
Pn161	2	Anti-Resonance Frequency	10 to 20000	0.1 Hz	1000	Immediately	Tuning	–																										
Pn162	2	Anti-Resonance Gain Compensation	1 to 1000	1%	100	Immediately	Tuning	–																										
Pn163	2	Anti-Resonance Damping Gain	0 to 300	1%	0	Immediately	Tuning	–																										
Pn164	2	Anti-Resonance Filter Time Constant 1 Compensation	-1000 to 1000	0.01 ms	0	Immediately	Tuning	–																										
Pn165	2	Anti-Resonance Filter Time Constant 2 Compensation	-1000 to 1000	0.01 ms	0	Immediately	Tuning	–																										
Pn20E	4	Reserved (Do not change.)	–	–	1	After restart	Setup	–																										
Pn210	4	Reserved (Do not change.)	–	–	1	After restart	Setup	–																										
Pn230	4	Number of Encoder Pulse	100 to 1048576	1 Pitch/Rev	1024	After restart	Setup	–																										
Pn232	2	C-Phase Compensation Width	-200 to 200	1 pulse	0	After restart	Setup	–																										
Pn234	2	Pulse Encoder Stop Vibration Suppression	0000 to 0001	–	0001	Immediately	Setup	–																										
	n. <table style="display: inline-table; vertical-align: middle;"> <tr> <td style="text-align: center;">4th digit</td> <td style="text-align: center;">3rd digit</td> <td style="text-align: center;">2nd digit</td> <td style="text-align: center;">1st digit</td> </tr> <tr> <td style="text-align: center;">□</td> <td style="text-align: center;">□</td> <td style="text-align: center;">□</td> <td style="text-align: center;">□</td> </tr> </table>		4th digit	3rd digit	2nd digit	1st digit	□	□	□	□	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2" style="text-align: right;">Pulse Encoder Stop Vibration Suppression</td> </tr> <tr> <td style="text-align: center;">0</td> <td>Does not use stop vibration suppression.</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Uses stop vibration suppression.</td> </tr> <tr> <td colspan="2" style="text-align: center;">Reserved (Do not change.)</td> </tr> <tr> <td colspan="2" style="text-align: center;">Reserved (Do not change.)</td> </tr> <tr> <td colspan="2" style="text-align: center;">Reserved (Do not change.)</td> </tr> </table>						Pulse Encoder Stop Vibration Suppression		0	Does not use stop vibration suppression.	1	Uses stop vibration suppression.	Reserved (Do not change.)		Reserved (Do not change.)		Reserved (Do not change.)							
	4th digit	3rd digit	2nd digit	1st digit																														
	□	□	□	□																														
	Pulse Encoder Stop Vibration Suppression																																	
	0	Does not use stop vibration suppression.																																
1	Uses stop vibration suppression.																																	
Reserved (Do not change.)																																		
Reserved (Do not change.)																																		
Reserved (Do not change.)																																		
Pn235	2	Load Shaft C-Phase Compensation Width	0 to 100	1 pulse	0	After restart	Setup	–																										
Pn300	2	Speed Reference Input Gain 1	50 to 3000	0.01 V/ Base speed	600	Immediately	Setup	–																										
Pn304	2	JOG Speed	0 to 10000	1 min ⁻¹	500	Immediately	Setup	–																										
Pn305	2	Soft Start Acceleration Time	0 to 10000	1 ms	0	Immediately	Setup	–																										

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section																
Pn306	2	Soft Start Deceleration Time	0 to 10000	1 ms	0	Immediately	Setup	–																
Pn30A	2	Speed Reference Input Gain 2	500 to 30000	0.001 V	10000	Immediately	Setup	–																
Pn324	2	Moment of Inertia Calculating Start Level	0 to 20000	1%	300	Immediately	Setup	–																
Pn401	2	1st Step 1st Torque Reference Filter Time Constant	0 to 65535	0.01 ms	397	Immediately	Tuning	–																
Pn406	2	Emergency Stop Torque	0 to 800	1%	800	Immediately	Setup	–																
Pn408	2	Torque Related Function Switch	0000 to 1111	–	0000	Immediately	Setup	–																
	<p>4th digit 3rd digit 2nd digit 1st digit</p> <p>n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/></p> <table border="1"> <thead> <tr> <th colspan="2">1st Step Notch Filter Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disables 1st step notch filter for torque reference.</td> </tr> <tr> <td>1</td> <td>Uses 1st step notch filter for torque reference.</td> </tr> <tr> <td colspan="2">Reserved (Do not change.)</td> </tr> <tr> <th colspan="2">2nd Step Notch Filter Selection</th> </tr> <tr> <td>0</td> <td>Disables 2nd step notch filter for torque reference.</td> </tr> <tr> <td>1</td> <td>Uses 2nd step notch filter for torque reference.</td> </tr> <tr> <td colspan="2">Reserved (Do not change.)</td> </tr> </tbody> </table>								1st Step Notch Filter Selection		0	Disables 1st step notch filter for torque reference.	1	Uses 1st step notch filter for torque reference.	Reserved (Do not change.)		2nd Step Notch Filter Selection		0	Disables 2nd step notch filter for torque reference.	1	Uses 2nd step notch filter for torque reference.	Reserved (Do not change.)	
	1st Step Notch Filter Selection																							
	0	Disables 1st step notch filter for torque reference.																						
	1	Uses 1st step notch filter for torque reference.																						
Reserved (Do not change.)																								
2nd Step Notch Filter Selection																								
0	Disables 2nd step notch filter for torque reference.																							
1	Uses 2nd step notch filter for torque reference.																							
Reserved (Do not change.)																								
Pn409	2	1st Notch Filter Frequency	50 to 2000	1 Hz	2000	Immediately	Tuning	–																
Pn40A	2	1st Notch Filter Q Value	50 to 1000	0.01	70	Immediately	Tuning	–																
Pn40B	2	1st Notch Filter Depth	0 to 1000	0.001	0	Immediately	Tuning	–																
Pn40C	2	2nd Notch Filter Frequency	50 to 2000	1 Hz	2000	Immediately	Tuning	–																
Pn40D	2	2nd Notch Filter Q Value	50 to 1000	0.01	70	Immediately	Tuning	–																
Pn40E	2	2nd Notch Filter Depth	0 to 1000	0.001	0	Immediately	Tuning	–																
Pn412	2	1st Step 2nd Torque Reference Filter Time Constant	0 to 65535	0.01 ms	397	Immediately	Tuning	–																
Pn413	2	1st Step 3rd Torque Reference Filter Time Constant	0 to 65535	0.01 ms	397	Immediately	Tuning	–																
Pn414	2	1st Step 4th Torque Reference Filter Time Constant	0 to 65535	0.01 ms	397	Immediately	Tuning	–																

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section	
Pn416	2	Torque Related Function Switch 2	0000 to 0011	–	0000	Immediately	Setup	–	
			3rd Step Notch Filter Selection						
			0	Disables 3rd step notch filter for torque reference.					
			1	Uses 3rd step notch filter for torque reference.					
			4rd Step Notch Filter Selection						
			0	Disables 4rd step notch filter for torque reference.					
			1	Uses 4rd step notch filter for torque reference.					
			Reserved (Do not change.)						
			Reserved (Do not change.)						
Pn417	2	3rd Notch Filter Frequency	50 to 2000	1 Hz	2000	Immediately	Tuning	–	
Pn418	2	3rd Notch Filter Q Value	50 to 1000	0.01	70	Immediately	Tuning	–	
Pn419	2	3rd Notch Filter Depth	0 to 1000	0.001	0	Immediately	Tuning	–	
Pn41A	2	4th Notch Filter Frequency	50 to 2000	1 Hz	2000	Immediately	Tuning	–	
Pn41B	2	4th Notch Filter Q Value	50 to 1000	0.01	70	Immediately	Tuning	–	
Pn41C	2	4th Notch Filter Depth	0 to 1000	0.001	0	Immediately	Tuning	–	
Pn430	2	Torque Limit (Powering)	0 to 800	1%	150	Immediately	Setup	–	
Pn431	2	Torque Limit (Regeneration)	0 to 800	1%	150	Immediately	Setup	–	
Pn432	2	Motor Flux Lower Level	10 to 100	1%	15	Immediately	Setup	–	
Pn433	2	Servo Mode Flux Level (for High-speed Winding)	30 to 100	1%	100	Immediately	Setup	–	
Pn434	2	Servo Mode Base Speed Ratio (for High-speed Winding)	100 to 500	1%	100	Immediately	Setup	–	
Pn435	2	Servo Mode Flux Level (for Low-speed Winding)	30 to 100	1%	100	Immediately	Setup	–	
Pn436	2	Servo Mode Base Speed Ratio (for Low-speed Winding)	100 to 500	1%	100	Immediately	Setup	–	
Pn43A	2	Flux Level at Completion of Orientation	10 to 100	1%	60	Immediately	Setup	–	
Pn43B	2	Flux Level for Orientation Control	10 to 100	1%	60	Immediately	Setup	–	
Pn43D	2	Servo Mode Speed Reference Gain 1	0 to 10000	0.01%	10000	After restart	Setup	–	
Pn43E	2	Servo Mode Speed Reference Gain 2	0 to 10000	0.01%	10000	After restart	Setup	–	
Pn43F	2	Load Ratio Meter Filter Time Constant	0 to 5000	1 ms	100	Immediately	Setup	–	

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section	
Pn456	2	Sweep Torque Reference Amplitude	1 to 800	1%	15	Immediately	Tuning	–	
Pn460	2	Notch Filter Adjustment Switch	0000 to 0101	–	0101	Immediately	Tuning	–	
	Notch Filter Adjustment Selection 1								
	0	Does not adjust 1st step notch filter automatically using utility function.							
	1	Adjust 1st step notch filter automatically using utility function.							
	Reserved (Do not change.)								
	Notch Filter Adjustment Selection 2								
	0	Does not adjust 2nd step notch filter automatically using utility function.							
	1	Adjust 2nd step notch filter automatically using utility function.							
	Reserved (Do not change.)								
Pn502	2	Rotation Detection Level	1 to 10000	1 min ⁻¹	20	Immediately	Setup	–	
Pn503	2	Speed Coincidence Signal Output Width	0 to 100	1 min ⁻¹	10	Immediately	Setup	–	
Pn51E	2	Excessive Position Error Warning Level	10 to 100	1%	100	Immediately	Setup	15.3.1	
Pn520	4	Excessive Position Error Alarm Level	1 to 1073741823	1 pulse	5242880	Immediately	Setup	15.2.1	
Pn522	4	Positioning Completed Width (Using an Encoder)	0 to 1073741824	1 pulse	5	Immediately	Setup	–	
Pn524	4	Positioning Release Width (Using an Encoder)	1 to 1073741824	1 pulse	10	Immediately	Setup	–	
Pn526	4	Excessive Position Error Alarm Level at Servo ON	1 to 1073741823	1 pulse	5242880	Immediately	Setup	15.2.1	
Pn528	2	Excessive Position Error Warning Level at Servo ON	10 to 100	1%	100	Immediately	Setup	15.3.1	
Pn529	2	Speed Limit Level at Servo ON	0 to 10000	1 min ⁻¹	10000	Immediately	Setup	15.2.1	
Pn52B	2	Overload Warning Level	1 to 100	1%	20	Immediately	Setup	11.2.5	
Pn52C	2	Derating of Base Current at Detecting Overload of Motor	10 to 100	1%	100	After restart	Setup	11.2.5	

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section																					
Pn530	2	Program JOG Operation Related Switch	0000 to 0005	–	0000	Immediately	Setup	–																					
		<div style="display: flex; justify-content: space-around; font-size: small;"> 4th digit 3rd digit 2nd digit 1st digit </div> <div style="display: flex; align-items: center; margin-top: 5px;"> n. <div style="display: flex; gap: 10px;"> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div> </div>	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Program JOG Operation Switch</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>(Waiting time Pn535 → Forward movement Pn531) × Number of movements Pn536</td> </tr> <tr> <td style="text-align: center;">1</td> <td>(Waiting time Pn535 → Reverse movement Pn531) × Number of movements Pn536</td> </tr> <tr> <td style="text-align: center;">2</td> <td>(Waiting time Pn535 → Forward movement Pn531) × Number of movements Pn536 (Waiting time Pn535 → Reverse movement Pn531) × Number of movements Pn536</td> </tr> <tr> <td style="text-align: center;">3</td> <td>(Waiting time Pn535 → Reverse movement Pn531) × Number of movements Pn536 (Waiting time Pn535 → Forward movement Pn531) × Number of movements Pn536</td> </tr> <tr> <td style="text-align: center;">4</td> <td>(Waiting time Pn535 → Forward movement Pn531 → Waiting time Pn535 → Reverse movement Pn531) × Number of movements Pn536</td> </tr> <tr> <td style="text-align: center;">5</td> <td>(Waiting time Pn535 → Reverse movement Pn531 → Waiting time Pn535 → Forward movement Pn531) × Number of movements Pn536</td> </tr> <tr> <td colspan="2" style="text-align: center;">Reserved (Do not change.)</td> </tr> <tr> <td colspan="2" style="text-align: center;">Reserved (Do not change.)</td> </tr> <tr> <td colspan="2" style="text-align: center;">Reserved (Do not change.)</td> </tr> </tbody> </table>							Program JOG Operation Switch		0	(Waiting time Pn535 → Forward movement Pn531) × Number of movements Pn536	1	(Waiting time Pn535 → Reverse movement Pn531) × Number of movements Pn536	2	(Waiting time Pn535 → Forward movement Pn531) × Number of movements Pn536 (Waiting time Pn535 → Reverse movement Pn531) × Number of movements Pn536	3	(Waiting time Pn535 → Reverse movement Pn531) × Number of movements Pn536 (Waiting time Pn535 → Forward movement Pn531) × Number of movements Pn536	4	(Waiting time Pn535 → Forward movement Pn531 → Waiting time Pn535 → Reverse movement Pn531) × Number of movements Pn536	5	(Waiting time Pn535 → Reverse movement Pn531 → Waiting time Pn535 → Forward movement Pn531) × Number of movements Pn536	Reserved (Do not change.)		Reserved (Do not change.)		Reserved (Do not change.)	
	Program JOG Operation Switch																												
	0	(Waiting time Pn535 → Forward movement Pn531) × Number of movements Pn536																											
	1	(Waiting time Pn535 → Reverse movement Pn531) × Number of movements Pn536																											
	2	(Waiting time Pn535 → Forward movement Pn531) × Number of movements Pn536 (Waiting time Pn535 → Reverse movement Pn531) × Number of movements Pn536																											
	3	(Waiting time Pn535 → Reverse movement Pn531) × Number of movements Pn536 (Waiting time Pn535 → Forward movement Pn531) × Number of movements Pn536																											
	4	(Waiting time Pn535 → Forward movement Pn531 → Waiting time Pn535 → Reverse movement Pn531) × Number of movements Pn536																											
	5	(Waiting time Pn535 → Reverse movement Pn531 → Waiting time Pn535 → Forward movement Pn531) × Number of movements Pn536																											
	Reserved (Do not change.)																												
Reserved (Do not change.)																													
Reserved (Do not change.)																													
Pn531	4	Program JOG Movement Distance	1 to 1073741824	1 pulse	32768	Immediately	Setup	–																					
Pn533	2	Program JOG Movement Speed	1 to 10000	1 min ⁻¹	500	Immediately	Setup	–																					
Pn534	2	Program JOG Acceleration/Deceleration Time	2 to 10000	1 ms	100	Immediately	Setup	–																					
Pn535	2	Program JOG Waiting Time	0 to 10000	1 ms	100	Immediately	Setup	–																					
Pn536	2	Number of Times of Program JOG Movement	0 to 1000	1 time	1	Immediately	Setup	–																					
Pn541	2	Rated Speed Setting	100 to 65535	1 min ⁻¹	65535	After restart	Setup	–																					
Pn542	2	Speed Coincidence Detection Width	10 to 50	1%	15	Immediately	Setup	–																					
Pn543	2	Speed Detection Level	0 to 10000	0.01%	100	Immediately	Setup	–																					
Pn544	2	Speed Detection Hysteresis	0 to 10000	0.01%	10	Immediately	Setup	–																					

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section		
Pn545	2	Speed Error Excessive Protection Select Switch	0000 to 0031	–	0000	Immediately	–	–		
	Detection Range of Speed Error Excessive Protection									
				0	1/2 or less of speed reference					
				1	1/4 or less of speed reference					
	Delay Time of Speed Error Excessive Protection									
				0	0 ms					
				1	300 ms					
				2	400 ms					
				3	500 ms					
Reserved (Do not change.)										
Reserved (Do not change.)										
Pn550	2	Analog Monitor 1 Offset Voltage	-10000 to 10000	0.1 V	0	Immediately	Setup	12.2		
Pn551	2	Analog Monitor 2 Offset Voltage	-10000 to 10000	0.1 V	0	Immediately	Setup			
Pn552	2	Analog Monitor Magnification (×1)	-10000 to 10000	×0.01	100	Immediately	Setup			
Pn553	2	Analog Monitor Magnification (×2)	-10000 to 10000	×0.01	100	Immediately	Setup			
Pn630	2	Emergency Stop Execution Delay Time	0 to 10000	1 ms	0	Immediately	Setup		–	
Pn632	2	Emergency Stop Fault Detection Time	0 to 65535	1 ms	10000	Immediately	Setup	–		
Pn800	4	Forward/Reverse Signal Acceleration Constant	1 to FFFFFFFF	10^n pulse/ s^2	100	Immediately	Setup	–		
Pn802	4	Forward/Reverse Signal Deceleration Constant	1 to FFFFFFFF	10^n pulse/ s^2	100	Immediately	Setup	–		
Pn804	2	Zero-Speed Braking Time	0 to 100	1 s	0	After restart	Setup	–		
Pn805	2	External Low-Torque Limit Level	0 to 800	1%	5	Immediately	Setup	–		
Pn806	2	External High-Torque Limit Level	0 to 800	1%	10	Immediately	Setup	–		

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section	
Pn807	2	Motion Select	0000 to 0001	–	0000	After restart	Setup	–	
		<div style="display: flex; justify-content: space-around; font-size: small;"> 4th digit 3rd digit 2nd digit 1st digit </div> <div style="display: flex; align-items: center; margin-top: 5px;"> n. <div style="display: flex; gap: 10px;"> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div> </div>							
			Torque Limit Auto Judgement						
			0 Not judged						
			1 Judged						
		Reserved (Do not change.)							
		Reserved (Do not change.)							
		Reserved (Do not change.)							
Pn80A	4	Load Shaft Positioning Origin (Using an Encoder)	0 to 1073741824	1 pulse	0	Immediately	Setup	–	
Pn80C	2	Load Shaft Positioning Origin (Using a Magnetic Sensor)	-200 to 200	0.01 deg	0	Immediately	Setup	–	
Pn80D	2	Positioning Completed Width (Using a Magnetic Sensor)	0 to 200	0.1 deg	5	Immediately	Setup	–	
Pn80E	2	Positioning Release Width (Using a Magnetic Sensor)	0 to 200	0.1 deg	10	Immediately	Setup	–	
Pn80F	2	Magnetic Sensor Signal Standardization Angle	50 to 200	0.1 deg	50	After restart	Setup	–	
Pn810	4	Reserved (Do not change.)	–	–	0	–	Setup	–	
Pn812	2	Orientation Target Speed	0 to 40960	10 pulse/s	3413	Immediately	Setup	–	
Pn813	4	Orientation Acceleration Constant	1 to 4294967295	10 ⁿ pulse/s ²	10	Immediately	Setup	–	
Pn815	4	Orientation Deceleration Constant	1 to 4294967295	10 ⁿ pulse/s ²	10	Immediately	Setup	–	
Pn817	4	Machine Encoder Pulse	1 to 1073741823	1 pulse	4096	After restart	Setup	–	
Pn819	2	BCD Stop Position Reference Resolution	1 to 1800	0.1 deg	10	After restart	Setup	–	

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section												
Pn81C	2	Orientation Function Select Switch 1	0000 to 1013	–	0000	After restart	Setup	–												
	4th digit 3rd digit 2nd digit 1st digit n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		<table border="1"> <thead> <tr> <th colspan="2">Orientation Positioning Rotation Direction</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Automatically selected rotation direction</td> </tr> <tr> <td>1</td> <td>Same direction as the forward/reverse run signal</td> </tr> <tr> <td>2</td> <td>Forward rotation of load shaft</td> </tr> <tr> <td>3</td> <td>Reverse rotation of load shaft</td> </tr> </tbody> </table>						Orientation Positioning Rotation Direction		0	Automatically selected rotation direction	1	Same direction as the forward/reverse run signal	2	Forward rotation of load shaft	3	Reverse rotation of load shaft		
	Orientation Positioning Rotation Direction																			
	0	Automatically selected rotation direction																		
	1	Same direction as the forward/reverse run signal																		
	2	Forward rotation of load shaft																		
	3	Reverse rotation of load shaft																		
			<table border="1"> <thead> <tr> <th colspan="2">Incremental Positioning Reference Point</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Previous stop reference position</td> </tr> <tr> <td>1</td> <td>Current stop position</td> </tr> </tbody> </table>						Incremental Positioning Reference Point		0	Previous stop reference position	1	Current stop position						
	Incremental Positioning Reference Point																			
	0	Previous stop reference position																		
1	Current stop position																			
		Reserved (Do not change.)																		
		<table border="1"> <thead> <tr> <th colspan="2">Tuneup Operation</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Tuneup enabled</td> </tr> <tr> <td>1</td> <td>Tuneup disabled</td> </tr> </tbody> </table>						Tuneup Operation		0	Tuneup enabled	1	Tuneup disabled							
Tuneup Operation																				
0	Tuneup enabled																			
1	Tuneup disabled																			
Pn820	4	Speed Detection Level	0 to 2097152000	1 pulse/s	40960	After restart	Setup	–												
Pn822	2	Speed Detection Hysteresis	0 to 10000	0.01%	1000	After restart	Setup	–												
Pn823	2	Torque Detection Signal Level	50 to 3000	0.1%	100	Immediately	Setup	–												
Pn824	2	Torque Detection Signal Hysteresis	0 to 100	0.1%	10	Immediately	Setup	–												
Pn82A	2	Sequence Input Signal Selection 1	0000 to 1112	–	0000	After restart	Setup	–												
	4th digit 3rd digit 2nd digit 1st digit n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>		<table border="1"> <thead> <tr> <th colspan="2">TLL/INC Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>TLL selected</td> </tr> <tr> <td>1</td> <td>INC selected</td> </tr> <tr> <td>2</td> <td>Not selected</td> </tr> </tbody> </table>						TLL/INC Selection		0	TLL selected	1	INC selected	2	Not selected				
	TLL/INC Selection																			
	0	TLL selected																		
	1	INC selected																		
	2	Not selected																		
			<table border="1"> <thead> <tr> <th colspan="2">TLH Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>TLH selected</td> </tr> <tr> <td>1</td> <td>Not selected</td> </tr> </tbody> </table>						TLH Selection		0	TLH selected	1	Not selected						
	TLH Selection																			
	0	TLH selected																		
	1	Not selected																		
		<table border="1"> <thead> <tr> <th colspan="2">SSC/SV Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>SSC selected</td> </tr> <tr> <td>1</td> <td>SV selected</td> </tr> </tbody> </table>						SSC/SV Selection		0	SSC selected	1	SV selected							
SSC/SV Selection																				
0	SSC selected																			
1	SV selected																			
		<table border="1"> <thead> <tr> <th colspan="2">PPI/LM10 Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PPI selected</td> </tr> <tr> <td>1</td> <td>LM10 selected</td> </tr> </tbody> </table>						PPI/LM10 Selection		0	PPI selected	1	LM10 selected							
PPI/LM10 Selection																				
0	PPI selected																			
1	LM10 selected																			

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section								
Pn82B	2	Sequence Input Signal Selection 2	0000 to 0001	–	0000	After restart	Setup	–								
	<p>4th digit 3rd digit 2nd digit 1st digit n. □ □ □ □</p> <p>RDY/EMG2 Selection</p> <table border="1"> <tr><td>0</td><td>RDY selected</td></tr> <tr><td>1</td><td>EMG2 selected</td></tr> </table> <p>Reserved (Do not change.)</p> <p>Reserved (Do not change.)</p> <p>Reserved (Do not change.)</p>								0	RDY selected	1	EMG2 selected				
	0	RDY selected														
	1	EMG2 selected														
	Pn82C	2	Sequence Output Signal Selection 1	0000 to 0011	–	0000	After restart	Setup	–							
<p>4th digit 3rd digit 2nd digit 1st digit n. □ □ □ □</p> <p>Speed Agree Signal Output at Zero Speed</p> <table border="1"> <tr><td>0</td><td>Output</td></tr> <tr><td>1</td><td>Not output</td></tr> </table> <p>Torque Detection Signal Output</p> <table border="1"> <tr><td>0</td><td>Standard output</td></tr> <tr><td>1</td><td>Does not output at acceleration/deceleration.</td></tr> </table> <p>Reserved (Do not change.)</p> <p>Reserved (Do not change.)</p>								0	Output	1	Not output	0	Standard output	1	Does not output at acceleration/deceleration.	
0		Output														
1		Not output														
0		Standard output														
1	Does not output at acceleration/deceleration.															
Pn830	2	5th Speed Loop Gain	10 to 20000	0.1 Hz	100	Immediately	Tuning	–								
Pn831	2	5th Speed Loop Integral Time Constant	15 to 51200	0.01 ms	3000	Immediately	Tuning	–								
Pn832	2	5th Position Loop Gain	10 to 20000	0.1/s	100	Immediately	Tuning	–								
Pn833	2	1st Step 5th Torque Reference Filter Time Constant	0 to 65535	0.01 ms	397	Immediately	Tuning	–								
Pn834	2	6th Speed Loop Gain	10 to 20000	0.1 Hz	100	Immediately	Tuning	–								
Pn835	2	6th Speed Loop Integral Time Constant	15 to 51200	0.01 ms	3000	Immediately	Tuning	–								
Pn836	2	6th Position Loop Gain	10 to 20000	0.1/s	100	Immediately	Tuning	–								
Pn837	2	1st Step 6th Torque Reference Filter Time Constant	0 to 65535	0.01 ms	397	Immediately	Tuning	–								
Pn838	2	7th Speed Loop Gain	10 to 20000	0.1 Hz	100	Immediately	Tuning	–								
Pn839	2	7th Speed Loop Integral Time Constant	15 to 51200	0.01 ms	3000	Immediately	Tuning	–								
Pn83A	2	7th Position Loop Gain	10 to 20000	0.1/s	100	Immediately	Tuning	–								

(cont'd)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classification	Reference Section																							
Pn83B	2	1st Step 7th Torque Reference Filter Time Constant	0 to 65535	0.01 ms	397	Immediately	Tuning	–																							
Pn83C	2	Gear Ratio 1	400 to 25000	0.0001	10000	After restart	Tuning	–																							
Pn83D	2	Gear Ratio 2	400 to 25000	0.0001	10000	After restart	Tuning	–																							
Pn83E	2	Gear Ratio 3	400 to 25000	0.0001	10000	After restart	Tuning	–																							
Pn84C	2	Speed Meter Gain Adjustment Value	90 to 150	0.01	100	Immediately	Setup	–																							
Pn84D	2	Load Ratio Gain Adjustment	90 to 150	0.01	100	Immediately	Setup	–																							
Pn84E	2	Load Ratio Meter Full Scale Value	100 to 1000	1%	200	Immediately	Setup	–																							
Pn850	2	12-bit Digital Input Selection	0000 to 0231	–	0000	After restart	Setup	–																							
	<p>4th digit 3rd digit 2nd digit 1st digit</p> <p>n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/></p> <table border="1"> <thead> <tr> <th colspan="2">12-bit Digital Reference Signal Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Digital reference signal</td> </tr> <tr> <td>1</td> <td>Orientation control stop position reference</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th colspan="2">Digital Speed Reference Selection</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>12-bit binary</td> </tr> <tr> <td>1</td> <td>BCD 3-digit</td> </tr> <tr> <td>2</td> <td>BCD 2-digit</td> </tr> <tr> <td>3</td> <td>Internal speed setting</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th colspan="2">Orientation Control Stop Position Reference Code</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>12-bit binary</td> </tr> <tr> <td>1</td> <td>BCD 3-digit</td> </tr> <tr> <td>2</td> <td>Reserved (Do not change.)</td> </tr> </tbody> </table> <p>Reserved (Do not change.)</p>								12-bit Digital Reference Signal Selection		0	Digital reference signal	1	Orientation control stop position reference	Digital Speed Reference Selection		0	12-bit binary	1	BCD 3-digit	2	BCD 2-digit	3	Internal speed setting	Orientation Control Stop Position Reference Code		0	12-bit binary	1	BCD 3-digit	2
12-bit Digital Reference Signal Selection																															
0	Digital reference signal																														
1	Orientation control stop position reference																														
Digital Speed Reference Selection																															
0	12-bit binary																														
1	BCD 3-digit																														
2	BCD 2-digit																														
3	Internal speed setting																														
Orientation Control Stop Position Reference Code																															
0	12-bit binary																														
1	BCD 3-digit																														
2	Reserved (Do not change.)																														
Pn851	2	Internal Set Speed 1	0 to 10000	0.01%	0	After restart	Setup	–																							
Pn852	2	Internal Set Speed 2	0 to 10000	0.01%	0	After restart	Setup	–																							
Pn853	2	Internal Set Speed 3	0 to 10000	0.01%	0	After restart	Setup	–																							
Pn854	2	Internal Set Speed 4	0 to 10000	0.01%	0	After restart	Setup	–																							
Pn855	2	Internal Set Speed 5	0 to 10000	0.01%	0	After restart	Setup	–																							
Pn856	2	Internal Set Speed 6	0 to 10000	0.01%	0	After restart	Setup	–																							
Pn857	2	Internal Set Speed 7	0 to 10000	0.01%	0	After restart	Setup	–																							
Pn858	2	Internal Set Speed 8	0 to 10000	0.01%	0	After restart	Setup	–																							
Pn900	2	Acceleration Basic Unit Selection	0003 to 0006	–	0004	After restart	Setup	–																							
Pn910	2	Reserved (Do not change.)	–	–	1810	–	Setup	–																							

16.3 Parameter Recording Table

Use the following form to record parameter settings for maintenance or other applications.

Parameter	Factory Setting					Name	When Enabled
Pn002	0014					Application Function Select Switch 2	After restart
Pn006	0002					Application Function Select Switch 6	Immediately
Pn007	0000					Application Function Select Switch 7	Immediately
Pn008	0000					Application Function Select Switch 8	After restart
Pn00B	0001					Application Function Select Switch B	After restart
Pn00D	0000					Application Function Select Switch D	After restart
Pn01A	0000					Application Function Select Switch 1A	After restart
Pn01B	0000					Application Function Select Switch 1B	After restart
Pn01C	0000					Application Function Select Switch 1C	After restart
Pn01E	0003					Application Function Select Switch 1E	After restart
Pn01F	0001					Application Function Select Switch 1F	After restart
Pn030	0000					Reserved (Do not change.)	–
Pn031	0001					Application Function Select Switch 31	After restart
Pn100	100					Speed Loop Gain	Immediately
Pn101	3000					Speed Loop Integral Time Constant	Immediately
Pn102	100					Position Loop Gain	Immediately
Pn103	100					Moment of Inertia Ratio	Immediately
Pn104	100					2nd Speed Loop Gain	Immediately
Pn105	3000					2nd Speed Loop Integral Time Constant	Immediately
Pn106	100					2nd Position Loop Gain	Immediately
Pn12B	100					3rd Speed Loop Gain	Immediately
Pn12C	3000					3rd Speed Loop Integral Time Constant	Immediately
Pn12D	100					3rd Position Loop Gain	Immediately
Pn12E	100					4th Speed Loop Gain	Immediately
Pn12F	3000					4th Speed Loop Integral Time Constant	Immediately
Pn130	100					4th Position Loop Gain	Immediately
Pn160	0010					Anti-Resonance Control Related Switch	Immediately
Pn161	1000					Anti-Resonance Frequency	Immediately
Pn162	100					Anti-Resonance Gain Compensation	Immediately
Pn163	0					Anti-Resonance Damping Gain	Immediately
Pn164	0					Anti-Resonance Filter Time Constant 1 Compensation	Immediately
Pn165	0					Anti-Resonance Filter Time Constant 2 Compensation	Immediately
Pn20E	1					Reserved (Do not change.)	–
Pn210	1					Reserved (Do not change.)	–

(cont'd)

Parameter	Factory Setting					Name	When Enabled
Pn230	1024					Number of Encoder Pulse	After restart
Pn232	0					C-Phase Compensation Width	After restart
Pn234	0001					Pulse Encoder Stop Vibration Suppression	Immediately
Pn235	0					Load Shaft C-Phase Compensation Width	After restart
Pn300	600					Speed Reference Input Gain 1	Immediately
Pn304	500					JOG Speed	Immediately
Pn305	0					Soft Start Acceleration Time	Immediately
Pn306	0					Soft Start Deceleration Time	Immediately
Pn30A	10000					Speed Reference Input Gain 2	Immediately
Pn324	300					Moment of Inertia Calculating Start Level	Immediately
Pn401	397					Torque Reference Filter Time Constant	Immediately
Pn406	800					Emergency Stop Torque	Immediately
Pn408	0000					Torque Related Function Switch	Immediately
Pn409	2000					1st Notch Filter Frequency	Immediately
Pn40A	70					1st Notch Filter Q Value	Immediately
Pn40B	0					1st Notch Filter Depth	Immediately
Pn40C	2000					2nd Notch Filter Frequency	Immediately
Pn40D	70					2nd Notch Filter Q Value	Immediately
Pn40E	0					2nd Notch Filter Depth	Immediately
Pn412	397					1st Step 2nd Torque Reference Filter Time Constant	Immediately
Pn413	397					1st Step 3rd Torque Reference Filter Time Constant	Immediately
Pn414	397					1st Step 4th Torque Reference Filter Time Constant	Immediately
Pn416	0000					Torque Related Function Switch 2	Immediately
Pn417	2000					3rd Notch Filter Frequency	Immediately
Pn418	70					3rd Notch Filter Q Value	Immediately
Pn419	0					3rd Notch Filter Depth	Immediately
Pn41A	2000					4th Notch Filter Frequency	Immediately
Pn41B	70					4th Notch Filter Q Value	Immediately
Pn41C	0					4th Notch Filter Depth	Immediately
Pn430	150					Torque Limit (Powering)	Immediately
Pn431	150					Torque Limit (Regeneration)	Immediately
Pn432	15					Motor Flux Lower Level	Immediately
Pn433	100					Servo Mode Flux Level (for High-speed Winding)	Immediately
Pn434	100					Servo Mode Base Speed Ratio (for High-speed Winding)	Immediately
Pn435	100					Servo Mode Flux Level (for Low-speed Winding)	Immediately
Pn436	100					Servo Mode Base Speed Ratio (for Low-speed Winding)	Immediately
Pn43A	60					Flux Level at Completion of Orientation	Immediately

(cont'd)

Parameter	Factory Setting					Name	When Enabled
Pn43B	60					Flux Level for Orientation Control	Immediately
Pn43D	10000					Servo Mode Speed Reference Gain 1	After restart
Pn43E	10000					Servo Mode Speed Reference Gain 2	After restart
Pn43F	100					Load Ratio Meter Filter Time Constant	Immediately
Pn456	15					Sweep Torque Reference Amplitude	Immediately
Pn460	0101					Notch Filter Adjustment Switch	Immediately
Pn502	20					Rotation Detection Level	Immediately
Pn503	10					Speed Coincidence Signal Output Width	Immediately
Pn51E	100					Excessive Position Error Warning Level	Immediately
Pn520	5242880					Excessive Position Error Alarm Level	Immediately
Pn522	5					Positioning Completed Width (Using an Encoder)	Immediately
Pn524	10					Positioning Release Width (Using an Encoder)	Immediately
Pn526	5242880					Excessive Position Error Alarm Level at Servo ON	Immediately
Pn528	100					Excessive Position Error Warning Level at Servo ON	Immediately
Pn529	10000					Speed Limit Level at Servo ON	Immediately
Pn52B	20					Overload Warning Level	Immediately
Pn52C	100					Derating of Base Current at Detecting Overload of Motor	After restart
Pn530	0000					Program JOG Operation Related Switch	Immediately
Pn531	32768					Program JOG Movement Distance	Immediately
Pn533	500					Program JOG Movement Speed	Immediately
Pn534	100					Program JOG Acceleration/Deceleration Time	Immediately
Pn535	100					Program JOG Waiting Time	Immediately
Pn536	1					Number of Times of Program JOG Movement	Immediately
Pn541	65535					Rated Speed Setting	After restart
Pn542	15					Speed Coincidence Detection Width	Immediately
Pn543	100					Speed Detection Level	Immediately
Pn544	10					Speed Detection Hysteresis	Immediately
Pn545	0000					Speed Error Excessive Protection Select Switch	Immediately
Pn550	0					Analog Monitor 1 Offset Voltage	Immediately
Pn551	0					Analog Monitor 2 Offset Voltage	Immediately
Pn552	100					Analog Monitor Magnification (×1)	Immediately
Pn553	100					Analog Monitor Magnification (×2)	Immediately
Pn630	0					Emergency Stop Execution Delay Time	Immediately
Pn632	10000					Emergency Stop Fault Detection Time	Immediately

(cont'd)

Parameter	Factory Setting					Name	When Enabled
Pn800	100					Forward/Reverse Signal Acceleration Constant	Immediately
Pn802	100					Forward/Reverse Signal Deceleration Constant	Immediately
Pn804	0					Zero-Speed Braking Time	After restart
Pn805	5					External Control Low-Torque Limit Level	Immediately
Pn806	10					External Control High-Torque Limit Level	Immediately
Pn807	0000					Motion Select	After restart
Pn80A	0					Load Shaft Positioning Origin (Using an Encoder)	Immediately
Pn80C	0					Load Shaft Positioning Origin (Using a Magnetic Sensor)	Immediately
Pn80D	5					Positioning Completed Width (Using a Magnetic Sensor)	Immediately
Pn80E	10					Positioning Release Width (Using a Magnetic Sensor)	Immediately
Pn80F	50					Magnetic Sensor Signal Standardization Angle	After restart
Pn810	0					Reserved (Do not change.)	Immediately
Pn812	3413					Orientation Target Speed	Immediately
Pn813	10					Orientation Acceleration Constant	Immediately
Pn815	10					Orientation Deceleration Constant	Immediately
Pn817	4096					Reference Pulses per Machine Rotation	After restart
Pn819	10					BCD Stop Position Reference Resolution	After restart
Pn81C	0000					Orientation Function Select Switch 1	After restart
Pn820	40960					Speed Detection Level	After restart
Pn822	1000					Speed Detection Hysteresis	After restart
Pn823	100					Torque Detection Signal Level	Immediately
Pn824	10					Torque Detection Signal Hysteresis	Immediately
Pn82A	0000					Sequence Input Signal Selection 1	After restart
Pn82B	0000					Sequence Input Signal Selection 2	After restart
Pn82C	0000					Sequence Output Signal Selection 1	After restart
Pn830	100					5th Speed Loop Gain	Immediately
Pn831	3000					5th Speed Loop Integral Time Constant	Immediately
Pn832	100					5th Position Loop Gain	Immediately
Pn833	397					1st Step 5th Torque Reference Filter Time Constant	Immediately
Pn834	100					6th Speed Loop Gain	Immediately
Pn835	3000					6th Speed Loop Integral Time Constant	Immediately
Pn836	100					6th Position Loop Gain	Immediately
Pn837	397					1st Step 6th Torque Reference Filter Time Constant	Immediately
Pn838	100					7th Speed Loop Gain	Immediately

(cont'd)

Parameter	Factory Setting						Name	When Enabled
Pn839	3000						7th Speed Loop Integral Time Constant	Immediately
Pn83A	100						7th Position Loop Gain	Immediately
Pn83B	397						1st Step 7th Torque Reference Filter Time Constant	Immediately
Pn83C	10000						Gear Ratio 1	After restart
Pn83D	10000						Gear Ratio 2	After restart
Pn83E	10000						Gear Ratio 3	After restart
Pn84C	100						Speed Meter Gain Adjustment Value	Immediately
Pn84D	100						Load Ratio Gain Adjustment	Immediately
Pn84E	200						Load Ratio Meter Full Scale Value	Immediately
Pn850	0000						12-bit Digital Input Selection	After restart
Pn851	0						Internal Set Speed 1	After restart
Pn852	0						Internal Set Speed 2	After restart
Pn853	0						Internal Set Speed 3	After restart
Pn854	0						Internal Set Speed 4	After restart
Pn855	0						Internal Set Speed 5	After restart
Pn856	0						Internal Set Speed 6	After restart
Pn857	0						Internal Set Speed 7	After restart
Pn858	0						Internal Set Speed 8	After restart
Pn900	0004						Acceleration Basic Unit Selection	After restart
Pn910	1810						Reserved (Do not change.)	–

16.4 Determining Drive Capacity

When controlling machine speed, a servo drive must supply torque to match the characteristics of the machine that makes up the motor load, as well as torque to accelerate and decelerate the drive system (couplings, machine, and motor). Consider the following points when determining drive capacity.




- Make clear the ratings to be used (continuous rating, short-time rating, and repetitive rating) to suit the load characteristics.
- Consider the efficiency of the motive force transmission mechanism and the load dispersion, and select a drive capacity greater than the motive force required by the load.
- Select a capacity that can sufficiently provide the startup torque and maximum torque required by the load. Use the following equation to select the drive capacity.

$$\text{Drive load} \geq \text{Motive force to drive the load mechanism} + \text{Motive force to accelerate and decelerate the load mechanism to the required speed}$$

The above equation shows the method for calculating load drive force and acceleration/deceleration motive force.

16.4.1 Load Drive Capacity

The following table shows the torque-speed characteristics of the load mechanism that uses the servo drive.

Load Characteristics	Load Examples	Speed-Torque Characteristics	Motor Capacity
Fixed Torque Load Load torque over speed is a fixed load. (Usually a friction load.)	<ul style="list-style-type: none"> • Conveyers • Cranes • Winches • Other friction loads and gravity loads 	<ul style="list-style-type: none"> • Load torque is fixed regardless of speed. • Output is proportional to speed.  <p>The graph shows a square coordinate system with 'Torque and output' on the vertical axis and 'Speed' on the horizontal axis, both ranging from 0 to 1.0. A horizontal line at the top is labeled 'Load torque'. A diagonal line from the origin (0,0) to the top-right corner (1.0, 1.0) is labeled 'Load output'.</p>	Motor capacity is the same as the maximum speed load capacity.
Fixed Output Load Required output over speed is a fixed load.	<ul style="list-style-type: none"> • Center drive low tension winders • Main axis of machine-tool • Veneer rotor relays 	<p>Within fixed torque range:</p> <ul style="list-style-type: none"> • Load torque is fixed regardless of speed. • Output is proportional to speed. <p>Within fixed output range:</p> <ul style="list-style-type: none"> • Output required by load is fixed. • Load torque is inversely proportional to speed.  <p>The graph shows a square coordinate system with 'Load torque' on the vertical axis and 'Speed' on the horizontal axis, both ranging from 0 to 2.0. A horizontal line at the top is labeled 'Load output'. A curve starting at (0,0) and rising to (1.0, 1.0) is labeled 'Load torque'.</p>	Required rated output when using a drive with fixed torque characteristics is as follows: Required output = Load output × Fixed output control ratio ^{1/2}
Reduced Output Load Load torque overspeed is a variable load. Load has the intermediate characteristics of fixed output load and fixed torque load.		<p>Intermediate speed-torque and output characteristics of fixed torque load and fixed output load</p>  <p>The graph shows a square coordinate system with 'Load output' on the vertical axis and 'Speed' on the horizontal axis, both ranging from 0 to 1.0. A diagonal line from the origin to the top-right corner is labeled 'Load output'. A curve starting at (0,0) and rising to (1.0, 1.0) is labeled 'Load torque'.</p>	Motor capacity is the same as the maximum speed load capacity.


(1) Servo Drives for Main Axes of Machine Tools

The cutting force determines the required force for a Servo Drive for the main axis of a lathe or machining center. Constant output characteristics are required for cutting, and a constant output control range of 1: 10 to 1: 30 is required. The method to calculate the required force is given for the following lathe processing, machine center milling, and drilling examples.

Note: The cutting oil conditions, the cutting tool material and shape, the hardness of the material being cut, and other factors that affect the cutting resistance must also be considered to accurately calculate the required force.

■ Lathe Processing Example

For lathe cutting, the object to be cut is rotated and the blade is pressed against it to cut the object, as shown in the following diagram.



The force, P_C , that is required to cut the object is calculated with the following formula.

$$P_C = \frac{K_S dLV}{60 \times 1000 \times \eta_C} = \frac{dLV}{S_C \cdot \eta_C} \text{ (kW)}$$

$$V = \frac{\pi D N_S}{1000} \text{ (m/min)}$$

K_S : Cutting resistance (N/mm^2)

d : Cutting depth (mm)

L : Length of blade actually performing cutting (i.e., amount of feed per rotation) (mm)

D : Diameter of object being processed (mm)


N_S : Main axis speed (min^{-1})

η_C : Machine efficiency 0.7 to 0.85


S_C : Cutting efficiency (i.e., cutting amount per 1 kW per minute) (CC/kW/min.)

■ Milling Example

For milling, the blade is mounted to the main axis and rotated to cut the object being processed.



(a) Side Milling



(b) Front Milling

The force, P_F , that is required to cut the object is calculated with the following formula.

$$P_F = \frac{K_S \delta W f}{60 \times 1000^2 \times \eta_F} = \frac{\delta W f}{1000^2 S_F \eta_F} \text{ (kW)}$$

K_S : Cutting resistance (N/mm^2)

δ : Cutting depth (mm)

W : Cutting width (mm)


f : Feed speed (mm/min.)

S_F : Cutting efficiency (i.e., cutting amount per 1 kW per minute) (CC/kW/min.)

η_F : Machine efficiency 0.7 to 0.85

■ Drilling Example

For drilling, the drill is mounted to the main axis and rotated, opening a hole in the material being processed.



The force, P_D , that is required is calculated with the following formula.


Note: The load torque, M , varies with the material, the drilling diameter (D), and the feed speed.

$$P_D = \frac{M \cdot 2 \pi n}{60 \times 100 \times 1000 \times \eta_D} = \frac{\pi D^2 f}{4 \times 1000 \times S_D \eta_D} \text{ (kW)}$$

- M : Drill load torque (N·cm)
- n : Main axis speed (min^{-1})
- η_D : Machine efficiency 0.7 to 0.85
- D : Drilling diameter (mm)
- f : Feed speed (mm/min.)
- S_D : Cutting efficiency (i.e., cutting amount per 1 kW per minute) (CC/kW/min.)

(2) Servo Drivers with a Gravity Load

The force required to vertically move a load, such as with a crane or loader, differs greatly depending on whether a counterweight is used.



(a) Without counterweight

(b) With counterweight

The force that is required for each is calculated with the following formulas.


$$\text{Without counterweight: } P_{GL} = \frac{m_L V}{6120 \eta} \text{ (kW)}$$

$$\text{With counterweight: } P_{GLC} = \frac{(m_L - m_C) V}{6120 \eta} \text{ (kW)}$$

- V : Vertical travel speed (m/min.)
- η : Machine efficiency
- m_L : Load mass (kg)
- m_C : Counterweight mass (kg)

(3) Servo Drives with Friction Loads

Cranes, tables, and other horizontal conveyance equipment are friction loads.



The force, P_F , that is required is calculated with the following formula, where μ is the friction coefficient.

$$P_F = \frac{\mu m_L V}{6120\eta} \text{ (kW)}$$

16.4.2 Acceleration/deceleration Capacity

When stopping machinery operation, the acceleration method can be selected from rapid acceleration/deceleration to smooth acceleration/deceleration, depending on the application. A comparison of these acceleration methods is shown in the following table.

Acceleration Method	Control Method	Explanatory Diagram	Remarks
Current-limited Acceleration	This method suppresses the current during acceleration to a fixed value to protect the drive unit and machinery.		Fixes the torque generated by the motor during acceleration.
Time-limited Acceleration	This method suppresses the acceleration rate so that there is linear acceleration change over time, against rapid speed reference changes.		Fixes the acceleration torque.
S-curve Acceleration	This method further suppresses torque over the above method, to perform smooth acceleration.		Suppresses the rate of change in the torque at the start and end of acceleration.

Calculate the acceleration/deceleration capacity using the severest current-limiting acceleration according to capacity. The formula for calculating the drive capacity required from the acceleration time t (s) is shown below.

- Required drive capacity of the fixed torque characteristics range ($0 \leq N_M \leq N_B$)

$$P_M = \left(\frac{2\pi}{60}\right)^2 \frac{J_M N_M^2}{1000 t} \text{ (kW)}$$

- Required drive capacity of the fixed torque characteristics + the fixed output characteristics range ($0 \leq N_M \leq N_{MAX}$)

$$P_M = \left(\frac{2\pi}{60}\right)^2 \frac{J_M (N_M^2 + N_B^2)}{2000 t} \text{ (kW)}$$

J_M : Motor axis conversion inertial moment ($\text{kg}\cdot\text{m}^2$)

P_M : Motor output at base speed (kW)


N_M : Operation speed (min^{-1})

N_B : Base speed (min^{-1})

N_{MAX} : Maximum speed (min^{-1})

■ Calculation Conditions

An example of calculations based on standard drive and machinery specifications is shown below. With actual machinery, the calculated values may vary slightly due to mechanical loss, fluctuations in the power supply voltage, and machine noise and motor magnetic field noise countermeasures.

Item	Value
Acceleration Time	2.5 s (0 to 6,000 min ⁻¹) 0.5 s (0 to 1,500 min ⁻¹)
Inertial Moment J_M	0.13 kg·m ² Load: 0.10 kg·m ² Spindle motor: 0.03 kg·m ² (assuming load to be × 0.3)
Output Characteristics (5 min. Rating)	Base speed N_B : 1500 min ⁻¹  <p>The graph shows Output (kW) on the y-axis and Speed (min⁻¹) on the x-axis. The x-axis has markers at 0, 1500, and 6000. A line starts at (0,0) and rises linearly to a point at 1500 min⁻¹. From 1500 min⁻¹ to 6000 min⁻¹, the output remains constant. This constant output level is indicated by a horizontal dashed line and labeled '5 min. rating' and 'Max. output (120%)'. Vertical dashed lines connect the x-axis values 1500 and 6000 to the graph line.</p>
Maximum Output During Acceleration/ deceleration	120% of 5 min. rated output

■ Calculations

As a result of performing the calculations in **■ Calculation Conditions**, the motive force required from the acceleration/deceleration time is as follows: Upper formula: 5 min. rated 7.5 kW (47.7 N·m); Lower formula: 15 kW (95.0 N·m).

- At 0 to 1,500 min⁻¹

$$P_M = \left(\frac{2\pi}{60}\right)^2 \frac{0.13 \times 1500^2}{1000 \times 0.5} = 6.41 \text{ (kW)}$$

- At 0 to 6,000 min⁻¹

$$P_M = \left(\frac{2\pi}{60}\right)^2 \frac{0.13 \times (6000^2 + 1500^2)}{2000 \times 2.5} = 10.89 \text{ (kW)}$$

16.4.3 Calculating Start and Stop Times

After selecting the machine characteristics and servo drive capacity, the start and stop times can be calculated using formulas in the following table.

Item	Calculating from Torque	Calculating from Output
Motor Characteristics		
Fixed Torque Characteristics ($0 \leq N_M \leq N_B$) $0 \leftrightarrow N_M$ Acceleration/ deceleration Time	$t = \frac{2\pi}{60} \cdot J_M \cdot N_M \cdot \frac{1}{T_M}$	$t = \left(\frac{2\pi}{60}\right)^2 \cdot \frac{J_M}{1000P_M} \cdot N_B \cdot N_M$
Fixed Output Characteristics ($N_B \leq N_M \leq N_{MAX}$) $N_B \leftrightarrow N_M$ Acceleration/ deceleration Time	$t = \frac{2\pi}{60} \cdot J_M \cdot \frac{1}{T_M} \cdot \frac{N_M^2 - N_B^2}{2N_B}$	$t = \left(\frac{2\pi}{60}\right)^2 \cdot \frac{J_M}{1000P_M} \cdot \frac{N_M^2 - N_B^2}{2}$
Fixed Torque + Fixed Output Characteristics ($N_B \leq N_M \leq N_{MAX}$) $0 \leftrightarrow N_M$ Acceleration/ deceleration Time	$t = \frac{2\pi}{60} \cdot J_M \cdot \frac{1}{T_M} \cdot \frac{N_M^2 + N_B^2}{2N_B}$	$t = \left(\frac{2\pi}{60}\right)^2 \cdot \frac{J_M}{1000P_M} \cdot \frac{N_M^2 + N_B^2}{2}$

Note: The values obtained from actual machinery may differ from calculated values due to mechanical losses, fluctuation in supply voltages, mechanical noise, and measures taken for motor's magnetic noise.


- N_M : Operation speed (min^{-1})
- N_B : Base speed (min^{-1})
- N_{MAX} : Maximum speed (min^{-1})
- J_M : Motor axis conversion inertial moment ($\text{kg}\cdot\text{m}^2$) (= Motor inertial moment + motor axis conversion load inertial moment)
- T_M : Motor axis maximum torque at base speed ($\text{N}\cdot\text{m}$) (For a standard motor, max. torque = 5 min. rated torque $\times 1.2$)
- P_M : Motor maximum output at base speed (kW) (For a standard motor, max. output = 5 min. rated output $\times 1.2$)

16.4.4 Intermittent Load Operating Capacity

If operations, such as tapping a machine-tool or driving a conveyer table, are frequently reversed, care must be taken in selecting the capacity. When using an operation cycle that includes acceleration/deceleration operations as follows, select so that the motor equivalence efficiency torque T_R is less than the servo drive continuous rated torque. (The maximum value of T_P will be 120% of the servo drive 5 min. rating.)

- Motor Torque and Speed Timechart

$$T_R = \sqrt{\frac{T_P^2 (t_r + t_f) + T_L^2 t_s}{t_c}} \text{ (N} \cdot \text{m)}$$



The motor reverse rating is the rating over the load where the motor load changes cyclically. When the reverse rated output is taken to be t_1 and with no load is taken to be t_2 , α that is expressed in the following equation is called %ED (Einschalt Dauer). In this equation, $t_1 + t_2$ is always equal to 10 minutes.

$$\alpha = \frac{t_1}{t_1 + t_2} \times 100 \text{ (\%)}$$

Revision History

The revision dates and numbers of the revised manuals are given on the bottom of the back cover.

MANUAL NO. SIEP S800000 39B <1>
 Published in Japan June 2015

Revision number
 Date of publication

Date of Publication	Rev. No.	Section	Revised Content
June 2015	<1>	All sections	Partly revised
		1.2.2, 2.3, 3.2, 3.3, 4.2, 5.2.2, 14.2	Addition: Power Regeneration Converter (model: CACP-JU37A3B)
		2.3.3, 3.3.1	Addition: Information on AC Reactors
		3.3.1	Addition: AC Reactor dimensional drawing (model: X008029)
		5.2.5(5)	Revision: Wiring example for analog input circuit
		13.4.18	Addition: Related parameters Revision: Operating procedure
		15.2.1 and 15.2.2	Addition: Information on A.687
February 2014	–	–	First edition

AC Servo Drives

Σ -V-SD Series

USER'S MANUAL

Speed Reference with Analog Voltage Expanded Functions

IRUMA BUSINESS CENTER (SOLUTION CENTER)

480, Kamifujisawa, Iruma, Saitama, 358-8555, Japan
Phone 81-4-2962-5151 Fax 81-4-2962-6138
<http://www.yaskawa.co.jp>

YASKAWA AMERICA, INC.

2121, Norman Drive South, Waukegan, IL 60085, U.S.A.
Phone 1-800-YASKAWA (927-5292) or 1-847-887-7000 Fax 1-847-887-7310
<http://www.yaskawa.com>

YASKAWA ELÉTRICO DO BRASIL LTDA.

777, Avenida Piraporinha, Diadema, São Paulo, 09950-000, Brasil
Phone 55-11-3585-1100 Fax 55-11-3585-1187
<http://www.yaskawa.com.br>

YASKAWA EUROPE GmbH

185, Hauptstraße, Eschborn, 65760, Germany
Phone 49-6196-569-300 Fax 49-6196-569-398
<http://www.yaskawa.eu.com>

YASKAWA ELECTRIC KOREA CORPORATION

9F, Kyobo Securities Bldg. 26-4, Yeouido-dong, Yeongdeungpo-gu, Seoul, 150-737, Korea
Phone 82-2-784-7844 Fax 82-2-784-8495
<http://www.yaskawa.co.kr>

YASKAWA ELECTRIC (SINGAPORE) PTE. LTD.

151, Lorong Chuan, #04-02A, New Tech Park, 556741, Singapore
Phone 65-6282-3003 Fax 65-6289-3003
<http://www.yaskawa.com.sg>

YASKAWA ELECTRIC (THAILAND) CO., LTD.

252/125-126, 27th Floor, Muang Thai-Phatra Tower B, Rachadapisek Road, Huaykwang, Bangkok, 10310, Thailand
Phone 66-2693-2200 Fax 66-2693-4200
<http://www.yaskawa.co.th>

YASKAWA ELECTRIC (CHINA) CO., LTD.

22F, One Corporate Avenue, No.222, Hubin Road, Shanghai, 200021, China
Phone 86-21-5385-2200 Fax 86-21-5385-3299
<http://www.yaskawa.com.cn>

YASKAWA ELECTRIC (CHINA) CO., LTD. BEIJING OFFICE

Room 1011, Tower W3 Oriental Plaza, No.1, East Chang An Ave.,
Dong Cheng District, Beijing, 100738, China
Phone 86-10-8518-4086 Fax 86-10-8518-4082

YASKAWA ELECTRIC TAIWAN CORPORATION

9F, 16, Nanking E. Rd., Sec. 3, Taipei, 104, Taiwan
Phone 886-2-2502-5003 Fax 886-2-2505-1280

YASKAWA

YASKAWA ELECTRIC CORPORATION

In the event that the end user of this product is to be the military and said product is to be employed in any weapons systems or the manufacture thereof, the export will fall under the relevant regulations as stipulated in the Foreign Exchange and Foreign Trade Regulations. Therefore, be sure to follow all procedures and submit all relevant documentation according to any and all rules, regulations and laws that may apply.

Specifications are subject to change without notice for ongoing product modifications and improvements.

© 2014-2015 YASKAWA ELECTRIC CORPORATION

MANUAL NO. SIEP S800001 39B <1>

Published in Japan June 2015

14-9-10

Original instructions